

# User's Manual

## 73201, 73202, 73203, and 73204

### Digital Multimeters

Thank you for purchasing our Digital Multimeter. Before using this Digital Multimeter, thoroughly read this manual to understand how to use it properly.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

PIM 113-01Z2: Inquiries List of worldwide contacts

Store this manual in an easily accessible place for quick reference.

Printed in Taiwan

**YOKOGAWA** IM 73201E  
Yokogawa Test & Measurement Corporation 10th Edition Oct. 2017 (YMI)

#### Safety Precautions

This product is designed to be used by a person with specialized knowledge.

When operating the instrument, be sure to observe the cautionary notes given below to ensure correct and safe use of the instrument. If you use the instrument in any way other than as instructed in this manual, the instrument's protective measures may be impaired.

This manual is an essential part of the product; keep it a safe place for future reference.

YOKOGAWA is by no means liable for any damage resulting from use of the instrument in contradiction to these cautionary notes.

The following safety symbols are used on the instrument and in this manual.

- Handle with Care. Refer to the user's manual. This symbol appears on dangerous locations on the instrument which require special instruction for proper handling or use.

#### WARNING

Indicates a hazard that may result in the loss of life or serious injury of the user unless the described instruction is abided by.

#### CAUTION

Indicates a hazard that may result in an injury to the user and/or physical damage to the product or other equipment unless the described instruction is abided by.

- This symbol indicates double insulation.
- This symbol indicates AC voltage/current.
- This symbol indicates DC voltage/current.
- This symbol indicates a fuse.
- This symbol indicates ground (earth).

#### WARNING

Failure to comply with the precautions below could lead to injury or death or damage to the instrument.

- The instrument is for measuring voltage, current, or resistance etc. Do not use this instrument for other purpose.
- Do not use the instrument if there is a problem with its physical appearance.
- Do not open the case except when replacing batteries or fuse. Only qualified YOKOGAWA personnel may remove the case and disassemble or alter the instrument. Do not attempt to repair/modify the instrument yourself, as doing so is extremely dangerous.
- Do not use the instrument in an atmosphere where any flammable or explosive gas is present.
- Use the testing leads supplied by YOKOGAWA with this instrument.
- Check the testing leads before use and do not use deteriorated or damaged ones. Check the continuity of the testing leads.
- Do not use the instrument if there is any damage to the casing or when the casing is removed.
- Disconnect the instrument from the circuit under test before opening the casing to replace the batteries or for any other reason.
- Avoid using the instrument if it has been exposed to rain or moisture or if your hands are wet.

#### WARNING

To avoid a short-circuit or an accident to personnel, use this instrument within maximum input voltage and current.

Category of Main Unit (Model 732) EN 61010-1: 2001

Measurement Category	Maximum Input Voltage
CAT II	600 V
CAT III	300 V

Measurement category	Description	Remarks
CAT I	For measurements performed on circuits not directly connected to MAINS. CAT I : EN 61010-1: 2001	Circuits not connected to a mains power source
CAT II	For measurements performed on circuits directly connected to the low-voltage installation.	Appliances, portable equipment, etc.
CAT III	For measurements performed in the building installation.	Distribution board, circuit breaker, etc.
CAT IV	For measurements performed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.

#### Category of Testing leads

When you use the test leads, attach or remove the caps according to the measurement category.

With caps: 1000V 10A CAT III / 600V 10A CAT IV  
Without caps: 1000V 10A CAT II

#### CAUTION

- The instrument is for domestic use (Class B) and meets the electromagnetic compatibility requirements.
- Do not use the multimeter near noise-emitting equipment or where there may be a sudden temperature change. Otherwise, the instrument may produce an unstable reading or errors.
- Do not wipe the instrument using any solvent (chemicals) such as benzene or paint thinner. Otherwise, the front panel may be damaged or discolored. When cleaning the instrument, use a dry cloth.
- Do not leave the multimeter exposed to direct sunlight or in a hot and humid location such as the inside of a car, for any prolonged length of time.

#### Components

##### 1) Function Switch

Turns off the power or selects the measurement mode.

- OFF Turns off the power
- $\sim V$  AC voltage measurement
- $\text{---} V$  DC voltage measurement
- $\Omega / \bullet$  Resistance measurement and continuity check (73202/03)
- $\Omega$  Resistance measurement (73201/04)
- $\bullet$  Continuity check (73201/04)
- $\text{---} \leftarrow$  Diode test
- $\text{---} \leftarrow$  Capacitor check (73202/03)
- $\mu A$  DC/AC current measurement in micro-amperes
- $mA$  DC/AC current measurement milli-amperes
- $A$  DC/AC current measurement in amperes

##### 2) SELECT key (73202/03) or $\text{---} / \sim$ key (73201)\*

This function is not supported on the 73204 multimeter.

This key is enabled only if the multimeter is in one of the following measurement modes.

- $\Omega / \bullet$  In this mode, the key selects between the resistance measurement and continuity test.
- $\text{---} \leftarrow$  In this mode, the key adjusts the stray capacitance of the testing leads and the multimeter itself to zero. (The display shows the  $\text{---} \leftarrow \text{CAL}$  symbol.)

$\mu A / mA / A$  In this mode, the key selects between the DC and AC modes.

\* The 73201 multimeter comes with the  $\text{---} / \sim$  key instead of the SELECT key.

This key is used only to select between the DC and AC modes in the current measurement mode.

##### 3) RANGE key \*


This function is not supported on the 73204 multimeter.

Allows the operator to select the measuring range manually. (The display shows the  $R \cdot H$  symbol.)

To return to the normal auto-ranging mode, hold down this key for at least one second until the display shows **AUTO**.

##### 4) AUTO. H key

Set up AUTO HOLD function. (The display shows the  $A \cdot H$  symbol.)



##### 5) Display View with All Elements Turned On

Symbol and Unit	Description
$\text{---}$	Lit when in DC-mode measurement
$\sim$	Lit when in AC-mode measurement
$\text{---}$	Polarity indicator lit when the polarity is negative
$\text{---} \leftarrow$	Lit when in diode test
$\bullet$	Lit when in continuity check
$A \cdot H$	AUTO HOLD indicator
$R \cdot H$	Manual range indicator
AUTO	Auto range indicator
AUTO POWER OFF	AUTO PWER OFF indicator
nF, $\mu F$	Unit for capacitance measurement
mV, V	Unit for voltage measurement
$\mu A$ , mA, A	Unit for current measurement
$\Omega$ , k $\Omega$ , M $\Omega$	Unit for resistance measurement
$\text{---} \leftarrow \text{CAL}$	Lit when stray capacitance is adjusted to zero
$\text{---}$	Lit when the batteries are low


#### Measuring Instructions

#### CAUTION

To avoid damage to Instrument or equipment.


- To verify the instrument's functionality, check that the measured value is update after turning on the power. If the measured value is not update, the reading will be incorrect and may lead to possible electrical shock or personal injury.
- Before starting measurement, check to which mode the function switch is set and make sure the testing leads are plugged into the terminals for the desired mode of measurement.
- Temporarily remove the testing leads from the device under test before operating the function switch.

#### AC Voltage Measurement $\sim V$



- Set the function switch from the OFF position to the  $\sim V$  position.
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the  $V \cdot \Omega \cdot \text{---} \leftarrow$  input terminal.
- Connect the testing leads to the circuit under test and then read the multimeter when it stabilizes.
- When measurement is complete, set the function switch back to the OFF position and turn off the multimeter.

#### DC Voltage Measurement $\text{---} V$



- Set the function switch from the OFF position to the  $\text{---} V$  position.
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the  $V \cdot \Omega \cdot \text{---} \leftarrow$  input terminal.
- Connect the testing leads to the circuit under test and then read the multimeter when it stabilizes.
- When measurement is complete, set the function switch back to the OFF position and turn off the multimeter.

#### NOTE

Do not mistake the following for a malfunction!


If the 400 mV range is selected and the testing leads are left open-circuited, the multimeter may give a certain reading. This does not affect your measurement.

#### Resistance Measurement $\Omega$

#### CAUTION

To avoid damage to instrument!

Turn off the power to the circuit under test before starting measurement in order to prevent any excessive voltage from being applied to the multimeter.




- Place the function switch in the  $\Omega$  position (73201/04) or  $\Omega / \bullet$  position (73202/03).
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the  $V \cdot \Omega \cdot \text{---} \leftarrow$  input terminal.
- Connect the testing leads to the circuit under test and then read the multimeter when it stabilizes.
- When measurement is complete, place the function switch in the OFF position and turn off the multimeter.

#### Continuity Check $\bullet$

#### CAUTION


To avoid damage to instrument!

Turn off the power to the circuit under test before starting measurement in order to prevent any excessive voltage from being applied to the multimeter.



- If the model is 73201 or 04, place the function switch in the  $\bullet$  position. If the model is 73202 or 03, place the function switch in the  $\Omega / \bullet$  position, and then press the SELECT key. (The  $\bullet$  symbol appears on the display.)
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the  $V \cdot \Omega \cdot \text{---} \leftarrow$  input terminal.
- Connect the testing leads to the circuit under check. If the circuit is continuous (no more than approximately 50  $\Omega$ ), the buzzer sounds.
- When the test is complete, place the function switch in the OFF position and turn off the multimeter.


## Diode Test $\rightarrow \leftarrow$



- Set the function switch from the OFF position to the  $\rightarrow \leftarrow$  position.
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the **V·Ω·→←** input terminal.
- Connect the testing leads to the diode and then read the multimeter when it stabilizes.


### (1) Forward-bias Diode Test

Connect the black testing lead to the cathode and the red testing lead to the anode (see Figure 1). Silicon diodes should give a reading of approximately 0.5 V and light-emitting diodes a reading between 1.5 V and 2.0 V. Note that readings close to 0 V represent a short-circuit and the "----" symbol indicates an open-circuit.



### (2) Reverse-bias Diode Test

Connect the black testing lead to the anode and the red testing lead to the cathode (see Figure 2). Normally, the display shows the "----" symbol, indicating that the diode under test is normal. The diode is defective if the display gives a certain voltage level.



- When the test is complete, set the function switch back to the OFF position and turn off the multimeter.


## Capacitor Check $\rightarrow \leftarrow$

\*This function is not supported on the 73201/04 multimeters.

### CAUTION

#### To avoid damage to instrument or equipment.

Before starting measurement, be sure to discharge the capacitor under check.



- Set the function switch from the OFF position to the  $\rightarrow \leftarrow$  position.
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the **μA·mA·→←** input terminal.
- Press the SELECT key to adjust the stray capacitance to zero. (The display shows the CAL  $\rightarrow \leftarrow$  CAL symbol)
- Connect the testing leads to the circuit under check and then read the multimeter when it stabilizes.
- When measurement is complete, set the function switch back to the OFF position and turn off the multimeter.

## NOTE

### Do not mistake the following for a malfunction!

Zero calibration is only effective when the 20 nF range is selected.

## Current Measurement (μA/mA/A)


\*This function is not supported on the 73204 multimeter.

### CAUTION

#### To avoid damage to instrument!

- Check to which mode the function dial is set before starting measurement.
- A current of 11 to 20 A can also be measured if the time interval is kept within 30 seconds. The buzzer will sound if the interval exceeds 30 seconds. If this happens, immediately stop measurement. To continue measurement, wait for 2 minutes or more when restart.

- Set the function switch from the OFF position to either the μA, mA or A position. (If the magnitude of the current being measured is not known, select the A position.)
- When measuring AC current, press the SELECT key to select the AC mode. (The display shows the  $\sim$  symbol to indicate AC-mode measurement.)
- Plug the black testing lead into the **COM** input terminal and the red testing lead into the A input terminal. If the current is in the order of milli-amperes or less, plug the red testing lead into the **μA·mA·→←** input terminal.
- Connect the testing leads to the circuit under test and then read the multimeter when it stabilizes.
- When measurement is complete, set the function switch back to the OFF position and turn off the multimeter.



## AUTO HOLD Function

The 732 series of multimeters can automatically retain the measured value when the testing leads are handled as described below.

- Press the AUTO.H key. (The display shows the **A·H** symbol.)
- Connect the testing leads to the object under test.
- When the reading stabilizes, the buzzer sounds.
- Remove the testing leads from the object under test.
- The multimeter now shows the measured value that it retains.
- You can repeat steps b) to e) as many times as you like as long as the display shows the **A·H** symbol.
- To cancel this function, press the AUTO.H key once again. (The **A·H** symbol disappears.)

## NOTE

### Do not mistake the following for a malfunction!

- In DC voltage measurement, the AUTO HOLD function is only available for ranges greater than the 4 V range.
- This function is not available for current-mode measurement.
- In a capacitor check, the AUTO HOLD function requires a few seconds before it takes effect.
- The AUTO HOLD function cannot be applied to unstable signals.

## AUTO POWER OFF Function

The multimeter automatically turns off if no key is pressed for a period of 20 minutes. The multimeter will beep for approximately one minute to alert the operator before the automatic power-off function takes effect. (Pressing any key while the multimeter is beeping postpones the power-off time. Pressing any key once after the power to the multimeter is automatically turned off switches the multimeter on again.) To cancel the automatic power-off function, hold down the SELECT key and then set the function switch from the OFF to the position of any desired measurement mode. (The AUTO POWER OFF indication turns off when the function is canceled.)

To enable the function once again, temporarily switch the function switch back to the OFF position, and then select the desired measurement mode.

## Battery Replacement

If the batteries fall below the normal operating voltage, the  $\rightarrow \leftarrow$  symbol turns on. If this happens, replace the batteries with new ones (AAA-size [ANSI] batteries: 2 pcs.).


### CAUTION

#### To avoid electrical shock!

- Be sure to disconnect the multimeter from the circuit under test before replacing the batteries.
- Replace both batteries at the same time making sure to position them with the correct polarities.

#### To replace the batteries:

- Remove the three screws on the back of the casing.
- Open the casing.
- Take the battery holder out of the casing.
- Replace the batteries with new ones and install the battery holder back into the casing.
- Close the casing and fasten it with the three screws.



## Fuse Replacement

If a current greater than the rated value flows when the multimeter is in the current-measurement range, a protection fuse may blow. If this happens, replace that fuse. The multimeter contains the following two types of fuses:

- Type F05: 500 mA/250 V fuse
- Type F02: 15 A/250 V fuse

### CAUTION

#### To avoid electrical shock!

- Be sure to disconnect the multimeter from the circuit under test before replacing the fuse(s).
- Do not operate the multimeter with the casing left open.
- In order to avoid damage to the multimeter or any possible accident, use fuses of the specified rating.

#### To replace the fuse(s):

- Remove the three screws on the back of the casing.
- Open the casing.
- Remove the blown fuse from the fuse holder.
- Install a new fuse in the holder.
- Close the casing and fasten it with the three screws.

F02: 15 A/250 V protection fuse  
F05: 500 mA/250 V protection fuse



View with the Casing Open

## Specifications

### 1. General Specifications

#### Measurement functions:

AC voltage, DC voltage, AC current (73201/02/03), DC current (73201/02/03), resistance, continuity, diode and capacitance (73202/03)

#### Additional functions:

Auto hold, manual range selection, over-range alarm, and Auto power off.

#### Display:

LCD display that is capable of indicating a significant reading of up to 4300\* counts along with the indications of the unit and function.

It shows the negative polarity only; no indication is given for positive polarity. The display also has the OL or over-range and  $\rightarrow \leftarrow$  low-battery alarm indicators.

\* : The most significant reading is 210 counts for the diode test and 2300 counts for the capacitor check.

#### Range selection:

Manual or automatic

#### Sampling:

2 times/sec

#### Operating temperature and humidity ranges:

0 to 50°C (Accuracy guaranteed range: 23±5°C)

Where the range is 0 to 40°C for humidity of 80%RH or less

and 40 to 50°C for humidity of 70%RH or less

#### Storage temperature and humidity ranges:

-20°C to 60°C, 70% RH or less

#### Battery life:

Approximately 600 hours (when continuously operated on alkaline batteries)

#### Power supply:

AAA-size batteries (ANSI) . . . . . 2 pcs.

#### External dimensions:

Approx.74 (W) × 155 (H) × 31 (D) mm (excluding protrusions)

#### Weight:

Approx. 240 g (including batteries)

#### Safety standards:

EN 61010-1: 2001, EN 61010-031: 2002+A1: 2008

AC/DC 300V CAT III, AC/DC 600 V CAT II

Indoor use, 2000m max above sea level, Pollution degree2

#### EMC standards:

EN 61326-1 Class B, EN 61326-2-2

EMC Regulatory Arrangement in Australia and New Zealand

EN 55011 Class B Group 1

Korea Electromagnetic Conformity Standard ( 한국 전자파적합성기준 )

#### Effect of EMS immunity:

Accuracy range of reading: (Rated accuracy of each range) ×5 for the strength of a radio-frequency electromagnetic field of 3 V/m

#### Accessories:

Batteries . . . . . 2 pcs. (housed in the instrument)

Testing leads . . . . . 1set

Spare fuse:  
F05 (500 mA/250 V) . . . . . 1  
F02 (15 A/250 V) . . . . . 1  
User's manual . . . . . 1

### 2. Accuracy (Electrical Specification)

Conditions: 23 ±5°C at 80% RH or less

Accuracy: ±(% of reading + digits)

Note: Each response noted below is a value measured in the Range Hold mode (manual range setting).

#### DC Voltage Measurement $\rightarrow \leftarrow$ V

Range	Resolution	Accuracy			Input Resistance	Maximum Input Voltage
		73201	73202/04	73203		
400 mV	0.1 mV				>100 MΩ	600 V
4 V	0.001 V	0.5%+1			11 MΩ	
40 V	0.01 V		0.5%+1	0.3%+1		
400 V	0.1 V		0.75%+1		10 MΩ	
600 V	1 V					

Response: 1.5 sec maximum for 400 mV range or 1 sec maximum for other ranges

#### AC Voltage Measurement $\sim$ V (Mean-value detection and rms-value calibration)

Range	Resolution	Accuracy (40-500 Hz)			Input Resistance	Maximum Input Voltage
		73201	73202	73203/04		
4 V	0.001 V				11 MΩ, <50 pF	600 V
40 V	0.01 V					
400 V	0.1 V	1%+5		0.75%+5	10 MΩ, <50 pF	
600 V	1 V					

Response: 2 sec maximum

#### DC Current Measurement $\rightarrow \leftarrow$ A

\* This function is not supported on the 73204 multimeter.

Range	Resolution	Accuracy			Voltage Drop	Maximum Input Current
		73201	73202	73203		
μA	400 μA *1	0.1 μA			<0.17 mV/μA	400 mA The input is protected by a 500 mA/250 V fuse
	4000 μA	1 μA				
mA	40 mA *2	0.01 mA		1%+2	<3 mV/mA	
	400 mA	0.1 mA				
A	10 A *3	0.01 A		2%+2	<0.04 V/A	10 A The input is protected by a 15 A/250 V fuse

\*1, \*2 These ranges may produce a readout error equivalent to several times their resolution.

\*3 A current of 11 to 20 A can also be measured if the time interval is kept within 30 seconds.

The buzzer will sound if the interval exceeds 30 seconds.

Response: 1 sec maximum

## AC Current Measurement $\sim$ A

\* This function is not supported on the 73204 multimeter.

(Mean-value detection and rms-value calibration)

	Range	Resolution	Accuracy (40-500 Hz)			Voltage Drop	Maximum Input Current
			73201	73202	73203		
μA	400 μA *1	0.1 μA				<0.17 mV/μA	400 mA The input is protected by a 500 mA/250 V fuse
	4000 μA	1 μA	2%+20				
mA	40 mA *2	0.01 mA				<3 mV/mA	
	400 mA	0.1 mA	2%+20		2%+5		
A	10 A *3	0.01 A		2.5%+20		<0.04 V/A	10 A The input is protected by a 15 A/250 V fuse

\*1, \*2 These ranges may produce a readout error equivalent to several times their resolution.

\*3 A current of 11 to 20 A can also be measured if the time interval is kept within 30 seconds.

The buzzer will sound if the interval exceeds 30 seconds.

Response: 2 sec maximum

## Resistance Measurement Ω

Range	Resolution	Accuracy			Measuring Current	Open-loop Voltage	Input Protective Voltage
		73201/02/03/04					
400 Ω	0.1 Ω				<1.0 mA	<3.4 V	600 V
4 kΩ	0.001 kΩ			0.75%+2	<0.5 mA	<1.0 V	
40 kΩ	0.01 kΩ				<70 μA		
400 kΩ	0.1 kΩ				<7 μA	<0.7 V	
4 MΩ	0.001 MΩ			2%+1	<0.7 μA		
40 MΩ	0.01 MΩ			5%+2	<70 nA		

Response: 1 sec maximum for ranges lower than the 400 kΩ range,

5 sec maximum for the 4 MΩ range, and

15 sec maximum for the 40 MΩ range

## Continuity check $\rightarrow \leftarrow$ )

Range	Resolution	Range of operation			Open-circuit Voltage	Input Protective Voltage
		73201/02/03/04				
400 Ω	0.1 Ω	The buzzer turns on for resistances lower than 50 ±20 Ω.			<3.4 V	600 V

Response: 0.2 sec maximum (for a buzzer response)

## Diode Test $\rightarrow \leftarrow$

Range	Resolution	Accuracy			Open-circuit Voltage	Input Protective Voltage
		73201/02/03/04				
2 V	0.01 V	1%+1 (for measuring currents smaller than 1.0 mA)			<3.4 V	600 V

Response: 1 sec maximum

## Capacitor check $\rightarrow \leftarrow$

Range	Resolution	Accuracy			Protection Fuse
		73201/04	73202	73203	
20 nF	0.01 nF				By means of a 500 mA/250 V fuse
200 nF	0.1 nF				
2 μF	0.001 μF	This function is not available.	2%+5 (typical)	Readings in the 20 nF range are values after zero calibration has been completed.	
20 μF	0.01 μF				
200 μF	0.1 μF				

Response: 1 sec maximum

## For the Pollution Control of Electronic and Electrical Products of the People's Republic of China

This manual is valid only in China.

产品中有毒物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
框架 (塑料)	×	×	×	×	○	○
线路板 ASSY	×	×	×	×	○	○
导线	×	×	×	×	○	○
电池	×	×	×	×	○	○

○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。

×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。

环保使用期限:

该标识适用于SJ/T 11364中所述, 在中华人民共和国销售的电子电气产品的环保使用期限。只要您遵守该产品相关的安全及使用注意事项, 在自制造日起算的年限内, 则不会因产品中有有害物质泄漏或突变, 而造成对环境的污染或对人体及财产产生恶劣影响。

注) 该年数为“环保使用期限”, 并非产品的质量保质期。零件更换的推荐周期, 请参照使用说明书。