

Instruction Manual

WX1□-FP (Voltage Input·Soft Variable Type)
 WX2□-FP (Voltage Input·Soft Variable Type)
 WX3□-FP (mV Input·Soft Variable Type)
Programmable Unit

JUXTA

1. INSPECTION

This instrument has been thoroughly tested at the factory before shipment. When you receive it, visually inspect it for damage and check the accessories.

1.1 Model number and specification check

Check to see the model number and specifications on the nameplate attached to the front cover of the unit are as ordered.

1.2 Contents of the instruction manual

This instruction manual provides instructions on mounting, external wiring and maintenance.

2. GENERAL

(WX1□, WX3□)

This soft variable type unit receives 2 voltage or mV signals from transmitter and outputs isolated current or voltage signal by making calculations on 2 inputs. (After delivery, programs are freely made out and decide function).

(WX2□)

This soft variable type unit receives 1 voltage signal and 1 contact input signal from transmitter and outputs isolated current or voltage signal by making calculations on 2 inputs. (After delivery, programs are freely made out and decide function).

Accessories : Mounting block 2
 Tag number and range label 1 each
 Mounting screw M4: 4

3. MOUNTING METHOD

JUXTA signal conditioners can be mounted on rack, wall or DIN rail.

3.1 Rack mounting

Use panel (FRK-16) and install it on an angle as shown in Fig.1. This is a convenient method for high density mounting of the unit on 19-inch rack panel. (See Fig. 6)

3.2 Wall mounting

Use panel (FRK-16) to mount the unit as shown in Fig. 2 or directly mount it on the wall (See Figs. 6 and 7 for mounting dimensions)

3.3 DIN rail mounting

Insert DIN rail into the upper of DIN rail groove on the rear of the unit and fix the rail with the slidlock at the lower of the unit as shown in Fig. 3.

3.4 Angle mounting

In case of single unit mounting, refer to Fig. 5 for its mounting.

3.5 Mounting block installation and removal

Insert mounting block into the groove of the unit as shown in Fig. 4 and slide it until it is locked with the stopper. To remove it, lift up the mounting block stopper with screwdriver (-) and slide it along the groove.

4. EXTERNAL WIRING

Open the terminal cover of the unit.

Wire should connect to M4 screw terminal. Flexible twisted wires and durable round crimp-on terminals (JIS C2805) are recommended to be used.

- Signal cable having more than 0.5mm² and power cable having more than 1.25mm² of nominal cross-sectional area of conductor are recommended.

Fig.1 Rack Mounting




Fig.2 Wall Mounting




Fig.3 DIN Rail Mounting

Use (-) screwdriver and lower the slidlock to remove the unit from DIN rail




Fig.4 Mounting Block installation and removal




Fig.5 Angle Mounting Dimension




Fig.6 Rack Mounting Dimension





Fig.7 Panel Mounting Dimension



4.1 Wiring

- ① See Fig. 8 for terminal arrangement.
- ② Connect Ch1 input signal cable to terminals 7(+), 8(-) and Ch2 input cable to 3(+), 4(-) of the unit.
- ③ Connect output signal cable of the unit to its terminals 11(+) and 12(-).
- ④ In case of use AC power, connect AC power cable to terminals 14(L), 15(N), 16(G).
In case of use DC power, connect DC power cable to terminals 14(+), 15(-).
(See Fig. 9 & 10)

5. ITEMS TO BE CHECKED BEFORE TURNING THE POWER SWITCH ON

- ① Make sure that 24V DC power cable of the unit is connected to the correct polarities (+), (-).
 - ② Confirm that the external wiring to the terminal board is correct.
 - ③ Check that the mounting, ambient temperature, humidity, dust and vibration are normal.
- Confirm the above items before turning the power on. The unit needs 5 minutes warmup to meet its specified accuracy level.

6. PROGRAMMING THROUGH HANDY TERMINAL

This unit performs programming through Handy Terminal and decides function.

When shipment, the unit is set as normal transmitter since it includes input (ch1)=output programming. Also, input (Ch2) of WX2□ is contact signal. As for details of Handy Terminal (JHT200 or JHT-100, refer Instruction Manuals (IM JF81-02E for JHT200 and IM JF81-01E for JHT-100).

6.1 Programming, fixed constant and zero/span areas
Programming area is B20~B49, fixed constant area is C11~C41 and zero/span area is B10, B11.

(Refer Parameter List)

Programs can enter maximum 30 steps in B20~B49 and they should be written closely forward.

Instruction of NOP should be written following next step of already written program and it should be filled upto B49. Program is carried out orderly B20→B21→B22→→→B49.

Input range is set by ZERO, SPAN (B10, B11).

Set voltage corresponding 0% input on B10 and span voltage on B11.

Fig.8 Terminal Arrangement

| TML | |
|-----|---------------|
| 3 | INPUT (ch2) + |
| 4 | INPUT (ch2) - |
| 5 | |
| 6 | |
| 7 | INPUT (ch1) + |
| 8 | INPUT (ch1) - |
| 9 | |
| 10 | |
| 11 | OUTPUT + |
| 12 | OUTPUT - |
| 13 | |
| 14 | SUPPLY L+ |
| 15 | SUPPLY N- |
| 16 | GND |




Fig.9 Wiring Diagram (WX1□, WX3□)




Fig.10 Wiring Diagram (WX2□)





Fig.11 Connection to Handy Terminal



PARAMETER LIST

| NO. | ITEM | TITLE DISPLAY | DATA DISPLAY |
|-----|-----------------------------|---------------|--|
| 01 | Model | MODEL | □□□□*□ |
| 02 | Tag No. | TAG NO | 16 Alphanumerics |
| 03 | Self Check | SELF CHK | Good or Error |
| A00 | Display Item | DISPLAY | |
| A01 | Input 1 | INPUT 1 | □□□□.□V/mV |
| A02 | Output | OUTPUT | □□□.□% |
| A03 | Status | STATUS | FF (Hexagonal 2 digits) |
| A04 | Rev No. | REV NO | n.nnn (n : Rev No.) |
| A05 | Load | LOAD | □□□.□% |
| A06 | Input 2 | INPUT 2 | □□□□.□V/mV |
| A07 | Buffer 1 | BUFFER 1 | □□□.□% |
| A08 | Buffer 2 | BUFFER 2 | □□□.□% |
| A09 | Buffer 3 | BUFFER 3 | □□□.□% |
| B00 | Set Item | SET | |
| B01 | Tag No.1 | TAG NO.1 | 8 Alphanumerics (1st half 8 characters of Tag No.) |
| B02 | Tag No.2 | TAG NO.2 | 8 Alphanumerics (2nd half 8 characters of Tag No.) |
| B03 | Comment 1 | COMMENT 1 | 8 Alphanumerics |
| B04 | Comment 2 | COMMENT 2 | 8 Alphanumerics |
| B07 | Input Type *1 | INP TYPE | Select from LL/L/H/HH |
| B10 | Zero Point | ZERO | Numeric Data |
| B11 | Span | SPAN | Numeric Data |
| B12 | Burnout *1 | BURN | Select from OFF/ON |
| B13 | Setup Error | SET ERR | GOOD/ERROR |
| B20 | Program | PROGRAM | [Inter-company Setup Item] |
| B21 | Program | PROGRAM | [Inter-company Setup Item] |
| ≡ | ≡ | ≡ | ≡ |
| B48 | Program | PROGRAM | [Inter-company Setup Item] |
| B49 | Program | PROGRAM | [Inter-company Setup Item] |
| C00 | Adjust Item | ADJUST | |
| C01 | 0% Output Adjust | OUT 0% | Numeric Data (±10.00) |
| C02 | 100% Output Adjust | OUT 100% | Numeric Data (±10.00) |
| C03 | Wiring Resistance Adjust *1 | WIRING R | RESET/EXECUTE |
| C04 | 0% input Adjust *2 | IN 0% | |
| C05 | 100% input Adjust *2 | IN 100% | |
| C11 | Fixed Constant | CONST | Numeric Data |
| C12 | Fixed Constant | CONST | Numeric Data |
| ≡ | ≡ | ≡ | ≡ |
| C40 | Fixed Constant | CONST | Numeric Data |
| C41 | Fixed Constant | CONST | Numeric Data |

*1 Display only WX3□-FP
 *2 Display only. Don't use

Subject to change without notice for grade up quality and performance.

YOKOGAWA 
Yokogawa Electric Corporation

Network Solutions Business Division
2-9-32, Nakacho Musashino-shi, Tokyo, 180-8750 Japan
Phone: (81)-422-52-7179 Fax: (81)-422-52-6793