

OD Precision

Displacement Sensor



This document is protected by the law of copyright, whereby all rights established therein remain with the company SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Alteration or abridgement of the document is not permitted without the explicit written approval of the company SICK AG.

Contents

1	Safety precautions.....	5
1.1	Meanings of safety symbols	5
1.2	Mandatory requirements	5
1.3	Precautions for installation	6
1.4	Cautions for laser product.....	6
2	Specifications	7
3	Basic information before use.....	12
3.1	Parts identifications of controller	12
3.1.1	Button names and operations.....	13
3.1.2	LCD guide	14
4	Basic operation	15
4.1	To switch RUN mode/SET mode	15
4.2	To change setting.....	15
5	First steps.....	16
5.1	Technology and functions.....	16
5.2	Frequently Asked Questions on start-up.....	18
5.2.1	Minimum/maximum thickness of a transparent material?.....	18
5.2.2	Thickness limit of a the glass in front of the gap?	18
5.2.3	Measuring through a glass	18
5.2.4	Referencing for glass thickness measurement.....	19
5.2.5	Sensor does not show a measurement, what to do?	21
5.2.6	What is the best alignment for measuring on glass?	22
5.3	Setup Execute function for application.....	23
5.3.1	Activate Setup Execute function	23
5.3.2	“Basic Setting” Setup Execute	23
5.3.3	“Calibration” Setup Execute	25
5.4	Setup execute function for calibration.....	27
6	Settings	29
6.1	Settings of sensor head	29
6.1.1	Set measurement function, choose measurement target	29
6.1.2	Set calibration (shift).....	30
6.1.3	Set calibration (span).....	31
6.1.4	Set laser power	32
6.1.5	Set sensitivity	32
6.1.6	Set threshold	33
6.1.7	Set moving average	34
6.1.8	Set the communication speed	35
6.1.9	Set the measurement value at alarm	36
6.1.10	Set sampling period	37
6.1.11	Monitor light distribution curve on CMOS receiver element.....	38
6.1.12	Prevent mutual interference	39
6.1.13	Set sensor head type	40
6.2	Setting control/switching output.....	41
6.2.1	Set upper limit/lower limit	41
6.2.2	Set hysteresis	41
6.2.3	Set delay	42
6.2.4	Set delay time.....	43
6.2.5	Set control/switching output source.....	43

6.3	Setting analog output.....	44
6.3.1	Set upper/lower limit.....	44
6.3.2	Set output source	45
6.4	Setting calculation.....	46
6.4.1	Set calculation	46
6.4.2	Change algebraic sign of measurement value	47
6.4.3	Set value of K.....	47
6.4.4	Set shift/offset.....	48
6.5	Using calculation	49
6.5.1	Calculation examples	49
6.5.2	Thickness calculation	49
6.6	Setting hold.....	51
6.7	Setting filter	54
6.7.1	Set filter function	54
6.7.2	Set frequencies of filter functions	55
6.8	Setting bank.....	56
6.9	Setting RS 232	56
6.10	Using memory function	57
6.10.1	Copy data	57
6.10.2	Return bank setting to Default (initialization).....	57
6.10.3	Complete reset	57
6.11	Setting display and keys.....	58
6.11.1	Set internal decimal places visible in RUN mode	58
6.11.2	Set brightness.....	58
6.11.3	Set key lighting.....	58
7	Mounting.....	59
7.1	Installing controller	59
7.1.1	Install to DIN rail	59
7.1.2	Install to panel	59
7.2	Connecting connectors for sensor head	61
7.3	Connecting cable to 12-pin terminal board	62
8	Appendix	63
8.1	Input/output diagram.....	63
8.2	Communication.....	64
8.2.1	Communication specification	64
8.2.2	Communication procedure.....	64
8.2.3	Connection with computer	65
8.2.4	Send data format (command).....	65
8.2.5	Received data format (response)	67
8.2.6	Communication command table	68
8.2.7	Specification of OD5 Light distribution data	75
8.3	ASCII code table.....	76
8.4	Dimensional drawing.....	77
8.4.1	Panel mounting dimensions	78
8.4.2	Panel opening dimensions.....	78
8.5	Accessories	79
8.5.1	Package descriptions	80
8.6	List of tables	81
8.7	List of figures	83

1 Safety precautions

Carefully read and understand the safety precautions before operation.

They provide important information to protect your health and property. Strictly follow this instruction manual, and do not apply any other installing/operating procedure which is not described in this manual.

1.1 Meanings of safety symbols



WARNING

Indicates a possible hazard that may result in death or serious injury if the product is used without observing the stated instructions.

Indicates a possible hazard that may result in personal injury or property damage if the product is used without observing the stated instructions.

1.2 Mandatory requirements



WARNING

This product cannot be used as a safety device to protect human body.

Do not disassemble or modify the product since it is not designed to automatically stop the laser emission when open. Disassembling or modifying may cause personal injury, fire or electric shock.

If smoke or abnormal smell occurs, stop operation and turn off power supply. If the problem requires a repair, contact the sales office or store where you purchased the product.

Use the supply voltage specified in the specifications.

Do not touch the controller unit and cable with wet hands. It may cause electric shock.

Use only the OD Precision sensor head.

Do not connect/disconnect the sensor head connector, terminal board or wiring when the power is on.

1.3 Precautions for installation



WARNING

Installing the unit in the following conditions may result in fire, electric shock or product damage.

- High humidity
- High temperature e.g. in direct sunlight, etc.
- Much dust
- Poor ventilation
- Static electricity
- Corrosive gas or flammable gas
- Exposure to water, oil, or chemicals
- Direct exposure to vibration or impact

Do not apply electricity during wiring. Ensure that the analog output does not contact with other wiring.



WARNING

Avoid parallel wiring and placing in the same piping with high-voltage cable or power transmission cable, since they may cause electric noise resulting in malfunction. Keep the power and signal cords in short length.

Do not pull or apply impact forcibly since it may cause product damage.

When using switching regulator for power supply, ensure grounding the frame ground terminal.

Do not drop or give a shock to the product. This may damage product and measurement accuracy.

Wait for approximately 5 minutes as warming-up time after turning the power on.

1.4 Cautions for laser product

The sensor-head light source of the displacement sensor OD series is rated as Class 2(II)/ Class 1 (I) for OD5-25x) Red Laser Diode, and compliant with JIS C6802/IEC/FDA laser safety standard. Do not stare directly into the laser beam or the reflected laser beam on a mirrored surface.

For details, refer to the Instruction Manual of sensor head (8013569).



WARNING

When incorporating the unit into your product/machine, provide an end-user with information that it is a laser product and should be properly operated.

2 Specifications

Tab. 1:
Specification

Model		AOD5-N1 NPN input/output type	AOD5-P1 PNP input/output type	
Response time		0.1 ms / 0.8 ms		
Output rate		10 kHz / 1.25 kHz		
Number of connected sensor heads		Max. 3 pcs		
Temperature drift		± 0.01 % F.S./°C (FS = Full Scale of measuring range)		
Communication		RS 232/USB		
Connection type		Terminal board		
Output	Analog output	Voltage output ± 10 V/F.S. (Output impedance 100 Ω, min load 10 kΩ)		
		Current output 4 ... 20 mA/F.S. (Load impedance Max. 300 Ω)		
	Alarm output	NPN open collector	PNP open collector	
		Max. 100 mA/24 V DC (residual voltage Max. 1.8 V)		
		Turns ON when the sensor head fails in measurement.		
	Control/Switching output	NPN open collector	PNP open collector	
		Max. 100 mA/24 V DC (residual voltage Max. 1.8 V)		
		HI/LO setting for each line and Hysteresis setting are available.		
	Input	Bank input	Turns ON when connected to GND	Turns ON when connected to 12 ... 24 V
16 banks selectable				
Hold input		Turns ON when connected to GND	Turns ON when connected to 12 ... 24 V	
		Measurement value holding (selectable in the menu)		
Reset input		Turns ON when connected to GND	Turns ON when connected to 12 ... 24 V	
		Zero reset of Head A measurement value/Head B measurement value/Head C measurement value/Calculation value is available.		
Laser off input		Turns ON when connected to GND	Turns ON when connected to 12 ... 24 V	
		Laser shutoff of Head A/Head B/Head C is available.		
Additional features		Calculation setting (calculation formula, measurement value increase/decrease direction, set variable value of K, shift), hold settings, filter setting (filter, cut-off frequency), memory bank setting, RS 232 setting, memory copying function, measurement value display, digit number setting, display brightness setting, key illumination setting		
Indication		4.4" LCD display		
Protection Class		III		
Enclosure rating		IP 20		
Ambient temperature	Operating temperature	-10 °C... +45 °C (Non-condensing)/For storage: -20 ... +60 °C		

Model		AOD5-N1 NPN input/output type	AOD5-P1 PNP input/output type
	Storage temperature	-20 °C ... +60 °C	
Supply voltage		12 V ... 24 V, DC ± 10 %	
Power consumption		350 mA/24 V (When connected with 3 sensor heads. Including analog current output)	
Operating humidity		35 % ... 85 % RH/For storage: 35 ... 85 % RH	
Vibration resistance		10 Hz ... 55 Hz, Double amplitude 1.5 mm, 2 h for XYZ axes	
Shock resistance		20 G (196 m/s ²)	
Housing material		Chassis: Polycarbonate, Terminal board: Nylon 66	
Weight		Approx. 550 g (including terminal board)	

Pin Assignment of 50-pin Input/Output Terminal

Tab. 2: Pinning of I/O Expansion Cable

No.	Description	Core color	Number of dots	Dot color
1	Bank switch 0 input	orange	1	black
2	Bank switch 1 input	grey		
3	Bank switch 2 input	white		
4	Bank switch 3 input	yellow		
5	Hold A input (for Head A)	pink	2	
6	Hold B input (for Head B)	orange		
7	Hold C input (for Head C)	grey		
8	Hold CAL input (for calculation result)	white		
9	Hold reset input (common)	yellow	3	
10	Zero reset A input (for Head A)	pink		
11	Zero reset B input (for Head B)	orange		
12	Zero reset C input (for Head C)	grey		
13	Zero reset CAL input (for calculation result)	white	4	
14	Laser OFF A input (for Head A)	yellow		
15	Laser OFF B input (for Head B)	pink		
16	Laser OFF C input (for Head C)	orange		
17	-	grey	5	
18	-	white		
19	-	yellow		
20	-	pink		
21	-	orange	5	
22	-	grey		
23	COM terminal (24 V output)	white		
24	-	yellow		
25	COM terminal (0 V output)	pink		


OD Precision

No.	Description	Core color	Number of dots	Dot color
26	Alarm output A (for Head A)	orange	1	red
27	Alarm output B (for Head B)	grey		
28	Alarm output C (for Head C)	white		
29	Control output 1	yellow		
30	Control output 2	pink		
31	Control output 3	orange	2	
32	Control output 4	grey		
33	Control output 5	white		
34	-	yellow		
35	-	pink		
36	-	orange	3	
37	-	grey		
38	-	white		
39	-	yellow		
40	-	pink		
41	-	orange	4	
42	-	grey		
43	-	white		
44	-	yellow		
45	-	pink		
46	-	orange	5	
47	-	grey		
48	-	white		
49	-	yellow		
50	-	pink		


Pin identification is by color code

The color of the dots, the number of the dots and the color of the core are used to identify each pin.

Example for Pin 6

Core color: orange	Number of dots: 2	Dot color: black
		

Example for Pin 39

Core color: yellow	Number of dots: 3	Dot color: red
		

Note

Use the half pitch connector of IEEE1284.
 Use the COM terminal only as the "COMMON" terminal of input/output of the product.
 Never use the terminal for any other application.

- Connection with the input terminal

- Load connection between the output terminal and COM terminal

The max current for each output terminal is 100 mA.

Hold input

Refer to chapter 6.6 "Setting hold".

Zero reset input

Zero reset is performed when the input is ON for 110 ms or more. Zero reset is canceled when the input is ON for 1 s or more.

Laser OFF input

The sensor head laser is shut off when the laser OFF input is turned ON.

Input time of the input terminals

All input terminals are enabled when they are OFF or ON for 110 ms or more. The zero reset is enabled when it is ON for 110 ms or more, and is cleared when it is ON for 1 s or more.

Alarm output

When the sensor head cannot make a measurement, the corresponding alarm output turns ON.

Control/Switching output

Refer to chapter 6.2 "Setting control/switching output".

Bank switch input

Refer to following table to switch between banks 1 to 15.

Tab. 3: Bank switch Input via Expansion cable

Bank No.	Bank switch input			
	3	2	1	0
0	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	ON
2	OFF	OFF	ON	OFF
3	OFF	OFF	ON	ON
4	OFF	ON	OFF	OFF
5	OFF	ON	OFF	ON
6	OFF	ON	ON	OFF
7	OFF	ON	ON	ON


Bank No.	Bank switch input			
	3	2	1	0
8	ON	OFF	OFF	OFF
9	ON	OFF	OFF	ON
10	ON	OFF	ON	OFF
11	ON	OFF	ON	ON
12	ON	ON	OFF	OFF
13	ON	ON	OFF	ON
14	ON	ON	ON	OFF
15	ON	ON	ON	ON

Refer also to chapter 6.8 "Setting bank".

OD Precision

Fig. 1: Pin assignment of 12-pin input/output terminals

Input/Output Terminal




Note All GND terminals are connected internally.
The voltage output is ± 10 V. The current output is 4 ... 20 mA.
Refer to chapter 6.3 "Setting analog output".

3 Basic information before use

3.1 Parts identifications of controller

Fig. 2: Parts identifications of controller




- ① Sensor head A connection port
- ② Sensor head B connection port
- ③ Sensor head C connection port
- ④ Terminal board 50-pin extern
- ⑤ LCD display (see chapter 3.1.2 “LCD guide“)
- ⑥ Operation panel (see chapter 3.1.1 “Button names and operations“)
- ⑦ For panel mounting bracket (recommended window size 173 x 102 mm)
- ⑧ RS 232C interface
- ⑨ USB interface
- ⑩ Fastening handle DIN Rail
- ⑪ Terminal board (detachable)

OD Precision

Fig. 3: Buttons on controller unit

3.1.1 Button names and operations




- ① SET/RUN button:
Press this button to switch from RUN mode (Operation mode) into SET mode (Function setting mode) and back
- ② BANK button:
Switches current bank (0 ... 15).
- ③ ZERO RESET button:
Activates zero reset for the measurement value and calculated value of corresponding sensor head. Pressing either of these buttons again for over 1 s clears the zero reset condition.
- ④ Sheet toggle button:
In SET mode this button will let the cursor jump to the headline of the sheet, now use LEFT/RIGHT to toggle through the various sheets. (see chapter 4.1 "To switch RUN mode/SET mode").
- ⑤ RIGHT/LEFT buttons:
In SET mode LEFT/RIGHT is used to adjust the setting for the currently highlighted parameter.
When the cursor is on the headline of the sheet LEFT/RIGHT is used to toggle through the various sheets.
- ⑥ UP/DOWN buttons:
In SET mode UP/DOWN is used to move cursor up or down. The option that the cursor is pointing on is highlighted.
Move cursor to headline of each sheet to change sheet using "LEFT/RIGHT" buttons.
- ⑦ 10 KEY mode/LOCK:
Pressing this button over 1 s in the RUN mode locks all the button operation (key lock function). Pressing the button again for over 1 s clears the lock condition.
Pressing the button in SET mode enables to input numerals using numeric key (10 KEY input function). This operation is available in selecting the setting options where the numeric key is available (see chapter 4.1 "To switch RUN mode/SET mode").
- ⑧ Status indication lamp:
Indicates power on/off condition and sensor head connection condition.

Note Buttons available in each mode are lit up.
Status indication lamp lights stay the same condition regardless of mode selection.


3.1.2 LCD guide

Fig. 4: Example in the RUN mode menu



- ① Displays the measured values of sensor heads A B and C. When the measurement is not available, the value “2999.99999” is displayed (Referred to as alarm condition). When no sensor head is connected, “-----” is displayed.
- ② Displays the calculated values.
- ③ Displays the current bank number.
- ④ When the key lock is applied, the indication “LOCK” is displayed.
- ⑤ Displays the object position in the measuring range of each sensor head. The red line indicates the center of the measuring range.
- ⑥ Displays the ON/OFF status of the / control outputs. (Remark: “control outputs” are often also referred to as “switching outputs”.)

Fig. 5: Example in the SET mode menu



- ① Displays the headline of the parameter sheet that can be set
 - Sheet 1 to 3: Sensor Head (see chapter 6.1 “Settings of sensor head”)
 - Sheet 4 and 5: Control Output (see chapter 6.2 “Setting control/switching output”)
 - Sheet 6: Analog Output (see chapter 6.3 “Setting analog output”)
 - Sheet 7: Calculation (see chapter 6.4 “Setting calculation”)
 - Sheet 8: Hold (see chapter 6.5 “Using calculation”)
 - Sheet 9: Filter (see chapter 6.6 “Setting hold”)
 - Sheet 10: Bank (see chapter 6.7 “Setting filter”)
 - Sheet 11: RS 232 (see chapter 6.8 “Setting bank”)
 - Sheet 12: Memory, Complete Reset (see chapter 6.9 “Setting RS 232”)
 - Sheet 13: Display/Key (see chapter 6.10 “Using memory function”)
- ② Displays bank Number.
- ③ Displays the setting title.
- ④ Displays the setting value.
- ⑤ Indicates that the setting corresponds to certain bank (no “B” means value is global and the same for each bank setting).
- ⑥ Indicates that the option can be set using 10 KEY (numeric key).



Note The display A/B/C next to the setting title corresponds to sensor head A/sensor head B/sensor head C respectively.

4 Basic operation

4.1 To switch RUN mode/SET mode











Switch from RUN mode to SET mode to change parameters of the sensors.

Tab. 4: Modes

1 Press 	Switches to SET mode from RUN mode. Switches to RUN mode from SET mode.
2 Press  again	Returns to the original mode.

4.2 To change setting

Tab. 5: Change settings

1 Press 	Go to the SET mode.
2 Press 	Move the cursor to the headline of the sheet.
3 Press 	Select the bank to change.
4 Press  or 	Toggle through the parameters of the active sheet.
5 Press  or 	When headline is highlighted use these keys to toggle through the various sheets. Use these keys to change the setting of the currently active parameter. When the setting option allows 10 key (numeric key) operation, it is recommended to press  to adjust the value using all 10 keys. Pressing  again stores the selected value
6 Press 	Save the setting, and return to the RUN mode. Important Note: When having used the 10KEY button to set a parameter it is important that this function is disabled first.


5 First steps

5.1 Technology and functions

Short-Range Distance (Displacement) Sensors by SICK make use triangulation for distance measurement. This technology allows to measure distance to object but also thickness of transparent material with only one sensor head. The laser is reflected on the front and also on the back side of the material. The sensor sees both reflections and can thus measure the distance to both surfaces. The difference, which is calculated simultaneously internally equals the thickness of the material. Additionally is the light path bent when entering and exiting the material.

One single reference measurement for each material is enough to compensate this effect and ensure a precise thickness measurements. This chapter explains in brief how to set the sensor up for distance measurement or thickness measurement.

Fig. 6: Measurement principle: Triangulation



First step: Press “Set/Run” and move to sheet 3. In sheet 3 start the “Setup Execute” function by pressing “RIGHT” Details on the setup execute functions can be found in 5.3 “Safety precautions Setup Execute function for application” on page 23.

In this setup the controller unit gives the following options:

- Measurement on surface:
Distance to first surface is measured.
- Measurement of thickness of transparent material (=glass thickness):
Distance between first and second surface is measured.
- Measurement of glass gap:
Distance between 2nd and 3rd surface is measured
- Measuring to the rear side executof a transparent material (=rear):
Distance to 2nd surface is measured. (so first surface is ignored)

Please be aware that not all options are available for all OD Precision sensor head types. Please refer to following table.


Tab. 6: Sensor types and availability of special functions

Sensor type	Glass thickness	Glass gap	Rear	Remark
OD5-25x01	yes	not supported	not supported	
OD5-30x05	yes	yes	yes	only half the measurement range is available
OD5-85x20	yes	yes	yes	
OD5-150x40	not supported	not supported	not supported	
OD5-350x100	not supported	not supported	not supported	
OD5-500x200	not supported	not supported	not supported	

Follow the instructions on the controller unit. When unable to get a measurement please see chapter 5.2.5 “Sensor does not show a measurement, what to do?” on page 21 to resolve problems. Best is to start with optimizing alignment.

When measuring thickness of a transparent material it is important to reference to ensure accuracy of the measurement. Please see 5.2.4 “Referencing for glass thickness measurement” on page 19.

Fig. 7: Exemplary light distribution on CMOS receiver element



- ① Front of glass 1
- ② Rear of glass 1
- ③ 3rd surface behind glass (can be glass or any other material)
- ④ Barycenter
- ⑤ CMOS or CCD receiver with x number of pixel

5.2 Frequently Asked Questions on start-up

5.2.1 Minimum/maximum thickness of a transparent material?

The minimum thickness is specified as shown in the table below.

The maximum thickness is limited by the physical measurement range of the sensor head, please refer to the table below.

Tab. 7: Min./Max. thickness of transparent materials for glass gap, rear and glass thickness measurement

Sensor type	min. glass thickness	max. glass thickness	min. glass gap	max. thickness of glass in front of gap.	remark
OD5-25T01 (thin light spot)	0.2 mm	2 mm	not supported	not supported	
OD5-25W01 (wide light spot)	0,3 mm	2 mm	not supported	not supported	
OD5-30T05 (thin light spot)	0.7 mm	5 mm	0.5 mm	4.5mm	only half the measurement range is available
OD5-30W05 (wide light spot)	0.9 mm	5 mm	0.6 mm	4.4mm	
OD5-85T20 (thin light spot)	2 mm	20 mm	1.4 mm	18.6 mm	only half the measurement range is available
OD5-85W20 (wide light spot)	2 mm	20 mm	1.4 mm	18.6 mm	
OD5-150T40	not supported	not supported	not supported	not supported	not supported
OD5-150W40	not supported	not supported	not supported	not supported	not supported
OD5-350W100	not supported	not supported	not supported	not supported	not supported
OD5-500W200	not supported	not supported	not supported	not supported	not supported

5.2.2 Thickness limit of a the glass in front of the gap?

First, second and third peak must be within physical measurement range of the sensor. Be aware that OD5-85x and OD5-30x only half the measurement range is available (see table above).

5.2.3 Measuring through a glass


This is possible, please ensure that the glass is placed closer to the sensor than the start of the measurement range. Also, it is best to tilt the glass by about 3° to ensure that reflections do not occur.

OD Precision

5.2.4 Referencing for glass thickness measurement

In addition to the remarks in 5.2.6 for measuring on transparent/reflective surfaces, the fact that the light path bends when entering a clear material should be considered. The degree of the bending is dependent on the refraction index of the material. In most cases this data is not easily available.

Fig. 8: Laser path through transparent material



① Laser

Easiest way to compensate is to reference the measurement of the sensor. The sensor then adjusts the “Span” factor accordingly and precise measurements for any object with the same light refraction index are achieved.

To reference, simply measure the thickness of the material manually once, compare the value to the thickness measurement of the sensor and adjust the span factor according to following formula. An example is shown on the following page.

$$Span(new) = t(ODmeasuredvalue) \div t(referencevalue) * Span(current)$$

t = thickness of material

Tab. 8: Referencing for measuring thickness of transparent material

Referencing the sensor is only necessary when measuring glass thickness /glass gap/ rear. Activate these measurement modes in the "Setup Execute" on sheet 3 on the controller unit. For details refer to 5.3 "Setup Execute function for application" on on page 23.

Referencing is best explained with an example:

In this case the result for glass thickness measurement shows: 1.517 mm = t(ODmeasuredvalue)

Thickness of the material is now measured manually. E.g. with a measuring gauge.

Result:

Reference glass plate thickness is 1.599 mm = t(referencevalue)

This means that the calibration Span factor of the sensor must be adapted for this material to accommodate to the light refraction index.

The Span factor can be changed on sheet 1 on the controller unit.

The default value for glass is 0.6666

The correct value for this material is calculated with the following formula:

$$\mathbf{Span(new) = t(ODMeasuredValue) / t(reference\ value * Span(current))}$$

$$\text{Result: Span(new) = } 1.517 \text{ mm} / 1.599 \text{ mm} * 0.6666 = 0.6420$$

When adjusting the Span to 0.6420 the ODMeasuredValue changes to 1,599 mm, the actual thickness.

5.2.5 Sensor does not show a measurement, what to do?

Best is to check what the sensor actually sees. Press “Set/Run” to enter menu. Adjust the setting “Operation” to light distribution of “A”, “B” or “C” on sheet 3 on the controller unit. Press “Set/Run” to see the light distribution. A more detailed explanation can be found in chapter 6.1.11 on page 38.

This graphic visualizes the light remission on the receiver element. In this example two peaks are visible. Both surpass the threshold level (indicated by the blue horizontal line).

- For more information on the blue line refer to chapter 6.1.11 “Monitor light distribution curve on CMOS receiver element” on page 38.
- For setting the threshold level refer to chapter 6.1.6 “Set threshold” on page 33.


The measurement value is indicated by the red vertical line. For glass thickness measurement you will see two red lines.

- For more information on the red line refer to chapter 6.1.11 “Monitor light distribution curve on CMOS receiver element” on page 38.

If nothing is visible this may be because alignment is not optimized or object is placed outside of measuring range. Tilting the sensor vertically by up to 15° helps to find the best alignment.

Remark: Laser power can be adjusted manually to increase peak intensity, refer to 6.1.4 Set laser power on page 32 . Sensitivity can be adjusted manually, refer to 6.1.5 Set sensitivity on page 32. Threshold level can be adjusted manually to ignore smaller peaks, refer to chapter 6.1.6 “Set threshold” on page 33.

Fig. 9: Light distribution curve on the CMOS receiver element



- ① Measured barycenter
- ② Set threshold level



5.2.6 What is the best alignment for measuring on glass?

The 24 mm ... 26 mm sensor type (OD5-25x01) is pre-set with a special housing for specular reflection. The optical axis of this type is at approx. 45° angle. This allows for the sensor face of the OD5-25x01 to be mounted parallel to the target surface.

Please be aware that any other sensor head must be mounted at an angle when measuring specular reflection.

Please refer to the following schematic.


Fig. 10: Alignment of sensor head for measuring on reflective material

	
<p>Any OD Precision Sensor head (except OD5-25x01)</p>	<p>OD Precision OD5-25x01 (24 mm ... 26 mm type)</p>
<p>Sensor is mounted at an angle. The angle differs by type. The tilted side of the sensor housing serves as a good indication of the optimum mounting angle.</p>	<p>Sensor is mounted vertically to target.</p>

5.3 Setup Execute function for application

5.3.1 Activate Setup Execute function

Tab. 9: Setup execute function






1 Select “3. Sensor Head [3/3]”	Change the headline to “Sensor Head”
2 Select “Setup execute”	Select “yes”
3 Press 	The setup wizard starts up.
4 Change the setting	For the operation of “setup execute” wizard, refer to the following description.


The setup wizard consists of two operations


1 Basic setting: Choose this option to set the sensor up in an application

2 Calibration: Choose this option to accommodate for compensating tilted alignment.

Note When the setup wizard starts up, follow the operation guide appearing at the bottom of menu. There are several steps in the setup wizard. For setting and selecting each step, follow the steps below;

1. Select the preferred step, and press .
2. Perform setting by selecting , , and by moving to next step with .
3. When the sequence reaches the last step, “Press [SET/RUN] to Complete” is displayed. Press  to finish.

Pressing  completes the setup wizard, and all settings not part of the wizard are set to standard values, unless “keep current setting” was chosen.

The setup wizard can be cancelled in process. To cancel, press the  key.

Not all options in each step can be selected. Those options are displayed in gray.

5.3.2 “Basic Setting” Setup Execute

Page 1 Select Sensor Head.

Choose the sensor head to be set.

Page 2 Select Installation

Select whether measuring on glossy/shiny material using specular reflection of e.g. glass, mirror, stainless steel or measuring on diffuse reflection of e.g. cardboard, rubber, tires, etc.

Page 3 Select Target

Select measuring mode:

1. Measurement on surface of target
= Distance to first surface is measured.
2. Measurement of thickness of transparent material (=glass thickness)
= Distance between first and second surface is measured.
3. Measurement of glass gap
= Distance between 2nd and 3rd surface is measured
4. Measuring to the rear side executof a transparent material (=rear)
= Distance to 2nd surface is measured. (so first surface is ignored)

Note: For “diffuse” only option “surface of target” can be selected.

Page 4 Select Material

Select the material of the target: Glass, mirror or Metal, Plastic, etc.

Page 5 Select average

Select the dynamic moving average. This means that the average of the selected number of measurements is calculated and given out at the selected output rate (e.g. 10kHz) Output rate during operation is not influenced by the selected averaging.

Be aware: When a distance change takes place the time until the new distance is given out is dependent on the chosen averaging. Refer to 6.1.7 “Set moving average” on page 34.

Page 6 Select Status during alarm

Please select the status that is given out during alarm: Clamp or hold.

Page 7 Anti Interference

Please activate anti interference when measuring thickness of transparent, semi transparent or very thin material.

Page 8 Other function

Please select whether the settings for Shift, Span, Sensitivity, Threshold level, Baud rate and Sampling period are set to default or whether previously chosen settings should be kept.

Are set to standard settings:

Set all above settings to factory default. It is possible to further adjust these parameters manually in later steps.

Keep current setting:

Choose this option if all above parameters are already set to specific values and should not be reset to default.

Page 9 Page Finish

Please press “SET/RUN” to finish the wizard.

5.3.3 “Calibration” Setup Execute

This function is used to compensate for an offset that results from tilted alignment. For more information refer to 5.3 “Setup Execute function for application” on page 23.

Page 1 Select Sensor Head

Choose the sensor head to set.

Page 2 Set Measurement / Correct value

This page shows the following:

Tab. 10: Calibration function

Point A Meas. Value:	This is the measured value at point A. Press button "5" to make a measurement.
Point A Corr. Value:	This is the actual distance at point A.
Point B Meas. Value:	This is the measured value at point B. Press button "5" to make a measurement.
Point B Corr. Value:	This is the actual distance at pont B.

By setting actual measurement values (Meas. Value) and correct values (Corr. Value), calibration automatically decides shift and span values.

Important Note:

- Use 10 KEY button to input values. Also the current measurement value can be input by pressing button 5.
- Point A must be closer to the sensor than point B.
- The sensors must be measuring default distance to object. (no manual Zeroing)
- The sign of the measurement must be positive. ("Far side +") This is default setting.
- An example can be found on the following page.

Exemplary Procedure:

- 1a.** Place a gauge block of a known thickness on the target. Read measurement value by pressing “5”. This value is “Point A Meas. Value”.
- 1b.** Enter the “Point A Corr. Value”. Typically choose the exact same value as “Point A Meas. Value” since the actual distance to the target is unknown in most cases. Use 10 KEY button.
- 2a.** Remove gauge block. Read measurement value by pressing “5”. This value is “Point B Meas. Value”.
- 2b.** Calculate “Point B Corr. Value”. Formula: “Point A Meas. Value” + “thickness of gauge block”. Enter the calculated value using 10 KEY button.
- 3.** Press “Set/Run” to finish the Calibration procedure.

Application Example:

To find “corr. values” a reference material of a known thickness is needed.

Typically a gauge block is used. In this case the gauge block has a thickness of 2mm.

Fig. 11: Example of calibration of OD5-85x20 using SOPAS software

The screenshot shows a software interface for calibration. It is divided into two main sections: 'Calibration Input' and 'Calibration Result'.

Calibration Input:

- Head variant:** A dropdown menu showing 'OD5-85'.
- Measure value A:** A text input field containing '59.8166' and a 'Read Value' button to its right.
- Correction Value A:** A text input field containing '59.8166'.
- Measure value B:** A text input field containing '62.0339' and a 'Read Value' button to its right.
- Correction Value B:** A text input field containing '61.8166'.

Calibration Result:

- Shift:** A text input field containing '-0.0617'.
- Span:** A text input field containing '1.1087'.

Be aware:

- Point A must be closer to the sensor than point B.
- The sensors must be measuring default distance to object. (no manual Zeroing)
- The sign of the measurement must be positive. ("Far side +") This is default setting.

5.4 Setup execute function for calibration

For best results alignment must be considered, see following figures which illustrates the resulting error of tilted alignment.

Please refer to 5.3.3 "Calibration" Setup Execute on page 25 for the according procedure.

Fig. 12: Perfect alignment






Fig. 13: Error due to sensor tilt



- ① Side-view
- ② Front-view

Fig. 14: Schematic of the result of the calibration



6 Settings

6.1 Settings of sensor head

6.1.1 Set measurement function, choose measurement target

Tab. 11: Set measurement function, choose measurement target

1	Select "1. Sensor Head [1/3]"	Change the headline to "Sensor Head".
2	Select "Measurement A, B, or C"	A/B/C corresponds to the sensor head
3	Change the setting	Select the measurement target.
4	Press SET/RUN	

- Note**
- Setting to "Surface" measures the distance to the first surface visible to the sensor. This setting is available for all sensor heads.
 - Setting to "Glass Thickness" measures the distance from the front to the back side of a transparent object (such as glass) This means a measurement to the first surface visible to the sensor is taken. Simultaneously a measurement to the second surface visible to the sensor is taken. The sensor then automatically calculates the distance inbetween and gives out the thickness value. "Glass Thickness" can only be used for some OD Precision sensor head types.
In setting to "Glass Thickness", it is important for precise measurement to set the calibration span to the correct value to compensate for the light refraction index of the measured material. Refer to chapter 6.1.3 "Set calibration (span)".
 - Setting to "glass gap" the distance between the second and third surface is measured This means a measurement to the second surface visible to the sensor is taken. Simultaneously a measurement to the third surface visible to the sensor is taken. The sensor then automatically calculates the distance inbetween and gives out the gap thickness value. "Glass gap" can only be used for some OD Precision sensor head types.
 - Setting to "rear" the distance to the second surface is measured This means a measurement to the second surface visible to the sensor is taken. "Rear" can only be used for some OD Precision sensor head types.


Tab. 12: Sensor type and function availability

Sensor type	Glass thickness	Glass gap	Rear	Remark
OD5-25x	yes	not supported	not supported	
OD5-30x	yes	yes	yes	only half the measurement range is available
OD5-85x	yes	yes	yes	
OD5-150x	not supported	not supported	not supported	not supported
OD5-350x	not supported	not supported	not supported	not supported
OD5-500x	not supported	not supported	not supported	not supported

Setting can be variable for each bank.

Default: "Surface"

Fig. 15: Reflection types



- ① Diffuse reflection type
- ② Specular reflection type

6.1.2 Set calibration (shift)

Tab. 13: Set calibration (shift)

1 Select "1. Sensor Head [1/3]"	Change the headline to "Sensor Head".
2 Select "Shift A, B, or C"	A/B/C corresponds to the sensor head A, B and C.
3 Change the setting	Set the shift of sensor head measurement value (-0.1000 to +0.1000).
4 Press <input type="button" value="SET/RUN"/>	

Note Calibration(shift) is not the "offset/ shift" value. Instead this value is used to accommodate for systematic error caused by different light refraction indices e.g. for glass thickness measurement. Set the value by the proportion of measurement error to the measurement range.

Manual setting example:

Sensor head: 85 mm ± 20 mm type, measurement value: displayed as "+85.400 mm"

To calibrate the value to 85.000 mm, set -0.0100 by the following calculation.

$$(85.000 - 85.400)/(20 \times 2) = -0.0100$$

This setting value does not change by zero reset, the value is stored globally and not stored in a bank.

This setting allows 10 KEY (numeric key) function.

Setting the measurement target to "Glass Thickness" influences this value (see chapter 6.1.1 "Set measurement function, choose measurement target").

Default: "0.0000"

OD Precision**6.1.3 Set calibration (span)**

Tab. 14: Set calibration span

1	Select "1. Sensor Head [1/3]"	Change the headline to "Sensor Head"
2	Select "Span A, B, or C"	A/B/C corresponds to the sensor head A,B and C.
3	Change the setting	Set the span of sensor head measurement value. (0.0000 to 3.9999)
4	Press <input type="button" value="SET/RUN"/>	

Note Set the value by the proportion of measurement error to the measurement range. It is used for:

- Performing calibration of sensor head Please refer to chapter 5.4 "Setup execute function for calibration" on page 27.
- Setting the measurement target to "Glass Thickness" refer to chapter 5.2.4 "Referencing for glass thickness measurement" on page 19.

Manual setting example:

Sensor head: 85 mm ± 20 mm type, measurement value error of 0,1mm; 10.100 mm

To calibrate the value to 10.000 mm, set 1.0100 by the following calculation.

$$10.100/10.000 = 1.0100$$

When choosing "Glass Thickness" mode, the following setting is necessary (Refer to chapter 6.1.1 "Set measurement function, choose measurement target").

- Input reciprocal of glass refraction (nd) to be measured as span setting value.
Example: Input "0.5435" when; nd = 1.84
- When the glass thickness is known, adjust the input value by referencing the actual measurement value. Refer to chapter chapter 5.2.4 "Referencing for glass thickness measurement" on page 19.

Note that the more span value increases, the more the measurement value decreases.


This setting value does not change by zero reset. the value is stored globally and not stored in a bank.

This setting allows 10 KEY (numeric key) function.

Default: "1.0000"

6.1.4 Set laser power


Tab. 15: Set laser power

1	Select "1. Sensor Head [1/3]"	Change the headline to "Sensor Head"
2	Select "Laser Power A, B, or C"	A/B/C corresponds to the sensor head A, B or C.
3	Change the setting	Select the laser power.
4	Press 	

Note For measuring an object with specular reflection of light (such as mirror or glass), set the laser power low. (Normally 1 [Minimum])
 For measuring on any other objects (objects with diffuse reflection of light), set the laser power high. (Normally 5 [Maximum])
 Turning this setting to "OFF" will turn the laser off. This setting is stored in the active bank.
 Default: "5 [Maximum]"

6.1.5 Set sensitivity

Tab. 16: Set sensitivity

1	Select "1. Sensor Head [1/3]"	Change the headline to "Sensor Head".
2	Select "Sensitivity A, B, or C"	A/B/C corresponds to the sensor head A, B or C.
3	Change the setting	Select the sensitivity.
4	Press 	

Note For "Auto" the receiving sensitivity is dynamically adjusted to light remission of the target surface. Auto adjustment may take up to 2 ms when the object-remission is extreme and changes instantaneously.
 If the above case causes any problem, the sensitivity can be set to a fixed level. The optimum fixed sensitivity can be checked by reviewing the light distribution on the CMOS receiver element. Please refer to chapter 6.1.11 "Monitor light distribution curve on CMOS receiver element" on page 38.
 Setting is stored in the active bank.
 Default: "Auto"

OD Precision**6.1.6 Set threshold**

Tab. 17: Set threshold

1	Select "2. Sensor Head [2/3]"	Toggle to sheet "Sensor H".
2	Select "Thresh Level A, B, or C"	A/B/C corresponds to the sensor head
3	Change the setting	Select the threshold value.
4	Press <input type="button" value="SET/RUN"/>	

Note The algorithm measures the distance to the object by evaluating the cross point of the barycenter of the peak of the light distribution and the threshold line. When the receiving waveform is extremely asymmetric (such as semitransparent object or object with very challenging surface condition), high thresholds can reduce the measurement error. When setting the threshold to 1 or more, ensure the receiving waveforms are always higher than the threshold for every object to be measured. (Any waveform lower than threshold is ignored)

The relationship between light distribution waveform and threshold can be reviewed with with the "Monitor light distribution curve on CMOS receiver element function" in chapter 6.1.11 on page 38.

When choosing "Automatic", the threshold is dynamically auto-adjusted (Threshold is automatically set to relatively high thresholds). Note that the resolution can be deteriorated.

Setting can be variable for each bank.

Default: "0"

6.1.7 Set moving average

Tab. 18: Set moving average

1 Select "2. Sensor Head [2/3]"	Toggle to sheet "Sensor Head".
2 Select "Average A, B, or C"	A/B/C corresponds to the sensor head
3 Change the setting	Select the number of measurement values for the averaging.
4 Press <input type="button" value="SET/RUN"/>	

Note Large moving average count is advantageous to resolution and unexpected irregularity of object surface. Small moving average count is advantageous to sensitive reaction to distance changes.


This sensor uses dynamic moving averaging. On start-up the selected number of measurement values are collected, then averaging takes place and the average is given out. From then on its one-in/ one-out, meaning that the next measurement value is collected and the average is taken immediately. This means the output rate is unaffected, but response time is affected. Please refer to the figure below.

For large distance changes, the response time can be roughly calculated by the following expression. (Sampling frequency x moving average count)

The following figure shows the relationship between the moving average, output rate and response time. Avg = 32 means that the average of 32 values is taken. Avg = 8 means that the average of 8 measurements is taken. In each case averaging is moving/dynamic, as compared to block averaging. With block averaging the average of the chosen number of measurements, e.g.32, is taken, then given out. Then the sensor waits for the next 32 measurements to be taken, takes the average and gives out the result. This means that the output rate is reduced by 32.

Default: "256"

Fig. 16: Moving average and response time



OD Precision

Tab. 19: Set communication speed

6.1.8 Set the communication speed

1 Select “2. Sensor Head [2/3]”	Toggle to sheet “sensor head setting.”
2 Select “Baud [kbps] A, B, or C”	A/B/C corresponds to the sensor head A, B and C.
3 Change the setting	Select the communication speed between sensor head and controller.
4 Press <input type="button" value="SET/RUN"/>	

Note Values higher than 921.6 kbps will transfer all the sampling data of sensor head to the controller.
 When the cable length between sensor head and controller is very long (approx. >25m), select slow communication speed to avoid loss of data.
 Default: “921.6 kbps”

6.1.9 Set the measurement value at alarm

Tab. 20: Set Clamp / Hold function

1 Select "2. Sensor Head [2/3]"	Toggle to sheet "sensor head setting."
2 Select "During Alarm A, B, or C"	A/B/C corresponds to the sensor head A, B and C
3 Change the setting	Select the measurement value at alarm. Clamp or Hold.
4 Press <input type="button" value="SET/RUN"/>	

Note This option defines the measurement value the sensor gives out when it is unable to measure.


- When set to "Clamp" the sensor gives out 2999.99999 mm as measurement value indicating that no measurement could be taken.
- When set to "Hold" the sensor gives out the last good measurement before it became unable to measure.

In both cases the "Alarm Output" is activated. For evaluating the Alarm Output the I/O Expansion cable is necessary.

Please refer to the following schematic.

Default: "Clamp"

Fig. 17: Clamp/Hold function



- ① Clamp
- ② Hold

OD Precision


6.1.10 Set sampling period

Tab. 21: Set sampling period

1 Select "2. Sensor Head [2/3]"	Toggle to sheet "sensor head setting."
2 Select "Sampling Per. A, B, or C"	A/B/C corresponds to the sensor head A, B and C.
3 Change the setting	Set the sampling period.
4 Press SET/RUN	


Note Shorter sampling period results in faster response time, longer sampling period enhances the resolution and the capability to measure on very dark material.

Fig. 18: Sampling period consequences



- ① Fast response time
- ② High-capability to measure on dark material

Fig. 19: Light distribution curve



- ① High-Sensitivity and high sampling period
- ② Low-Sensitivity and high sampling period

Default is as follows:

Tab. 22: Sampling period default values

Sampling Period	Sensor Head
100 μ s	OD5-25x01 24 ... 26 mm
	OD5-30x05 25 ... 35 mm
	OD5-85x20 65 ... 105 mm
	OD5-150x40 110 ... 190 mm
800 μ s	OD5-350x100 250 ... 450 mm
	OD5-500x200 300 ... 700 mm
	OD5-25x01 24 ... 26 mm


Tab. 23: View light distribution on CMOS receiver element

6.1.11 Monitor light distribution curve on CMOS receiver element

1 Select "3. Sensor Head [3/3]"	Toggle to sheet "sensor head setting."
2 Select "Operation"	A/B/C corresponds to the sensor headA, B and C.
3 Change the setting	Choose "light distribution A/B/C" or "measurement".
4 Press <input type="button" value="SET/RUN"/>	

Note Use this function to monitor what the sensor actually sees. This function shows the light remission on the receiver element. (CMOS element)

Fig. 20: Light distribution curve on CMOS receiver element



- ① Red line
- ② Blue line

Red Line on light distribution function

A red line indicates the measurement value of the sensor. It shows the position of the barycenter of a remission peak.

- When the measurement target is set to "Surface", only one red line will appear on the first peak closest to the sensor.
- When the measured target is set to "Glass Thickness" two red lines will appear, one on the first and one on the second peak. One line indicates the front side of the glass/transparent material and the other indicates the rear side.
- When the measurement target is set to "Rear" one red line will appear. This red line will appear on the second peak, not on the first peak as with "surface" mode.
- When measurement target is set to "Glass gap" then two red lines will appear. One on the second and one on the third peak.

Blue Line of light distribution function

A blue line appears at the position set by the Receiving Waveform Threshold Setting (see chapter 0 "Set threshold").

Set threshold").

Note Receiving waveform does not appear if no sensors are connected.

Measurement operation stops while monitoring the receiving waveform. Measurement is continued when returning to "Measurement" from "Light Distrib" in the menu.

Default is "Measurement".

6.1.12 Prevent mutual interference

Tab. 24: Set anti-interference mode

1 Select "3. Sensor Head [3/3]"	Toggle to sheet "sensor head setting."
2 Select "Anti interfere"	
3 Change the setting	Select the Anti Interfere (mutual interference prevention) function.
4 Press <input type="button" value="SET/RUN"/>	

Note Default is "Off", which allows the measurement with measuring frequency stated in the specification. Measurement timing of each sensor head is asynchronous. Setting to "A and B" allows synchronous measurement timing between sensor head A and sensor head B (alternate measurement), Lasers are pulsed, reducing the mutual interference.


In the setting "A and B" the measuring frequency is 6 times slower, the data storage time of image sensor is not influenced, so no sensitivity adjustment is necessary.

It is recommended to activate the function to avoid negative influences in the following cases.

- When thickness measurement with two sensor heads is performed on transparent or semi-transparent material.
- When measurement is performed in a way that laser light of sensor head A is reflected to sensor head B. Refer to following figure.

Default: "Off"

Fig. 21: Mutual interference



6.1.13 Set sensor head type

Tab. 25: Set sensor head type manually

1 Select "3. Sensor Head [3/3]"	Toggle to sheet "sensor head setting."
2 Select "Model A, B or C"	A/B/C corresponds to the sensor head A, B and C.
3 Change the setting	Select the head type to be connected.
4 Press SET/RUN	

Tab. 26: Sensor head types

AUTO	Every time the power is turned on, the head type code is read-out and the setting is automatically adjusted. This function is active even when the head is not connected.
25 mm	One can also manually choose the connected sensor head.
30 mm	
85 mm	
150 mm	
350 mm	
500 mm	When the head is not connected, select this option.
No connection	

After the setting is changed, be sure to turn the power ON again.

Default: "AUTO"

6.2 Setting control/switching output

6.2.1 Set upper limit/lower limit

Tab. 27: Set control/switching output

1 Select "4. Control Output [1/2]"	Toggle to sheet "Control Output"
2 Select Upper or Lower to set	Q1 to 5 correspond to control output 1 to 5. "Upper" corresponds to upper limit, and "Lower" corresponds to lower limit.
3 Change the setting	Set the upper limit and lower limit of control/switching output. (-2999.9999 to +2999.9999 mm)
4 Press <input type="button" value="SET/RUN"/>	

Note This setting allows 10 KEY (numeric key) function. Setting can be variable for each bank.

Default:

- Q1 Upper "+1.0000"
Lower "-1.0000"
- Q2 Upper "+2.0000"
Lower "-2.0000"
- Q3 Upper "+3.0000"
Lower "-3.0000"
- Q4 Upper "+4.0000"
Lower "-4.0000"
- Q5 Upper "+5.0000"
Lower "-5.0000"

6.2.2 Set hysteresis

Tab. 28: Set hysteresis


1 Select "4. Control Output [1/2]"	Toggle to sheet "Control Output"
2 Select Hysteresis	
3 Change the setting	Set hysteresis of control output. (0.0000 to 2999.9999 mm)
4 Press <input type="button" value="SET/RUN"/>	

Note Hysteresis is the difference in distance between the switch-on and switch-off points of a switching output. Hysteresis is necessary for stable switching when the measured distance fluctuates around the switching point that has been set. The hysteresis can be set freely. The free choice allows an ideal compromise between precise switching and stable behavior in each individual application.

This setting allows 10 KEY (numeric key) function. This setting is a global setting, it is set for all control output, upper and lower limit values, as well as to all banks.

Default: "0.0000"

Fig. 22: Hysteresis



- ① Upper
- ② Lower

6.2.3 Set delay

Tab. 29: Set delay function

1 Select "4. Control Output [1/2]"	Toggle to sheet "Control Output"
2 Select "Delay"	
3 Change the setting	Select the delay mode (timing control).
4 Press SET/RUN	

Note The following delay modes of the control/switching outputs can be chosen.


- "Off": Timer is deactivated
- "Off Delay": Switching OFF of the control/switching output is delayed for set period. Short signals (bursts) are suppressed.
- "On Delay": Switching ON of control/switching output is extended by the configured time to allow for the use of slower control system.
- "1 Shot": The signal given out always remains active for the same period of time regardless of the duration of the input signal

The time period is set in "Delay time setting" (see following chapter 6.2.4 "Set delay time").

This setting is set for all control/switching outputs.

Default: "Off"


Fig. 23: Timing/delay functions



- ① OFF
- ② OFF DELAY: OFF delay
- ③ ON DELAY: ON delay
- ④ 1 SHOT: Fixed and once only switching duration

OD Precision**6.2.4 Set delay time**

Tab. 30: Set delay time

1 Select “4. Control Output [1/2]”	Toggle to sheet “Control Output”
2 Select Timer	
3 Change the setting	Set the delay time of control output. (0 to 60000 ms)
4 Press 	

Note When the delay setting is “Off”, this setting is disabled (see chapter 6.2.4 “Set delay time”).


This setting allows 10 KEY (numeric key) function.

This setting is set for all control/switching output.

Default: “0 ms”

6.2.5 Set control/switching output source

Tab. 31: Set judgement source

1 Select “5. Control Output [2/2]”	Toggle to sheet “Control Output”
2 Select Source to set	Q1 to Q5 correspond to control/switching output 1 to control/switching output 5.
3 Change the setting	“A” : Measurement value of sensor head A “B” : Measurement value of sensor head B “C” : Measurement value of sensor head C “CAL”: Calculation value
4 Press 	

Note The control/switching output source (A/B/C/CAL) corresponds to four (4) values displayed in the RUN mode.

For calculation value, refer to the description of Setting calculation (see chapter 6.4 “Setting calculation”).

Default: “A”

6.3 Setting analog output


6.3.1 Set upper/lower limit

Tab. 32: Set analog output

1 Select “6. Analog Output”	Toggle to sheet “Analog Output”
2 Select Upper or Lower to set	Port 1 to Port 3 correspond to analog output 1 to analog output 3. “Upper” is upper limit value, and “Lower” is lower limit value.
3 Change the setting	Set upper limit value and lower limit value of analog output. (-2999.9999 to +2999.9999 mm)
4 Press <input type="button" value="SET/RUN"/>	

Note Value set to “Upper” corresponds to +10 V (or 20 mA) of analog output.
Value set to “Lower” corresponds to -10 V (or 4 mA) of analog output.
When the value exceeds Upper limit, the maximum value is given out.
When the value remains below the Lower limit, the minimum value is given out.
(When the value is out of measurement range of sensor, maximum value is given out.)
There are two analog outputs: voltage output and current output. Both are active at the same time.
Default: Lower limit = start of measuring range, Upper limit = end of measuring range.

Fig. 24: Analog output



- ① Lower
- ② Upper

OD Precision

Tab. 33: Set source for output

6.3.2 Set output source

1 Select "6. Analog Output"	Toggle to sheet "Analog Output"
2 Select Source to set	Port 1 to Port 3 correspond to analog output 1 to analog output 3.
3 Change the setting	"A" : Measurement value of sensor head A "B" : Measurement value of sensor head B "C" : Measurement value of sensor head C "CAL": Calculation value
4 Press <input type="button" value="SET/RUN"/>	

Note The output source (A/B/C/CAL) corresponds to the four (4) values displayed in the RUN mode.

For the calculation value, refer to the calculation setting (see chapter 6.4 Setting calculation on page 46).

Default: Port 1 = "A", Port 2 = "B", Port 3 = "C"

6.4 Setting calculation


6.4.1 Set calculation

Tab. 34: Setting calculation

1 Select "7. Calculation"	Toggle to sheet "Calculation".
2 Select calculation formula to set	Select either Value of W, Operator 1, Value of X, Operator 2, Value of Y, Operator 3 or Value of Z. For calculation structure, refer to the following description.
3 Assign Calculation value to output	Set the calculation value used as source of control output and/or analog output. Refer to chapter 6.2.5 "Set control/switching output source" on page 43 and chapter 6.3.2 "Set output source" on page 45.
4 Press SET/RUN	

Note The following calculation structure is used.

Fig. 25: Operators to program calculations



- ① Operator 1
- ② Operator 2
- ③ Operator 3

The following options are available for Operator 1 to Operator 3:

- "+" : Addition (+)
- "-" : Subtraction (-)

For the other variables (W/X/Y/Z), select from the followings:

- "A" : Measurement value of sensor head A
- "B" : Measurement value of sensor head B
- "C" : Measurement value of sensor head C
- "K" : Constant K (see chapter 6.4.3 "Set value of K" on page 47)
- "0" : 0

Setting is stored in the active bank.

Default:

- Value of W "A"
- Operator 1 "+"
- Value of X "0"
- Operator 2 "+"
- Value of Y "0"
- Operator 3 "+"
- Value of Z "0"

The default calculation therefore is: $A+0+0+0+0 = A$, this means that Cal = A.

OD Precision


6.4.2 Change algebraic sign of measurement value

Tab. 35: Set algebraic sign of measurement value

1 Select "7. Calculation"	Toggle to sheet "Calculation"..
2 Select "Sign A, B, or C"	A/B/C corresponds to sensor head A, B or C.
3 Change the setting	Select the algebraic sign. Refer to figure below.
4 Press <input type="button" value="SET/RUN"/>	

Note Setting to "Far side+" means that the measurement value increases as the object moves further away from the sensor head. Measurement value sign is positive. (This is default)
 Setting to "Near side+" reverses the algebraic sign (\pm sign) and the measurement value increases as the object moves closer to the sensor head. Measurement value sign is negative.
 Default: "Far side+"

Fig. 26: Near/Far side +, change algebraic sign



- ① For Near side+, negative sign of measurement value
- ② For Far side+ , positive sign of measurement value

6.4.3 Set value of K

Tab. 36: Set value of constant "K"

1 Select "7. Calculation"	Toggle to sheet "Calculation"..
2 Select "Value of K"	
3 Change the setting	Set the constant K for calculation setting. (-2999.9999 to +2999.9999 mm)
4 Press <input type="button" value="SET/RUN"/>	

Note Use this setting when a constant K is used for the calculation formula.
 This setting allows 10 KEY (numeric key) function. Setting is stored in the active bank.
 Default: "0.0000"

6.4.4 Set shift/offset

Tab. 37: Set shift/ offset

1	Select "7. Calculation"	Toggle to sheet "Calculation"..
2	Select "Shift A, B, C" or CAL	A/B/C corresponds to sensor head A, B and C. CAL corresponds to the calculation value.
3	Change the setting	Sets the shift/offset value of the measurement of the sensor head and the calculation value (-2999.9999 to +2999.9999 mm).
4	Press <input type="button" value="SET/RUN"/>	


Note This setting is used to set the measurement value to zero (0) using the zero reset function. This setting allows 10 KEY (numeric key) function. Setting is stored in the active bank.
Default: "0.0000"

6.5 Using calculation

6.5.1 Calculation examples

Various applications with two or three sensor heads are possible. E.g. flatness, thickness and centricity measurement. Following figure shows some calculations.

Fig. 27: Exemplary calculation functions



A Distance A
 B Distance B
 CALC Thickness
 K Distance K

6.5.2 Thickness calculation

A reference material of a known thickness is placed between the two sensor heads and a “Zeroing” of both sensor heads is performed. The following formula is then used to calculate the thickness of any object placed between the sensor heads.

$$K - A - B = 0$$

K = thickness of a reference object

A = measurement of sensor head A


B = measurement of sensor head B

Note the following procedure:

- 1.) Set “K” to the thickness of the reference object (e.g. gauge block)
- 2.) Place the reference object between the two sensor heads. (within the measurement range of each sensor head)
- 3.) Conduct Zeroing of the used sensor heads.

Calculation result now represents thickness of the object placed in-between the two sensor heads.

Fig. 28: Calculation;
 Thickness with two sensor
 heads



- A Distance A
- B Distance B
- K Known Thickness K
- D Distance D

When measuring the thickness of any material with 2 sensor heads from two sides, alignment becomes very important for accurate measurement.


Error in alignment will result in inaccurate measurements, unless each of the sensor heads is calibrated beforehand (e.g. with the calibration wizard) to compensate errors in alignment.

Also ensure that the object is within the measurement range of each individual sensor.

When measuring thickness with two sensor heads, anti-interference mode must be activated when the material is transparent, semi-transparent, or very thin. In this case sampling frequency is 6 times longer as the lasers are pulsed.

Note: One can easily check alignment by placing a paper in-between the two sensor heads. If two light spots are visible on the paper, then alignment is incorrect. Move the paper within the measurement range to ensure only one light spot is visible on the paper throughout the full measurement range.

Fig. 29: Alignment for measuring with two sensor heads



6.6 Setting hold

Tab. 38: Hold functions


1 Select "8. Hold"	Toggle to sheet "Hold"..
2 Select "Head A, B, C" or "Calculated Val"	A/B/C corresponds to sensor head A, B and C. Calculated Val corresponds to the calculation value.
3 Change the setting	Select HOLD function. Refer to list below for the different options.
4 Press <input type="button" value="SET/RUN"/>	

Note The selected HOLD function is triggered using the Hold Input and Reset Input. The inputs are accessible via the I/O Expansion cable. There are seven setting options as follows:

"Off": HOLD is deactivated

"Sample": Sample HOLD. The current measurement value is held when at the rising edge.


Fig. 30: Sample hold function



- ① Measurement value
- ② Sample holding value

"Peak": Peak HOLD. "Peak": Peak HOLD. The peak value is being held.


Fig. 31: Peak hold function



- ① Measurement value
- ② Peak holding value
- ③ Period of sampling

“Bottom”: Bottom HOLD. The bottom value is being held.


Fig. 32: Bottom hold function



- ① Measurement value
- ② Bottom holding value
- ③ Period of sampling

“Peak to Peak”: Peak to Peak HOLD. The difference between peak and bottom value is being held.


Fig. 33: Peak to peak hold function



- ① Measurement value
- ② Peak to peak holding value
- ③ Period of sampling

“Auto Peak”: Auto Peak HOLD. The peak value is automatically held. Function is activated with rising edge on Reset Input. The function is deactivated when Hold input is ON. The Reset Input sets the held measurement value to the current measurement value.

Fig. 34: Auto peak hold function




- ① Measurement value
- ② Auto peak holding value
- ③ Stop of revision

OD Precision

“Auto Bottom”: Auto Bottom HOLD. The bottom value is automatically held. Function is activated with rising edge on Reset Input. The function is deactivated when Hold input is ON. The Reset Input sets the held measurement value to the current measurement value.

Fig. 35: Auto bottom hold function



- ① Measurement value
- ② Auto bottom holding value
- ③ Stop of update

Default: “Off”

6.7 Setting filter

6.7.1 Set filter function

Tab. 39: Set filter function

1 Select "9. Filter"	Toggle to sheet "Filter"..
2 Select "Filter"	
3 Change the setting	"Off": Filtering is not applied "Hi pass" : "High pass filter" is applied "Lo pass" : "Low pass filter" is applied
4 Press <input type="button" value="SET/RUN"/>	


Note To set filter to "Hi pass" or "Lo pass", moving average must be set to "1" (deactivated) (see chapter 6.1.7 "Set moving average" on page 34).

Setting to "Hi pass" ignores the changes of the measurement value with a frequency lower than the cut-off frequency. In this setting, the measurement value is "0.00000" when the object stops moving.

Setting to "Lo pass" ignores the changes of the measurement value with a frequency higher than the cut-off frequency.

Example of result with "Hi pass" filter


Fig. 36: Hi-Pass Filter



- ① Off
- ② Hi pass

Example of result with "Lo pass" filter

Fig. 37: Deactivated filter



- ① Off
- ② Lo pass

Default: "Off"

OD Precision**6.7.2 Set frequencies of filter functions**

Tab. 40: Set filter settings

1 Select "9. Filter"	Toggle to sheet "Filter".
2 Select "Frequency"	
3 Change the setting	Select the filter frequency for filter setting.
4 Press <input type="button" value="SET/RUN"/>	

Note Frequencies available:

Tab. 41: Hi-/Low- pass filter frequencies

Setting value	Cut-off frequency applicable when Hi pass is selected	Cut-off frequency applicable when Lo pass is selected
Hi: 650/Lo: 2000	650 Hz	2000 Hz
Hi: 350/Lo: 800	350 Hz	800 Hz
Hi: 200/Lo: 400	200 Hz	400 Hz
Hi: 100/Lo: 200	100 Hz	200 Hz
Hi: 50/Lo: 100	50 Hz	100 Hz
Hi: 25/Lo: 50	25 Hz	50 Hz
Hi: 15/Lo: 20	15 Hz	20 Hz
Hi: 10/Lo: 10	10 Hz	10 Hz

Example: "Hi pass" filter is chosen and filter frequency "Hi: 650/Lo: 2000" is chosen. This means that any change of the measurement value with a frequency lower than 650 Hz is ignored.

"Lo pass" is selected. This means that changes of the measurement value with a frequency higher than 2000 Hz are ignored.

Default: "Hi: 650/Lo: 2000"

6.8 Setting bank

Tab. 42: Change bank

1	Select "10. Bank"	Toggle to sheet "Bank"..
2	Select Bank	
3	Change the setting	Select active memory bank. A total of 16 banks is available. (0...15)
4	Press <input type="button" value="SET/RUN"/>	

Note Many parameter settings are stored in the active bank. This is indicated by the small blue "B" sign next to the parameter. Some parameter settings are stored globally and will remain the same for each bank. These are the parameters without a blue "B" next to them.

When bank function is not required, select "0".

The bank setting after power ON is as follows:

- When the bank switching input (in I/O 50-pin input/output connector) is bank 0 (all OFF): bank is set to bank 0
- Bank can always be changed by pressing the "+/-BANK" button.
- When the bank switching input is other than bank 0: bank according to bank switching input signal is activated. For the list of available signals refer to chapter "Bank switch input" on page 10.

6.9 Setting RS 232

Tab. 43: Change settings of RS232 communication


1	Select "11. RS232"	Toggle to sheet "RS232".
2	Change the setting	Adjust the setting to that of communication device.
3	Press <input type="button" value="SET/RUN"/>	

Note Default: Baud "115200"
Data "8"
Parity "None"

6.10 Using memory function

6.10.1 Copy data


Tab. 44: Copy data from bank to bank

1 Select "12. Memory"	Toggle to sheet "Memory"..
2 Select "Copy from"	Select the bank to copy from. All settings stored in this bank will then be copied. Use "Initial setting" to restore to default.
3 Select "(Copy) to"	Select the destination bank number to copy the bank settings to. To copy to all banks, select "All Bank". To reset device choose "Complete Reset".
4 Select "Execute"	Selects "Yes"
5 Press 	Copying is executed.

Note Use this setting to copy the setting value to other bank.

6.10.2 Return bank setting to Default (initialization)


Tab. 45: Return bank to default settings

1 Select "12. Memory"	Toggle to sheet "Memory"..
2 Select "Copy from"	Select "Initial setting".
3 Select "(Copy) to"	Select bank to reset to default values. To reset all banks to default, select "All Bank". To reset common settings to default, select "Common settings".
4 Select "Execute"	Selects "Yes"
5 Press 	The initialization starts.

Note When choosing "Complete Reset" for "Copy to ..." the setting "Copy from" becomes inactive.

6.10.3 Complete reset

Tab. 46: Complete reset


1 Select "12. Memory"	Toggle to sheet "Memory"..
2 Select "Copy from"	Ignore this setting
3 Select "(Copy) to"	Select "Complete reset"
4 Select "Execute"	Selects "Yes"
5 Press 	The initialization starts.

Note When choosing "Complete Reset" for "Copy to ..." the setting "Copy from" becomes inactive.

6.11 Setting display and keys

6.11.1 Set internal decimal places visible in RUN mode

Tab. 47: Set decimal places visible in RUN mode


1 Select "13. Display/Key"	Toggle to sheet "Display/Key".
2 Select Display Digit	
3 Change the setting	"All" : displays up to 5 places of decimals "-1" : displays up to 4 places of decimals "-2" : displays up to 3 places of decimals "-3" : displays up to 2 places of decimals
4 Press 	

Note This setting only changes the displayed digit number, it does not influence the output value or even the output quality.

Default: "-2"

6.11.2 Set brightness


Tab. 48: Set brightness

1 Select "13. Display/Key"	Toggle to sheet "Display/Key".
2 Select LCD Backlight	
3 Change the setting	"100 percent" : Maximum brightness "20 percent" : 20% brightness "2 percent" : 2% brightness
4 Press 	

Note Default: "100 percent"

6.11.3 Set key lighting

Tab. 49: Set key lighting

1 Select "13. Display/Key"	Toggle to sheet "Display/Key".
2 Select "Key Lighting"	
3 Change the setting	"On" : key lighting ON "Off" : key lighting OFF
4 Press 	

Note Setting to "On" lights the buttons which are available.


Default: "On"

7 Mounting


7.1 Installing controller

7.1.1 Install to DIN rail

Tab. 50: Mount controller to DIN rail


<p>1 Insert the upper claw on rear of the DIN rail, and push the bottom of controller into the rail, with the knob pulled down.</p>	 <p>① Knob</p>
<p>2 Ensure the controller fits perfectly on the DIN rail.</p>	



Note To remove the controller from DIN rail, pull the bottom of controller to the front, with the knob pulled down using a flathead screwdriver.



7.1.2 Install to panel


Tab. 51: Mount controller to panel

<p>1 Drill hole of specified size on the panel. (“Dimensional outline”).</p>	
<p>2 Remove any terminal board and connectors from the controller.</p>	
<p>3 Insert the upper of controller to the opening, and push the bottom into the opening. When the whole controller is in the opening, align the position.</p>	

<p>4 Insert the protruded part of fixture to the slit at the lateral side of controller (panel mounting mechanism).</p>	 <p>① Fixture</p>
<p>5 By pressing fixture to the controller, slide the fixture to the direction indicated by the arrow, to secure the controller.</p> <p>Note Set the fixture to the opposite side also.</p>	 <p>① Fixture</p>

Note To install/remove the controller to/from the panel, remove all the terminals and connectors connected to the controller.

To remove fixture from the controller, pull claws (two places) up to the direction of arrow A, and slide the fixture to the front (direction of arrow B).



① Fixture

7.2 Connecting connectors for sensor head



WARNING

Ensure the cutout of connector smoothly fits the protruded part of controller. Forced connector insertion can damage the connector pin seriously.





Tab. 52: Connecting connectors for sensor head

<p>1 Insert the connector cutout to the protruded part of controller.</p>	<p>① Cutout ② Protruded part</p>
<p>2 Turn the connector lock to the direction of arrow (clockwise direction) until it clicks.</p>	<p>① Lock</p>

Note To remove connector from the controller, turn the lock in counterclockwise direction before removing.

7.3 Connecting cable to 12-pin terminal board


Tab. 53: Connecting cable to 12-pin terminal board

<p>1 Strip the insulation of the cable coating to expose the cable core by 8 to 9 mm. When using shield cable, twist so that the core diameter is less than $\varnothing 1.2$ mm.</p>	 <p>① Peel the cable coating</p>
<p>2 Insert the cable until exposed cable is fully inserted into terminal board.</p>	 <p>① Press down using a flathead screwdriver ② Insert cable</p>
<p>3 Pull lever up until it clicks</p>	 <p>① Pull up</p>
<p>4 Pull the cable softly to ensure that the lever is locked and the cable is not pulled out. Ensure that the cable core is not exposed.</p>	 <p>① Ensure the cable is not easily pull out</p>

8 Appendix

8.1 Input/output diagram

Fig. 38: Input/output diagram



8.2 Communication

8.2.1 Communication specification

RS 232 (In the Default setting, the following values are set)

Tab. 54: RS232 communication parameters

Baud rate	9600/19200/ 38400 /115200 bps
Transmission code	ASCII
Data length	7/ 8 bit
Stop bit length	1 bit
Parity check	None /Even/Odd
Data classification	STX · ETX

Adjust the settings of the computer and this product within the above range.

USB

This product uses FT245M manufactured by Future Technology Devices International Ltd. (FTDI) for the USB device. (USB1.1 and USB2.0 compatible)

This product can be accessed from the computer using the virtual COM port (VCP) driver or DLL USB driver D2XXX.

Please use the FTDI driver that was supplied with your current SOPAS software. You can find this driver in a folder (FTDI Driver) under the SOPAS program.


8.2.2 Communication procedure

When a command is sent from computer to the controller, the controller sends a response back to the computer.

Basically, one response is sent to one command.

When a command is sent, be sure to send it after receiving the response to the previous command. (A stop command can be sent while measurement values are being read continuously.)

Fig. 39: USB communication procedure




OD Precision

8.2.3 Connection with computer

RS 232

Use a shielded RS232C cable (straight).

Fig. 40: RS232C communication pinnig



① Not connected

Note The shield must be applied when using the RS232 interface.

To connect the sensor with an RS232 compatible interface to a computer (D-sub, 9 pin):

- Connect pin 2 (TXD) of the sensor to pin 2 (RXD) on the computer.
- Connect pin 3 (RXD) of the sensor to pin 3 (TXD) on the computer.
- Connect pin 5 (GND) of the sensor to pin 5 (GND) on the computer.
- Connect the shielded cable with shielding of the D-sub male connector to the sensor and to the computer.

USB

Use a USB 2.0 cable (A-B type).

8.2.4 Send data format (command)

There three types of data (command 1, 2 and 3) being sent. Parameters are indicated by the combination of commands 1 and 2, and command 3 indicates the setting value.

When only commands 1 and 2 are sent, the setting value for the parameter is returned as response. (Readout)

To write (change) the setting item, add command 3 which then becomes the new setting value of the according parameter.

When data was written correctly, ">" (3EH) is returned as the response.

When the command was wrong, "?" (3FH) is returned as the response.

Tab. 55: Command format for read out of data

For the readout of settings or measurement values, and control commands (such as zero reset)

02H		20H		03H	
STX	Command 1	SPACE 1	Command 2	ETX	
1	2	3	4	5	

1	STX	Code which indicates the beginning of the data to be sent. (02H)
2	Command 1	Select and set from the command 1 column in the command table. Refer to chapter 8.2.6 "Communication command table" on page 68 onwards.
3	SPACE 1	Indicates the separation of command 1 and command 2. (20H)
4	Command 2	Select and set from the command 2 column in the command table. Refer to chapter 8.2.6 "Communication command table" on page 68 onwards.
5	ETX	Code which indicates the end of send data. (03H)

Tab. 56: Command format for writing data

For writing settings

02H		20H		20H		03H	
STX	Command 1	SPACE 1	Command 2	SPACE 2	Command 3	ETX	
1	2	3	4	5	6	7	

1	STX	Code which indicates the beginning of the data to be send (02H)
2	Command 1	Select and set from the command 1 column in the command table. Refer to chapter 8.2.6 "Communication command table" on page 68 onwards.
3	SPACE 1	Indicates the separation of command 1 and command 2. (20H)
4	Command 2	Select and set from the command 2 column in the command table. Refer to chapter 8.2.6 "Communication command table" on page 68 onwards.
5	SPACE 2	Indicates the separation of command 2 and command 3. (20H)
6	Command 3	Select and set from the command 3 column in the command table. Refer to chapter 8.2.6 "Communication command table" on page 68 onwards.
7	ETX	Code which indicates the end of send data. (03H)

OD Precision

Tab. 57: Data format of response

8.2.5 Received data format (response)

	02H	03H
STX	Response	ETX
1	2	3

1	STX	Code which indicates the beginning of the receive data. (02H)
2	Response	Response data for the sent command is set.
3	ETX	Code which indicates the end of the received data. (03H)

As the response to the readout command, the character string shown in command 3 of the command table is sent.

There are the following 2 responses for the writing command and control command:

> (3EH) Indicates that data was written correctly.

? (3FH) Indicates that data was not accepted because the command was wrong, etc.

8.2.6 Communication command table

When any Command is sent to unsupported controller unit or sensor head “?” is returned.

Tab. 58: Communication command table

Sensor head setting			
Command 1	Command 2	Command 3	Set contents
HEAD	MEASURE_A MEASURE_B MEASURE_C	FRONT, REAR, THICKNESS, GAP	Measurement target
	SHIFT_A SHIFT_B SHIFT_C	-0.1000 to +0.1000	Calibration (shift)
	SPAN_A SPAN_B SPAN_C	0 to 3.9999	Calibration (span)
	LASER_A LASER_B LASER_C	5 to 0	Laser power
	SENS_A SENS_B SENS_C	MIN, 1 to 9, MAX , AUTO	Sensitivity
	THRESH_A THRESH_B THRESH_C	0 to 14, AUTO	Light receiving waveform threshold
	AVE_A AVE_B AVE_C	1, 2, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096	Number of values taken for moving average
	BAUD_A BAUD_B BAUD_C	9.6 K, 19.2 K, 38.4 K, 57.6 K, 115.2 K, 230.4 K, 460.8 K, 921.6 K, 1843.2 K, 312.5 K, 625.0 K, 1250.0 K	Baud rate
	ALARM_A ALARM_B ALARM_C	CLAMP , HOLD	Output during alarm (when no measurement can be taken)
	SAMP_A SAMP_B SAMP_C	100, 200, 400, 800, 1600, 3200, AUTO	Sampling period (comparable to aperture time)
HEAD	INTER	OFF, ON	Mutual interference prevention (Only available for sensor head A & B.
HEAD	INSTALL_A INSTALL_B INSTALL_C	DIFFUSE SPECULAR	Chose target surface remission type. Available for OD5-85x20 and OD5-30x05 type.

OD Precision

Tab. 59: Communication command table, control output

Control output setting			
Command 1	Command 2	Command 3	Set contents
CONTROL	Q1_HI Q1_LO Q2_HI Q2_LO Q3_HI Q3_LO Q4_HI Q4_LO Q5_HI Q5_LO	-2999.99999 to +2999.99999	Upper/Lower limit value for the different switching outputs.
	HYSTE	0 to +2999.99999	Hysteresis
	MODE	OFF, OFF_DELAY, ON_DELAY, 1SHOT	Delay functions
	TIMER	0 to 60000	Delay time of delay functions
	Q1_SOURCE Q2_SOURCE Q3_SOURCE Q4_SOURCE Q5_SOURCE	A, B, C, CAL	Output source

Tab. 60: Communication command table, analog output

Analog output setting			
Command 1	Command 2	Command 3	Set contents
ANALOG	P1_UP P1_LO P2_UP P2_LO P3_UP P3_LO	-2999.99999 to +2999.99999	Upper/Lower limit value of the different analog outputs
	P1_SOURCE P2_SOURCE P3_SOURCE	A, B, C, CAL	Source for each analog output.

Tab. 61: Communication command table, calculation settings

Calculation setting			
Command 1	Command 2	Command 3	Set contents
CAL	VAL_W VAL_X VAL_Y VAL_Z	0, A, B, C, K	W, X, Y, Z variables for calculation
	OPE_1 OPE_2 OPE_3	+, -	Operator 1/2/3 for calculation
	SIGN_A SIGN_B SIGN_C	FARSIDE+ NEARSIDE+	Measurement value increase/decrease direction, changes the algebraic sign of the measurement value
	K	-2999.99999 to +2999.99999	Value of K, as constant for calculation
	SHIFT_A SHIFT_B SHIFT_C SHIFT_CAL	-2999.99999 to +2999.99999	Shift

Tab. 62: Communication command table, hold settings

Hold setting			
Command 1	Command 2	Command 3	Set contents
HOLD	A B C CAL	OFF SAMPLE PEAK BOTTOM P-P AUTOPEAK AUTOBOTOM	Hold functions

Tab. 63: Communication command table, filter setting

Filter setting			
Command 1	Command 2	Command 3	Set contents
FILTER	FILTER	OFF HIPASS LOPASS	Filter functions
	FREQ	10/10 15/20 25/50 50/100 100/200 200/400 350/800 650/2000	Cut-off frequency for filter functions

OD Precision

Tab. 64: Communication command table, bank setting

Bank setting			
Command 1	Command 2	Command 3	Set contents
BANK	BANK	0 to 15	Bank

Tab. 65: Communication command table, memory setting

Memory setting			
Command 1	Command 2	Command 3	Set contents
MEMORY	FROM	0 to 15, INI	Copy source
	TO	0 to 15, ALL, COMMON, RESET	Copy destination
	EXE	NO, YES	Copy execution

Tab. 66: Communication command table, measurement value read out

Measurement value readout			
Command 1	Command 2	Command 3	Set contents
MEASURE	A B C CAL AB ABC	-	Readout of measurement value or calculation value of sensor head, or several sensor heads (1 measurement value only)
	START_A START_B START_C START_CAL START_AB START_ABC	-	Readout of measurement value or calculation value of sensor head, or several sensor heads (Start of continuous readout)
	STOP	-	Stop of continuous read-out
	SIZE	0, 10, 20, 50, 100, 200, 500, 1000, 2000, 5000, 10000, 20000, 50000	Sets the number of measurement values to be sent for continuous readout. When 0 (zero) is selected, data continues to be sent until the "stop" command is received. Default: 10

Measurement value readout			
Command 1	Command 2	Command 3	Set contents
	RATE	1, 2, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768	Slows down the output rate for continuous readout. Measurement value is read out per 100 µs when 1 is selected, and per 6.4 ms when 64 is selected. (The output rate for RS 232 is controlled by the chosen baud rate. Default: 1
MEASURE	ZEROSUP	YES, NO	Sets zero suppression to the measurement value to be read out. Example: +85.00000 (YES) +0085.00000 (NO) Default: YES

Example:

```

PC -> AOD5 (STX)MEASURE A(ETX)
AOD5 -> PC (STX)+30.12345(ETX)
PC -> AOD5 (STX)MEASURE B(ETX)
AOD5 -> PC (STX)+85.54321(ETX)
PC -> AOD5 (STX)MEASURE AB(ETX)
AOD5 -> PC (STX)+30.12345+85.54321(ETX)
PC -> AOD5 (STX)MEASURE ABC(ETX)
AOD5 -> PC (STX)+30.12345+85.54321+350.12345(ETX)
PC -> AOD5 (STX)MEASURE START_A(ETX)
AOD5 -> PC +30.12345(CR)
+30.23456(CR)
+30.34567(CR)
+30.45678(CR) ·
.
PC -> AOD5 (STX)MEASURE START_ABC(ETX)
AOD5 -> PC +30.12345+85.54321+350.12345(CR)
+30.23456+85.65432+351.23456(CR)
+31.34567+86.76543+361.34567(CR)
+32.45678+76.654321+391.12340(CR)

```


OD Precision

Note

Tab. 67: Reading out period at different communication speeds.

RATE	Reading out period (Reference)		
	USB	RS 232 (115.2 kbps)	RS 232 (38.4 kbps)
1	100 µs	1.1 ms	2.6 ms
2	200 µs	1.2 ms	2.6 ms
4	400 µs	1.4 ms	2.7 ms
8	800 µs	1.8 ms	3.1 ms
16	1.6 ms	2.6 ms	3.9 ms
32	3.2 ms	4.2 ms	5.5 ms
64	6.4 ms	7.4 ms	8.7 ms
128	12.8 ms	13.8 ms	15.1 ms
256	25.6 ms	26.6 ms	27.9 ms
512	51.2 ms	52.2 ms	53.4 ms
1024	102.4 ms	103.4 ms	105 ms
2048	204.8 ms	205.8 ms	207 ms
4096	409.6 ms	410.6 ms	412 ms
8192	819.2 ms	820.2 ms	820.2 ms
16384	1.6384 s	1.6394 s	1.6394 s
32768	3.2768 s	3.2778 s	3.2778 s

RS 232 values are typical examples under the following condition. Reading out period varies from condition.

- data = 8 bit
- parity = None
- Reading value is "+85.00000" (10 letters including CR.)

Tab. 68: Communication command table, Zero reset

Zero reset			
Command 1	Command 2	-	Set contents
ZERO	A B C CAL	-	Zero reset of measurement value or calculation value of sensor head. This will automatically set the offset/shit value accordingly.
	CAN_A CAN_B CAN_C CAN_CAL	-	Zero reset cancellation of measurement value or calculation value of sensor head

Tab. 69: Communication command table, read firmware

Read firmware command			
Command 1	Command 2	-	Set contents
VERSION	AMP_HARD AMP_SOFT HEAD_A HEAD_B HEAD_C	-	Read out firmware of controller unit and sensor head.

Example:

```

PC -> AOD5      (STX)VERSION HEAD_A(ETX)
AOD5 -> PC      (STX)01.5(ETX)
PC -> AOD5      (STX)VERSION AMP_SOFT(ETX)
AOD5 -> PC      (STX)10.0(ETX)

```

OD Precision

Tab. 70: Communication command table, select operation

Select Operation			
Command 1	Command 2	Command 3	Set contents
HEAD	OPERATION	MEASURE LIGHT_A LIGHT_B LIGHT_C	Roud out measurement data or light distribution curve of sensor head A/B/C.

Tab. 71: Communication command table, get light distribution data

Get light distribution data			
Command 1	Command 2	Command 3	Set contents
MEASURE	LIGHT	-	Light intensity data of each pixel (481 pixels)
	LIGHT_C0		Location of the barycenter of the first peak
	LIGHT_C1		Location of the barycenter of the second peak
	LIGHT_TH		Location of the threshold level

8.2.7 Specification of OD5 Light distribution data

Light intensity data of each pixel (481 pixels)

STX	P1-C1	P1-C2	P1-C3	CR	
	P2-C1	P2-C2	P2-C3		CR
	P480-C1	P479-C2	P479-C3	CR	
	P481-C1	P480-C2	P480-C3	CR	ETX

- P1-C1 Hundreds digit value (ASCII) in the first pixel intensity (0-255)
- P1-C2 Tenths digit value (ASCII) in the first pixel intensity (0-255)
- P1-C3 Once digit value (ASCII) in the first pixel intensity (0-255)
- .
- P481-C1 Hundreds digit value (ASCII) in the 481th pixel intensity (0-255)
- P481-C2 Tenths digit value (ASCII) in the 481th pixel intensity (0-255)
- P481-C3 Once digit value (ASCII) in the 481th pixel intensity (0-255)

Location of the barycenter of the first (second) light-peak

STX	C1	C2	C3	ETX
-----	----	----	----	-----

- C1 Hundreds digit value (ASCII) in the x-coordinate (0-481)
- C2 Tenths digit value (ASCII) in the x-coordinate (0-481)
- C3 Once digit value (ASCII) in the x-coordinate (0-481)

Locaton of the threshold level

STX	C1	C2	C3	ETX
-----	----	----	----	-----

- C1 Hundreds digit value (ASCII) in the Y-coordinate (0-255)
- C2 Tenths digit value (ASCII) in the Y-coordinate (0-255)
- C3 Once digit value (ASCII) in the Y-coordinate (0-255)

Tab. 72: Data format light intensity of each pixel

Tab. 73: Data format location of barycenter of first (second) light-peak

Tab. 74: Data format location of the threshold level

Tab. 75: ASCII code table


8.3 ASCII code table

Character	Hexadecimal	Decimal	Character	Hexadecimal	Decimal	Character	Hexadecimal	Decimal
NUL	0	0	+	2B	43	V	56	86
SOH	1	1	,	2C	44	W	57	87
STX	2	2	-	2D	45	X	58	88
ETX	3	3	.	2E	46	Y	59	89
EOT	4	4	/	2F	47	Z	5A	90
ENQ	5	5	0	30	48	[5B	91
ACK	6	6	1	31	49	\	5C	92
BEL	7	7	2	32	50]	5D	93
BS	8	8	3	33	51	^	5E	94
HT	9	9	4	34	52	_	5F	95
NL	A	10	5	35	53	`	60	96
VT	B	11	6	36	54	a	61	97
NP	C	12	7	37	55	b	62	98
CR	D	13	8	38	56	c	63	99
SO	E	14	9	39	57	d	64	100
SI	F	15	:	3A	58	e	65	101
DLE	10	16	;	3B	59	f	66	102
DC1	11	17	<	3C	60	g	67	103
DC2	12	18	=	3D	61	h	68	104
DC3	13	19	>	3E	62	i	69	105
DC4	14	20	?	3F	63	j	6A	106
NAK	15	21	@	40	64	k	6B	107
SYN	16	22	A	41	65	l	6C	108
ETB	17	23	B	42	66	m	6D	109
CAN	18	24	C	43	67	n	6E	110
EM	19	25	D	44	68	o	6F	111
SUB	1A	26	E	45	69	p	70	112
ESC	1B	27	F	46	70	q	71	113
FS	1C	28	G	47	71	r	72	114
GS	1D	29	H	48	72	s	73	115
RS	1E	30	I	49	73	t	74	116
US	1F	31	J	4A	74	u	75	117
SPACE	20	32	K	4B	75	v	76	118
!	21	33	L	4C	76	w	77	119
"	22	34	M	4D	77	x	78	120
#	23	35	N	4E	78	y	79	121
\$	24	36	O	4F	79	z	7A	122
%	25	37	P	50	80	{	7B	123
&	26	38	Q	51	81		7C	124
'	27	39	R	52	82	}	7D	125
(28	40	S	53	83	~	7E	126
)	29	41	T	54	84	DEL	7F	127
*	2A	42	U	55	85			

OD Precision

8.4 Dimensional drawing


Fig. 41: OD Precision Dimensional drawing



- ① RS 232C interface
- ② USB interface
- ③ Terminal board (detachable)
- ④ For panel mounting bracket (recommended window size 173 x 102 mm)
- ⑤ Sensor head A connection port
- ⑥ Sensor head B connection port
- ⑦ Sensor head C connection port
- ⑧ Terminal board 50-pin extern
- ⑨ DIN rail mounting mechanism

8.4.1 Panel mounting dimensions


Fig. 42: Dimensional drawing Panel



- ① Panel
- ② Size when the controller is mounted to a panel of 4.0 mm thickness

8.4.2 Panel opening dimensions

Fig. 43: Panel opening dimensions



- ① Panel thickness to apply: 1 to 4 mm
- ② Opening

8.5 Accessories

Fig. 44: Extension cables sensor head – controller unit

Extension cable between sensor head and controller		
Type	Order no.	Length (L)
DSL-1212-G02M	6035986	2 m
DSL-1212-G05M	6035987	5 m
DSL-1212-G10M	6045158	10 m
DSL-1212-G20M	6045159	20 m




Fig. 45: Cable for stand-alone use of sensor head

Cable for sensor head (For stand-alone use of sensor head)		
Type	Order no.	Length (L)
DOL-1212-G05M	6035988	5 m
DOL-1212-G10M	6045214	10 m
DOL-1212-G20M	6045215	20 m





Fig. 46: I/O Expansion cable


I/O Connector cable (Half pitch, 50-pin)		
Type	Order no.	Length (L)
IO-EXP-AOD5	6035990	3 m



For pinning refer to chapter 2 "Pin Assignment of 50-pin Input/Output Terminal" on page 8.

Fig. 47: Terminal board connector

12-pin terminal board		
Type	Order no.	
TERM.-AOD5	6035989	Terminal Board Connector



8.5.1 Package descriptions

Controller Main Unit

12-pin terminal board (1 pc)

User Manual

Fixture (1 set including 2 pcs) [For panel mounting]

8.6 List of tables

Tab. 1: Specification.....	7
Tab. 2: Pinning of I/O Expansion Cable.....	8
Tab. 3: Bank switch Input via Expansion cable	10
Tab. 4: Modes.....	15
Tab. 5: Change settings	15
Tab. 6: Sensor types and availability of special functions	17
Tab. 7: Min./Max. thickness of transparent materials for glass gap, rear and glass thickness measurement	18
Tab. 8: Referencing for measuring thickness of transparent material	20
Tab. 9: Setup execute function.....	23
Tab. 10: Calibration function	25
Tab. 11: Set measurement function, choose measurement target.....	29
Tab. 12: Sensor type and function availability.....	29
Tab. 13: Set calibration (shift).....	30
Tab. 14: Set calibration span.....	31
Tab. 15: Set laser power	32
Tab. 16: Set sensitivity.....	32
Tab. 17: Set threshold.....	33
Tab. 18: Set moving average	34
Tab. 19: Set communication speed	35
Tab. 20: Set Clamp / Hold function.....	36
Tab. 21: Set sampling period.....	37
Tab. 22: Sampling period default values	37
Tab. 23: View light distribution on CMOS receiver element.....	38
Tab. 24: Set anti-interference mode	39
Tab. 25: Set sensor head type manually	40
Tab. 26: Sensor head types.....	40
Tab. 27: Set control/switching output.....	41
Tab. 28: Set hysteresis.....	41
Tab. 29: Set delay function.....	42
Tab. 30: Set delay time	43
Tab. 31: Set judgement source	43
Tab. 32: Set analog output	44
Tab. 33: Set source for output.....	45
Tab. 34: Setting calculation	46
Tab. 35: Set algebraic sign of measurement value.....	47
Tab. 36: Set value of constant "K"	47
Tab. 37: Set shift/ offset.....	48
Tab. 38: Hold functions.....	51
Tab. 39: Set filter function	54

Tab. 40: Set filter settings	55
Tab. 41: Hi-/Low- pass filter frequencies	55
Tab. 42: Change bank	56
Tab. 43: Change settings of RS232 communication	56
Tab. 44: Copy data from bank to bank	57
Tab. 45: Return bank to default settings.....	57
Tab. 46: Complete reset	57
Tab. 47: Set internal decimal places visible in RUN mode.....	58
Tab. 48: Set brightness	58
Tab. 49: Set key lighting	58
Tab. 50: Mount controller to DIN rail	59
Tab. 51: Mount controller topanel	59
Tab. 52: Connecting connectors for sensor head.....	61
Tab. 53: Connecting cable to 12-pin terminal board.....	62
Tab. 54: RS232 communication parameters.....	64
Tab. 55: Comand format for read out of data	66
Tab. 56: Comand format for writing data	66
Tab. 57: Data format of response.....	67
Tab. 58: Communication command table.....	68
Tab. 59: Communication command table, control output.....	69
Tab. 60: Communication command table, analog output.....	69
Tab. 61: Communication command table, calculation settings.....	70
Tab. 62: Communication command table, hold settings.....	70
Tab. 63: Communication command table, filter setting.....	70
Tab. 64: Communication command table, bank setting	71
Tab. 65: Communication command table, memory setting.....	71
Tab. 66: Communication command table, measurement value read out.....	71
Tab. 67: Reading out period at different communication speeds.	73
Tab. 68: Communication command table, Zero reset	73
Tab. 69: Communication command table, read firmware.....	74
Tab. 70: Communication command table, select operation	75
Tab. 71: Communication command table, get light distribution data	75
Tab. 72: Data format light intensity of each pixel	75
Tab. 73: Data format location of barycenter of first (second) light-peak.....	75
Tab. 74: Data format location of the threshold level.....	75
Tab. 75: ASCII code table	76

8.7 List of figures

Fig. 1: Pin assignment of 12-pin input/output terminals.....	11
Fig. 2: Parts identifications of controller	12
Fig. 3: Buttons on controller unit	13
Fig. 4: Example in the RUN mode menu	14
Fig. 5: Example in the SET mode menu	14
Fig. 6: Measurement principle: Triangulation	16
Fig. 7: Exemplary light distribution on CMOS receiver element.....	17
Fig. 8: Laser path through transparent material	19
Fig. 9: Light distribution curve on the CMOS receiver elemet.....	21
Fig. 10: Alignment of sensor head for measuring in reflective material	22
Fig. 11: Example of calibration of OD5-85x20 using SOPAS software.....	26
Fig. 12: Perfect alignment.....	27
Fig. 13: Error due to sensor tilt	27
Fig. 14: Schematic of the result of the calibration	28
Fig. 15: Reflection types.....	30
Fig. 16: Moving average and respone time	34
Fig. 17: Clamp/Hold function	36
Fig. 18: Sampling period consequences.....	37
Fig. 19: Light distribution curve	37
Fig. 20: Light distribution curve on CMOS receiver element	38
Fig. 21: Mutual interference	39
Fig. 22: Hysteresis	41
Fig. 23: Timing/delay functions	42
Fig. 24: Analog output	44
Fig. 25: Operators to program calucaltions	46
Fig. 26: Near/Far side +, change algebraic sign	47
Fig. 27: Exemplary calculation functions	49
Fig. 28: Calculation; Thickness with two sensor heads.....	49
Fig. 29: Alignment for measuring with two sensor heads	50
Fig. 30: Sample hold function.....	51
Fig. 31: Peak hold function.....	51
Fig. 32: Bottom hold function	52
Fig. 33: Peak to peak hold function	52
Fig. 34: Auto peak hold function	52
Fig. 35: Auto bottom hold function.....	53
Fig. 36: Hi-Pass Filter	54
Fig. 37: Deactivated filter.....	54
Fig. 38: Input/output diagram	63
Fig. 39: USB communication procedure	64
Fig. 40: RS232C communication pinnig	65

Fig. 41: OD Precision Dimensional drawing	77
Fig. 42: Dimensional drawing Panel	78
Fig. 43: Panel opening dimensions.....	78
Fig. 44: Extension cables sensor head – controller unit	79
Fig. 45: Cable for stand-alone use of sensor head	79
Fig. 46: I/O Expansion cable	79
Fig. 47: Terminal board connector.....	79

Australia

Phone +61 (3) 9457 0600
1800 33 48 02 - tollfree
E-Mail sales@sick.com.au

Austria

Phone +43 (0) 2236 62288-0
E-Mail office@sick.at

Belgium/Luxembourg

Phone +32 (0) 2 466 55 66
E-Mail info@sick.be

Brazil

Phone +55 11 3215-4900
E-Mail comercial@sick.com.br

Canada

Phone +1 905.771.1444
E-Mail cs.canada@sick.com

Czech Republic

Phone +420 2 57 91 18 50
E-Mail sick@sick.cz

Chile

Phone +56 (2) 2274 7430
E-Mail chile@sick.com

China

Phone +86 20 2882 3600
E-Mail info.china@sick.net.cn

Denmark

Phone +45 45 82 64 00
E-Mail sick@sick.dk

Finland

Phone +358-9-25 15 800
E-Mail sick@sick.fi

France

Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Germany

Phone +49 (0) 2 11 53 01
E-Mail info@sick.de

Hong Kong

Phone +852 2153 6300
E-Mail ghk@sick.com.hk

Hungary

Phone +36 1 371 2680
E-Mail ertesites@sick.hu

India

Phone +91-22-6119 8900
E-Mail info@sick-india.com

Israel

Phone +972-4-6881000
E-Mail info@sick-sensors.com

Italy

Phone +39 02 27 43 41
E-Mail info@sick.it

Japan

Phone +81 3 5309 2112
E-Mail support@sick.jp

Malaysia

Phone +603-8080 7425
E-Mail enquiry.my@sick.com

Mexico

Phone +52 (472) 748 9451
E-Mail mario.garcia@sick.com

Netherlands

Phone +31 (0) 30 229 25 44
E-Mail info@sick.nl

New Zealand

Phone +64 9 415 0459
0800 222 278 - tollfree
E-Mail sales@sick.co.nz

Norway

Phone +47 67 81 50 00
E-Mail sick@sick.no

Poland

Phone +48 22 539 41 00
E-Mail info@sick.pl

Romania

Phone +40 356-17 11 20
E-Mail office@sick.ro

Russia

Phone +7 495 283 09 90
E-Mail info@sick.ru

Singapore

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Slovakia

Phone +421 482 901 201
E-Mail mail@sick-sk.sk

Slovenia

Phone +386 591 78849
E-Mail office@sick.si

South Africa

Phone +27 (0)11 472 3733
E-Mail info@sickautomation.co.za

South Korea

Phone +82 2 786 6321
E-Mail info@sickkorea.net

Spain

Phone +34 93 480 31 00
E-Mail info@sick.es

Sweden

Phone +46 10 110 10 00
E-Mail info@sick.se

Switzerland

Phone +41 41 619 29 39
E-Mail contact@sick.ch

Taiwan

Phone +886-2-2375-6288
E-Mail sales@sick.com.tw

Thailand

Phone +66 2 645 0009
E-Mail marcom.th@sick.com

Turkey

Phone +90 (216) 528 50 00
E-Mail info@sick.com.tr

United Arab Emirates

Phone +971 (0) 4 88 65 878
E-Mail info@sick.ae

United Kingdom

Phone +44 (0)17278 31121
E-Mail info@sick.co.uk

USA

Phone +1 800.325.7425
E-Mail info@sick.com

Vietnam

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Further locations at www.sick.com