


Type code

Type code



Not all variants of the type code can be combined!

Measuring range

	Gauge pressure measuring range	Overload limit
X40	0 ... 0.4 bar	0.8 bar
X60	0 ... 0.6 bar	1.2 bar
1X0	0 ... 1 bar	2 bar
1X6	0 ... 1.6 bar	3.2 bar
2X5	0 ... 2.5 bar	5 bar
4X0	0 ... 4 bar	8 bar
6X0	0 ... 6 bar	12 bar
010	0 ... 10 bar	20 bar
016	0 ... 16 bar	32 bar
025	0 ... 25 bar	50 bar
040	0 ... 40 bar	80 bar
060	0 ... 60 bar	120 bar
100	0 ... 100 bar	200 bar
160	0 ... 160 bar	320 bar
250	0 ... 250 bar	500 bar
400	0 ... 400 bar	800 bar
600	0 ... 600 bar	1,200 bar

	Absolute pressure measuring range	Overload limit
X40	0 ... 0.4 bar abs	0.8 bar abs
X60	0 ... 0.6 bar abs	1.2 bar abs
1X0	0 ... 1 bar abs	2 bar abs
1X6	0 ... 1.6 bar abs	3.2 bar abs
2X5	0 ... 2.5 bar abs	5 bar abs
4X0	0 ... 4 bar abs	8 bar abs
6X0	0 ... 6 bar abs	12 bar abs
010	0 ... 10 bar abs	20 bar abs
016	0 ... 16 bar abs	32 bar abs
025	0 ... 25 bar abs	50 bar abs

	± measuring range	Overload limit
1X0	-1 ... 0 bar	2 bar
2X5	-1 ... +1.5 bar	3 bar
4X0	-1 ... +3 bar	6 bar
6X0	-1 ... +5 bar	10 bar
010	-1 ... +9 bar	18 bar
016	-1 ... +15 bar	30 bar
025	-1 ... +24 bar	48 bar

	Gauge pressure measuring range	Overload limit
1K0	0 ... 1,000 bar	2,000 bar

	Absolute pressure measuring range	Overload limit
--	--	-----------------------

	± measuring range	Overload limit
--	--------------------------	-----------------------