


Type code

Type code



Not all variants of the type code can be combined! Not all available variants are shown.

Measuring range

	Gauge pressure measuring range
6X0	0 bar ... 6 bar
010	0 bar ... 10 bar
016	0 bar ... 16 bar
025	0 bar ... 25 bar
040	0 bar ... 40 bar
060	0 bar ... 60 bar
100	0 bar ... 100 bar
160	0 bar ... 160 bar
250	0 bar ... 250 bar
400	0 bar ... 400 bar

	± measuring range
6X0	-1 bar ... +5 bar
010	-1 bar ... +9 bar
016	-1 bar ... +15 bar
025	-1 bar ... +24 bar
040	-1 bar ... +39 bar
060	-1 bar ... +59 bar

	Gauge pressure measuring range
600	0 bar ... 600 bar

	± measuring range
--	--------------------------

	Gauge pressure measuring range
100	0 psi ... 100 psi
160	0 psi ... 160 psi
200	0 psi ... 200 psi
250	0 psi ... 250 psi
300	0 psi ... 300 psi
400	0 psi ... 400 psi
500	0 psi ... 500 psi
600	0 psi ... 600 psi
750	0 psi ... 750 psi
800	0 psi ... 800 psi
1K0	0 psi ... 1,000 psi
1K5	0 psi ... 1,500 psi
2K0	0 psi ... 2,000 psi
3K0	0 psi ... 3,000 psi
4K0	0 psi ... 4,000 psi
5K0	0 psi ... 5,000 psi
6K0	0 psi ... 6,000 psi
7K5	0 psi ... 7,500 psi
8K0	0 psi ... 8,000 psi

	± measuring range
115	-14.5 ... +100 psi
175	-14.5 ... +160 psi
215	-14.5 ... +200 psi
315	-14.5 ... +300 psi