NTXUL

TI 231-01EN

VJ Series



M Series



WXT



JHT200



VJ77



Introduction

The VJ, M Series, and WXT free-program computing units for the JUXTA signal conditioners receive signals such as voltage, current, and contact, apply various computing functions to them, and then convert them into isolated DC voltage, DC current, or contact signals.

The computing units are available in six models that differ depending on their series and input/output specifications. Each one of them has an interface circuit for communication with a Handy Terminal and can perform the following:

- Setting computation programs
- · Entering computation parameters
- · Setting zero and span of the input range
- · Monitoring input and output values

Table 1.1 Models of Free-Program Computing Units

Series	Model	Description		
M Series	MXD-A	One analog input, one contact input, one isolated		
(Plug-in type)		analog output, and one isolated contact output		
	MXS-A	One analog input and two isolated analog outputs		
	MXT-A	Three analog inputs and one isolated analog output		
VJ Series	VJXS-A	One analog input and two isolated analog outputs		
(Compact plug-in	VJX7-A	One analog input and one isolated analog output		
type)		Option (Can select from second isolated analog output,		
		communication output, or two contact outputs)		
WXT	WXT-A	Three analog inputs and one isolated analog output		
(Front-panel				
terminal type)				

In addition, it is possible to collectively set and load setting data and programs from a PC using the VJ77 Parameter Setting Tool.

Notice

- The contents of this manual are subject to change without notice as a result of continuing improvements to the instrument's performance and functions.
- Every effort has been made to ensure accuracy in the preparation of this manual. Should any errors or omissions come to your attention, however, please inform Yokogawa Electric's sales office or sales representative.
- Under no circumstances may the contents of this manual, in part or in whole, be transcribed or copied without our permission.

Trademarks

- Our product names or brand names mentioned in this manual are the trademarks or registered trademarks of Yokogawa Electric Corporation (hereinafter referred to as YOKOGAWA).
- Microsoft, MS-DOS, Windows, Windows XP, Windows Vista, and Windows 7 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe, Acrobat, and Postscript are either registered trademarks or trademarks of Adobe Systems Incorporated.
- We do not use the TM or ® mark to indicate these trademarks or registered trademarks in this user's manual.
- All other product names mentioned in this user's manual are trademarks or registered trademarks of their respective companies.

Functions of VJ, M, and WXT Free-Program Computing Units

TI 231-01EN

CONTENTS

Intro	duction		i
1.	Block I	Diagram and Terminal Arrangement	1-1
	1.1	MXD Free-Program Computing Unit	1-1
	1.2	MXS Free-Program Computing Unit	1-2
	1.3	MXT Free-Program Computing Unit	1-3
	1.4	VJXS Free-Program Computing Unit	1-4
	1.5	VJX7 Free-Program Computing Unit	1-5
	1.6	WXT Free-Program Computing Unit	1-7
2.	Operat	ion of Computation Program	2-1
	2.1	Basic Flow	2-1
	2.2	Principle of Computation	2-2
	2.3	Program Structure, Capacity, and Interval	2-3
3.	Compu	utational Operations and Applications	3-1
	3.1	Program Commands and Corresponding Registers	3-2
	3.2	Arithmetical Operation	3-4
	3.3	Square Root Extraction without Variable Low-cut Point	3-5
	3.4	Square Root Extraction with Variable Low-cut Point (1)	3-6
	3.5	Square Root Extraction with Variable Low-cut Point (2)	3-7
	3.6	Square Root Extraction with Variable Low-cut Point (3)	3-8
	3.7	Absolute Value	3-9
	3.8	Selector	3-10
	3.9	Limiter	3-11
	3.10	Line Segment Function	3-12
	3.11	Comparison	3-19
	3.12	Signal Switching	3-20
	3.13	First-order Lag Computation	3-21
	3.14	First-order Lead (Differential Calculus)	3-22
	3.15	Dead Time Computation	3-23
	3.16	Velocity Computation	3-25
	3.17	Velocity Limiter	3-27
	3.18	Moving Average Computation	3-29
	3.19	Timer	3-31

	3.20	Status Change Detection (for MXD-A Only)3-3	3
	3.21	Pulse Input Counter (for MXD-A Only)3-3	4
	3.22	Integrated Pulse Output Counter (for MXD Only)3-3	5
	3.23	Alarm3-3	6
	3.24	Logical Operation3-3	8
	3.25	Trigonometric Function (for VJX7 and WXT Only)3-3	9
	3.26	Other Functions	2
	3.27	Unconditional Jump3-4	4
	3.28	Conditional Jump3-4	4
	3.29	S Register Exchange3-4	5
	3.30	S Register Rotation3-4	6
	3.31	No Operation3-4	7
	3.32	Contact Input and Output (for MXD-A and VJX7 with Optional Contact Output Only). 3-4	7
	3.33	User Flag3-4	8
	3.34	End of Computation3-4	8
4.	Progra	mming4-	1
	4.1	Programming Procedures4-	2
	4.2	Programming Exercise (Temperature-pressure compensation for ideal gas flow control)4-	
5 .	Progra	m Entry and Setting Fixed Constants5-	1
Appe	ndix 1. L	ist of Program FunctionsApp-	1
Appe	ndix 2. \	Nork SheetApp-	3
Appe	ndix 3. [Data Sheet (for WXT)App	4
Appe	ndix 4. [Data Sheet (for VJX7, VJXS, MXS, MXD and MXT)App-	5
Appe	ndix 5. F	Program SheetApp-	6
Revis	ion Info	rmation	.i

Block Diagram and Terminal Arrangement

1.1 MXD Free-Program Computing Unit

1.1.1 Block Diagram




Figure 1.1.1 MXD Free-Program Computing Unit Block Diagram

1.1.2 Terminal Assignments




Figure 1.1.2 MXD Free-Program Computing Unit Terminal Arrangement

1.2 MXS Free-Program Computing Unit

1.2.1 Block Diagram




Figure 1.2.1 MXS Free-Program Computing Unit Block Diagram

1.2.2 Terminal Assignments




Figure 1.2.2 MXS Free-Program Computing Unit Terminal Arrangement

1.3 MXT Free-Program Computing Unit

1.3.1 Block Diagram




Figure 1.3.1 MXT Free-Program Computing Unit Block Diagram

1.3.2 Terminal Assignments




Figure 1.3.2 MXT Free-Program Computing Unit Terminal Arrangement

1.4 VJXS Free-Program Computing Unit

1.4.1 Block Diagram





Figure 1.4.1 VJXS Free-Program Computing Unit Block Diagram

1.4.2 Terminal Assignments




1	Input	(+)
2	Output 2	(+)
3	Input	(-)
4	Prohibited to co	onnect
5	Output 2	(-)
6	Prohibited to co	onnect
7	Output1	(+)
8	GND	(G)
9	Output1	(-)
10	Power Supply	(L+)
11	Power Supply	(N-)

Note: For 1-output type models, the output 2 terminals are not connected (Prohibited to connect).


Figure 1.4.2 VJXS Free-Program Computing Unit Terminal Arrangement

1.5 VJX7 Free-Program Computing Unit

1.5.1 Block Diagram



When optional code A or 6 (Analog output) is specified.



When optional code P (RS-485 output) is specified.





Figure 1.5.1 VJX7 Free-Program Computing Unit Block Diagram

1.5.2 Terminal Assignments




	N. 0 !! 10 !	Optional Code			
	No Optional Code	A, 6: Analog output	P:Communication output	T: Contact output	
1	Input (+)	Input (+)	Input (+)	Input (+)	
2	N.C.	Output2 (+)	RS-485 B (+)	Contact Output 1	
3	Input (–)	Input (–)	Input (–)	Input (–)	
4	Prohibited to connect	Prohibited to connect	Prohibited to connect	Prohibited to connect	
5	Prohibited to connect	Output 2 (–)	RS-485 A (–)	Contact Output COM	
6	Prohibited to connect	Prohibited to connect	RS-485 COM	Contact Output 2	
7	Output 1 (+)	Output 1 (+)	Output 1 (+)	Output 1 (+)	
8	GND	GND	GND	GND	
9	Output 1 (–)	Output 1 (–)	Output 1 (–)	Output 1 (–)	
10	Power Supply (L+)	Power Supply (L+)	Power Supply (L+)	Power Supply (L+)	
11	Power Supply (N–)	Power Supply (N–)	Power Supply (N–)	Power Supply (N–)	

Figure 1.5.2 VJX7 Free-Program Computing Unit Terminal Arrangement

1.6 WXT Free-Program Computing Unit

1.6.1 Block Diagram



Note: The optional output 2 should be specified by code /D0 and has the same signal as the output 1.

Figure 1.6.1 WXT Free-Program Computing Unit Block Diagram

1.6.2 Terminal Assignments

1 5	② — — 6	3 7	4 8
00			
9	10	1	12
13	14	(5)	16

1	Input 3 (+)	9	Output 2 (+)
2	Input 3 (–)	10	Output 2 (–)
3	Input 2 (+)	11	Output 1 (+)
4	Input 2 (–)	12	Output 1 (–)
5	Prohibited to connect	13	Prohibited to connect
6	Prohibited to connect	14	Power Supply (L+)
7	Input 1 (+)	15	Power Supply (N–)
8	Input 1 (–)	16	GND (GND)

Figure 1.6.2 WXT Free-Program Computing Unit Terminal Arrangement

2. Operation of Computation Program

The signal conditioner has the computing feature built-in as a set of library commands. These commands can be combined to create a specific computation function. The program structure of a computing unit is similar to the one used with calculators with a programming function. The computation program is expressed in the reverse Polish logic notation method without parentheses, which makes writing a program very easy.

2.1 Basic Flow

Figure 2.1.1 shows signal and processing flows in the computing unit.

(1) Input Conversion

The input signals are automatically converted into internal data by the input converter and stored in the corresponding input data registers.

(2) Executing User Program

After the input conversion, the computing unit calls up a user program, loads various data, and executes the objective computation. The results are stored in the corresponding data registers.

(3) Output Conversion

The computing unit stores the data in output data registers, automatically converts them into analog or contact signals, and then outputs them.

The steps (1) to (3) described above are periodically executed at computation intervals (selected from 50ms, 100 ms or 200 ms).




Figure 2.1.1 Computation Basic Flow

2.2 Principle of Computation

This section refers to an example of the addition of two inputs to explain the principle of computation in the user program and the behavior of registers (see figure 2.2.1).

The computation is carried out in a stack of four registers, called S registers (S1, S2, S3, and S4 registers).

Inputting an S register is performed by LOAD instruction (described as LD) and the input data is loaded into the S1 register. Consequently the old data previously stored in the S1, S2, and S3 registers are pushed in a sequential order. Note that the old data in the S4 register is lost.

The computation of data is performed by FUNCTION instruction, which has a variety of computation commands and each command is described by a unique symbol (e.g., ADD [+] or HSL [High Selector]). After performing computation, only the results remain in the S registers and the input data for the computation are lost. The emptied S registers pop up the data in turn. The S4 register holds the same data as stored before the FUNCTION instruction was performed. To store the results in the output registers, use the STORE command (described as ST). Performing the ST command does not affect the contents of S registers.

Assume that the data in S1 to S4 registers, before loading input 1, are A, B, C, and D respectively.

1. Loading Input 1 (LDX1)

Data in the input register (X1) is loaded into the S1 register. Accordingly each data in the S registers will be pushed and the old data D in the S4 register will be extruded.

2. Loading Input 2 (LDX2)

In the same way as input 1, data in the input register (X2) is loaded into the S1 register. Each data in the S registers will be pushed and the old data C in the S4 register will be extruded.

3. Addition (ADD)

The addition of S1 and S2 registers is stored in the S1 register. In consequence, the data in each register will be popped up and the S4 register holds the same old data.

4. Output (STY1)

The data in the S1 register is stored in the output register (Y1). This does not change the contents of the S registers.




Figure 2.2.1 Two-Input Addition and Behavior of Arithmetic Register

2.3 Program Structure, Capacity, and Interval

2.3.1 Program Capacity

The number of program steps that the computing unit can execute is 59 (or 40 for WXT).

2.3.2 Program Load Factor

When the computing unit is connected to a Handy Terminal or VJ77 Parameter Setting Tool, the load factor is displayed as a percentage, with LOAD A17 (A28 for VJX7 or A12 for WXT). This can be displayed but not modified.

Load Factor =
$$\frac{\text{Program Running Time}}{\text{Computation Interval}} \times 100\%$$

Design your program so that the load factor is less than 100%. The computing unit does not operate correctly for load factors greater than 100%. Change the computation interval or modify the program.

2.3.3 Computation Interval

The computation interval of the computing unit can be set and indicated using the CYCLE TIME D47 (D48 for VJX7 or CYCLE TIME B09 for WXT) setting parameter. It can be set to 50 ms^(*), 100 ms or 200 ms.

2.3.4 Program Structure

The program begins with step G01 in the computing unit program area, carries out each step in succession, and ends when the END command or step G59 is executed.

For the WXT, the steps covered by the program area are B20 to B59. Therefore, read "G01 to G59" noted above as "B20 to B59," for the program area of WXT. Also read "nn = 01 to 59" as "nn = 20 to 59," for the step numbers of jump destination by commands (GOnn as unconditional jump and GIFnn as conditional jump).

2.3.5 Input/Output Signals and Registers

The input/output signals are stored in the input/output registers. The user program can store the data in an input register to the arithmetic registers or output the data in the arithmetic registers to the output register, by designating the input/output registers.

Table 2.1 below shows the relationship between the input/output signals and respective registers.

Table 2.1 Input/Output Signals and Registers

Input Register	Signal	Output Register	Signal
X1	Analog Input 1	Y1	Analog Output 1
X2	Analog Input 2	Y2	Analog Output 2
Х3	Analog Input 3	DO1	Digital Output 1
DI1	Digital Input 1	DO2	Digital Output 2

Note: For the WXT, the analog output specified by the optional code /D0 is the same signal as Y1 (analog output 1).


^{*} VJX7 is not available.

2.3.6 Input/Output Signals and Internal Data

The computing unit deals with many input/output signals. This section refers to the example of inputs of 1-5 V and 0-100 mV, and outputs of 1-5 V and 4-20 mA, and their respective input/output ranges are given below in table 2.2, figure 2.3.1, and figure 2.3.2.

Table 2.2 Relationship between Input/Output Signals and Internal Data

	Signal	Percentage Notation	Corresponding Internal Data
Input	1 to 5 V	0% to 100%	0.000 to 1.000
	0 to 100 mV	0% to 100%	0.000 to 1.000
Output	1 to 5 V	0% to 100%	0.000 to 1.000
	4 to 20 mA	0% to 100%	0.000 to 1.000



2.3.7 Internal Computation of Signals

The computing unit expresses its internal digital data in floating decimal format and can perform internal computations under the following conditions:

Range of numbers that can be processed:

-9E + 18 to 9E + 18 (for WXT)

-3.4E + 38 to 3.4E + 38 (for VJX7, VJXS, MXS, MXD and MXT)

Number of significant digits: 4 (for WXT)

7 (for VJX7, VJXS, MXS, MXD and MXT)

However, it adopts the fixed decimal format for computations about time measurement.

2.3.8 Program End

The computing unit offers a programming area ranging from G01 to G59. Basically the program begins the computation with G01 and ends with G59. If it finds an END command during this process, then it ends with the command.

For the WXT, the program area is B20 to B59. Therefore, read "G01 to G59" program steps noted above as "B20 to B59".

3. Computational Operations and Applications

The computing unit is capable of performing various computational functions, including input/output commands and arithmetical operations. This chapter describes their operation, setting procedure, and gives program examples.

Limit to Number of Command Usage

The computational commands are categorized as follows:

- · Basic command: Can be used limitlessly in the program.
- Dynamic command: Can be used only once every computational interval.

The dynamic command consists of time-related functions or functions that have an internal buffer for computation. The computing unit performs them only once every computational interval so that it can measure time and detect the occurrence of a status change after the previous cycle.

Buffer Registers (Tn)

The computing unit is provided with buffer registers (Tn) to store the intermediate data of computations.

The data saved in the Tn register can be used in other steps of the program and holds the same value until another data is stored in the same register. In other words, the Tn register resets its data to zero not every computation period but when the power turns off.

The Tn register consists of T1 to T4 and their values can be displayed using the Handy Terminal or VJ77 Parameter Setting Tool. The on-screen data is shown as a percentage.

Fixed Constants (Cn)

The fixed constants (Cn) are loaded into the arithmetic registers for use by the LD command during computations. The Cn register consists of 59 registers, C01 to C59, and can be set to a value (percentage) using the Handy Terminal (JHT200) or VJ77 Parameter Setting Tool. Take care as some commands use specific fixed constant area.

'H' can also be used instead of 'C' in C01 to C59 to load and display the fixed constants. They can also be used together in a program. In that case, a total of 59 numbers from 01 to 59 can be allocated to nn in Cnn (or Hnn) and C01 and H01, for example, refer to the same fixed constant.

For the WXT, 44 fixed constants, C20 to C63, are available. Therefore, read "C01 to C59" noted above as "C20 to C63."

For setting C01 to C59, set H01 to H59 of the parameter H: CONST.

For the WXT, set C20 to C63 of the parameter C: ADJUST.

3.1 **Program Commands and Corresponding** Registers

The program commands including input/output and arithmetic operations are shown in table 3.1 below.

Table 3.1 Commands and Symbols

Category	Command	Command Symbol	Section Number
Input/output	Load	LDXn, LDYn *1 LDCnn, LDTn *2 LDDIn *3 LDDOn *1 STXn, STYn *1 STTn, STDOn *1	2.2
Basic operation	+,-, x, ÷ Square root extraction Absolute value Selector Limiter Line segment function Comparison Signal switching	ADD, SUB, MLT, DIV SQR ABS HSL, LSL HLM, LLM FX1, FX2, FX3, FX4 *4 CMP SW	3.2 3.3 3.7 3.8 3.9 3.10 3.11 3.12
Dynamic operation	First-order lag First-order lead (Differential calculus) Dead time Velocity Velocity limiter Moving average Timer Status change detection Pulse input counter Square root extraction with variable low-cut point Integrated pulse output counter Alarm	LAGn (n = 1 to 3) *5 LEDn (n = 1 to 3) *5 DED *6 VEL *6 VLMn (n = 1 and 2) *5 MAV *6 TIM CCD *7 PIC *7 SQT, SQAn, SQBn (n = 1 to 3) *5 CPO *7 HALn, LALn (n = 1 and 2) *5, *8	3.13 3.14 3.15 3.16 3.17 3.18 3.19 3.20 3.21 3.4, 3.5 and 3.6 3.22 3.23
Logical operation	Logical multiplication Logical addition Logical negation Exclusive logical addition	AND OR NOT EOR	3.24
Function operation	Trigonometric function Natural logarithm Common logarithm Exponential function Exponentiation	SIN, COS, TAN, ASIN, ACOS, ATN *9 LN LOG EXP PWR	3.25
Others	Unconditional jump Conditional jump S register exchange S register rotation No operation End of computation	GOnn (nn = 01 to 59) *10 GIFnn (nn = 01 to 59) *10 CHG ROT NOP END	3.27 3.28 3.29 3.30 3.31 3.34

The analog input/output registers (Xn/Yn) and digital output registers (DOn) that do not correspond to actual hardware I/O ports can be used as buffers and flags, respectively.

The "nn" in LDCnn is 01 to 59 for computing units other than the WXT and 20 to 63 for the WXT.

^{*3:} The "n" in LDDIn is only 1 for the MXD.
*4: The line segment functions FXn use a specific area of the fixed constants Cnn as parameters for the I/O table. If

you want to use a Cnn with any instruction command other than the FXn, select it from a different area.

*5: The same command, among the LAGn, LEDn, VLMn, SQAn, SQBn, HALn and LALn commands, can be used only once every computational interval. Therefore, more than one command (n commands) is available for each

of these types of commands.

Only one of the DED, VEL, MAV commands can be used in the same program step; they cannot be used only once every computational interval.

Only available for the MXD.

^{7.} Only available for the WAD.
*8. Not available for the WXT.
*9. Only available for the VJX7 and WXT.
*10: For computing units other than the WXT, the "nn"corresponds to the program step numbers G01 to G59. For the WXT, the "nn" corresponds to the program step numbers B20 to B59.

The following table summarizes the registers, fixed constants, and program area related to the input/output commands.

Table 3.2 Input/Output Registers and Program Areas

Item	Register, Constant Area and Program Area Symbols	
	MXD, MXS, MXT, VJXS and VJX7	WXT
Arithmetic register (Sn)	\$1 \$2 \$3 \$4	S1 S2 S3 S4
Buffer register (Tn)	T1 T2 T3 T4	T1 T2 T3 T4
Analog input register (Xn)	X1 X2 *1, *5 X3 *1, *5	X1 X2 X3
Digital input register (DIn)	DI1 *2 DI2 *6 DI3 *6	
Analog output register (Yn)	Y1 Y2 *3	Y1
User flag (DOn)	DO1 *4, *7 DO2 *7 DO3 DO4	DO1 DO2 DO3 DO4
Fixed constant area (Cnn)	C01 *8 C59	C20 • • • • C63
Program area (Bnn)	G01 • • • • • • •	B20 • • • • B59

^{*1:} Can be used for the MXT only.
*2: Can be used if the contact input is custom-ordered for the MXD or MXT.
*3: Can be used as an analog output if the optional analog output is selected for the MXS, VJXS or VJX7. This

^{*5:} *6:

register can also be used as a buffer for any other computing unit.

For the MXD, DO1 cannot be used as a buffer but as a digital output.

For computing units other than the MXT, X2 and X3 can be used as buffers.

Only if the contact input is custom-ordered for the MXT. This register can not be used for any other computing

unit.

If the optional contact input is selected for the VJX7, DO1 and DO2 can be used as digital outputs but not as user

flags.

*8: If used as symbols for fixed constants, "C01 to C59" can also be expressed as "H01 to H59."

3.2 **Arithmetical Operation**

[Mnemonic Instruction Code]

+	:	ADD	Addition	$S2 + S1 \rightarrow S1$
_	:	SUB	Subtraction	$S2-S1 \rightarrow S1$
Х	:	MLT	Multiplication	$S2 \times S1 \to S1$
/	:	DIV	Division	$S2/S1 \rightarrow S1$

[Operation]

The arithmetical operations are performed to data in the S1 and S2 registers and the result is stored in the S1 register.

[Function Block]

The function block can be expressed as an original equation as shown in figure 3.2.1.




Figure 3.2.1 Function Block of Arithmetical Operation

[Program Example]

Figure 3.2.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load fixed constant C01
G03	ADD	X1+C01			Add
G04	LDC02	C02	X1+C01		Load fixed constant C02
G05	DIV	(X1+C01)/C02			Divide
G06	STY1	(X1+C01)/C02			Store the result in Y1
G07	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.3 **Square Root Extraction without Variable Low-cut Point**

[Mnemonic Instruction Code]

SQR Extraction of square root

[Operation]

This command is performed to data in the S1 register and the result is stored in the S1 register.



Figure 3.3.1 Function of Block Square Root Extraction

[Program Example]

Figure 3.3.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	SQR	√X1		Extract square root
G03	STY1	√ X 1		Store the result in Y1
G04	Next computation			

Note: For the WXT, read the program steps and fixed constants in this section as shown below: Program steps: "G01 to G59" as "B20 to B59" Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

3.4 Square Root Extraction with Variable Lowcut Point (1)

[Mnemonic Instruction Code]

: SQT

Extraction of square root with variable low-cut point (for inputs not higher than the low-cut point, the output is the same as input)

[Operation]

This command is performed to data in the S2 register with the S1 register as the low-cut point and the result is stored in the S1 register. The input/output characteristics are shown in figure 3.4.1.




Figure 3.4.1 Input/output Characteristics of Square Root Extraction with Variable Low-cut Point

If the input is not higher than the low-cut point, the output is the same as input. The low-cut point can be set to a value within 0 to 3.4E + 38.

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

This command can form one function block in combination with arithmetical operations. The function block can be expressed as shown in figure 3.4.2, which extracts the input X1 not lower than the set low-cut point and stores the result.



Figure 3.4.2 Function Block of Square Root Extraction with Variable Low-cut Point

[Program Example]

Figure 3.4.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load low-cut point
G03	SQT	√ X 1			Extract square root with low-cut
G04	STY1	√ X 1			Store the result in Y1
G05	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Program steps: "G01 to G59" as "B20 to B59"

Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

TI 231-01EN Jan..06, 2017-00

3.5 Square Root Extraction with Variable Lowcut Point (2)

[Mnemonic Instruction Code]

 SQAn (n = 1 to 3) Extraction of square root with variable low-cut point (for inputs not higher than the low-cut point, the output is the same as input)

[Operation]

This command is performed to data in the S2 register with the S1 register as the low-cut point and the result is stored in the S1 register. The input/output characteristics are shown in figure 3.5.1.




Figure 3.5.1 Input/output Characteristics of Square Root Extraction with Variable Low-cut Point

If the input is not higher than the low-cut point, the output is the same as input. The low-cut point can be set to a value within 0 to 3.4E + 38.

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

This command can form one function block in combination with arithmetical operations. The function block can be expressed as shown in figure 3.5.2, which extracts the input X1 not lower than the set low-cut point and stores the result.



Figure 3.5.2 Function Block of Square Root Extraction with Variable Low-cut Point

[Program Example]

Figure 3.5.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load low-cut point
G03	SQA1	√ X1			Extract square root with low-cut
G04	STY1	√ X1			Store the result in Y1
G05	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Program steps: "G01 to G59" as "B20 to B59"

Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

3.6 Square Root Extraction with Variable Lowcut Point (3)

[Mnemonic Instruction Code]

: SQBn (n = 1 to 3) Extraction of square root with variable low-cut point (for inputs not higher than the low-cut point, the output is 0%)

[Operation]

This command is performed to data in the S2 register with the S1 register as the low-cut point and the result is stored in the S1 register. The input/output characteristics are shown in figure 3.6.1.




Figure 3.6.1 Input/output Characteristics of Square Root Extraction with Variable Low-cut Point

If the input is not higher than the low-cut point, the output is 0%. The low-cut point can be set to a value within 0 to 3.4E + 38.

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

This command can form one function block in combination with arithmetical operations. The function block can be expressed as shown in figure 3.6.2, which extracts the input X1 not lower than the set low-cut point and stores the result.



Figure 3.6.2 Function Block of Square Root Extraction with Variable Low-cut Point

[Program Example]

Figure 3.6.2 can be programmed as shown in the table below.

Program Statement	S1	S2	S3	Description
LDX1	X1			Load input 1
LDC01	C01	X1		Load low-cut point
SQB1	√ X1			Extract square root with low-cut
STY1	√ X1			Store the result in Y1
Next computation				
	LDX1 LDC01 SQB1 STY1 Next		Statement X1 LDX1 X1 LDC01 C01 X1 SQB1 √X1 √X1 STY1 √X1 Next	Statement X1 LDX1 X1 LDC01 C01 X1 SQB1 √X1 √X1 STY1 √X1 √X1 Next √X1 √X1

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.7 **Absolute Value**

[Mnemonic Instruction Code]

ABS Absolute value

[Operation]

This command is performed to data in the S1 register and the result is stored in the S1 register.

[Function Block]

The function block can be expressed as shown in figure 3.7.1, which calculates an absolute value from the difference of two inputs and stores the result (for the MXT-A and WXT-A only).




Figure 3.7.1 Function Block of Absolute Value

[Program Example]

Figure 3.7.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDX2	X2	X1		Load input 2
G03	SUB	X1 – X2			Subtract X2 from X1
G04	ABS	X1-X2			Find the absolute value
G05	STY1	X1-X2			Store the result in Y1
G06	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.8 **Selector**

[Mnemonic Instruction Code]

HSL High selector LSL Low selector

[Operation]

High selector: This command compares the data in S1 and S2 registers, and then stores the higher one in the S1 register.

Low selector: This command compares the data in S1 and S2 registers, and then stores the lower one in the S1 register.

Note the data that has not been selected will be lost.

[Function Block]

The function block of the high selector can be expressed as shown in figure 3.8.1, which compares three inputs.



Figure 3.8.1 Function Block of High Selector for Three Inputs

[Program Example]

Figure 3.8.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDX2	X2	X1		Load input 2
G03	HSL	X1			Select higher data (X1 > X2 in this case)
G04	LDX3	X3	X1		Load input 3
G05	HSL	X1			Select higher data (X1 > X3 in this case)
G06	STY1	X1			Store the result in Y1
G07	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.9 Limiter

[Mnemonic Instruction Code]

HLM High limiter

LLM Low limiter

[Operation]

This command loads the preset ascending limit or descending limit in S1 and input in S2 register, and stores the result of limiting in the S1 register.

[Function Block]

The function block of the high selector can be expressed as shown in figure 3.9.1, which performs high limiting and low limiting in succession. The fixed constants enclosed with parentheses are high/low limits.




Figure 3.9.1 Function Block of High/Low Limiter

[Program Example]

Figure 3.9.1 can be programmed as shown in the table below.

Notice how the values of arithmetic registers change when X1 < C02 < C01.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load ascending limit
G03	HLM	X1			Upper limit (X1 < C20 in this case)
G04	LDC02	C02	X1		Load descending limit
G05	LLM	C02			Lower limit (X1 < C21 in this case)
G06	STY1	C02			Store the result in Y1
G07	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Program steps: "G01 to G59" as "B20 to B59"

Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

3.10 Line Segment Function

[Mnemonic Instruction Code]

FX1 Ten-segment linearizer

FX2 Arbitrary line segment linearizer (10-segment)

FX3 Arbitrary line segment linearizer (20-segment)

FX4 Arbitrary line segment linearizer (any number of segments)

[Operation]

Table 3.10 gives the fixed constant area for the input/output data tables and figures 3.10.1, 3.10.3, 3.10.5 and 3.10.7 show the relationship between inputs and outputs. You can create two 10-segment functions by using the FX1 and FX2 linearizers.

Note: It is not possible to create two functions using the FX3 and FX4 linearizers.

TI 231-01EN Jan..06, 2017-00

Table 3.10 Fixed Constants as Input/Output Data of Line Segment Linearizer

	MXD,MXS	,MXT,V	JXS,VJ	X7	
Fixed constant	Setting address	FX1	FX2	FX3	FX4
C01	H01	Y0		X0	X0
C02	H02	Y1		X1	X1
C03	H03	Y2		X2	X2
C04	H04	Y3		Х3	Х3
C05	H05	Y4		X4	X4
C06	H06	Y5		X5	X5
C07	H07	Y6		X6	X6
C08	H08	Y7		X7	X7
C09	H09	Y8		X8	X8
C10	H10	Y9		X9	X9
C11	H11	Y10		X10	X10
C12	H12		X0	X11	X11
C13	H13		X1	X12	X12
C14	H14		X2	X13	X13
C15	H15		Х3	X14	X14
C16	H16		X4	X15	X15
C17	H17		X5	X16	X16
C18	H18		X6	X17	X17
C19	H19		X7	X18	X18
C20	H20		X8	X19	X19
C21	H21		X9	X20	X20
C22	H22		X10	Y0	Y0
C23	H23		Y0	Y1	Y1
C24	H24		Y1	Y2	Y2
C25	H25		Y2	Y3	Y3
C26	H26		Y3	Y4	Y4
C27	H27		Y4	Y5	Y5
C28	H28		Y5	Y6	Y6
C29	H29		Y6	Y7	Y7
C30	H30		Y7	Y8	Y8
C31	H31		Y8	Y9	Y9
C32	H32		Y9	Y10	Y10
C33	H33		Y10	Y11	Y11
C34	H34			Y12	Y12
C35	H35			Y13	Y13
C36	H36			Y14	Y14
C37	H37			Y15	Y15
C38	H38			Y16	Y16
C39	H39			Y17	Y17
C40	H40			Y18	Y18
C41	H41			Y19	Y19
C42	H42			Y20	Y20
C43	H43			120	Number of
Vn: Innut r		0.4	ıt rogici	l	segments

Fixed constant (Setting address)		WX	Γ	
C20 Y0 X0 C21 Y1 X1 C22 Y2 X2 C23 Y3 X3 C24 Y4 X4 C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45	Fixed constant (Setting address)	FX1	FX2	FX3
C22 Y2 X2 C23 Y3 X3 C24 Y4 X4 C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47		Y0		X0
C22 Y2 X2 C23 Y3 X3 C24 Y4 X4 C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47	C21	Y1		X1
C24 Y4 X4 C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C50		Y2		X2
C24 Y4 X4 C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C50	C23	Y3		Х3
C25 Y5 X5 C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50		Y4		X4
C26 Y6 X6 C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51		Y5		X5
C27 Y7 X7 C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C54				_
C28 Y8 X8 C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C55 <td></td> <td></td> <td></td> <td>X7</td>				X7
C29 Y9 X9 C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C55 Y14 C56 C57 </td <td></td> <td></td> <td></td> <td></td>				
C30 Y10 X10 C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C54		Y9		X9
C31 X0 X11 C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C57 Y16 C58 C59				
C32 X1 X12 C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C54 Y15 C56 C57 Y16 C58 C5			X0	-
C33 X2 X13 C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18				
C34 X3 X14 C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19				
C35 X4 X15 C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C54 Y15 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20 <td></td> <td></td> <td></td> <td>-</td>				-
C36 X5 X16 C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y13 C55 Y14 Y15 C56 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20			_	
C37 X6 X17 C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C54 Y15 C56 C57 Y16 C58 C59 Y18 C60 C60 Y19 C61				
C38 X7 X18 C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 C54 Y13 C55 C54 Y15 C56 C57 Y16 C58 C59 Y18 C60 C61 Y20			_	_
C39 X8 X19 C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y13 C55 Y14 Y15 C56 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20				_
C40 X9 X20 C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y13 C55 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20				
C41 X10 Y0 C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y13 C55 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20			_	
C42 Y0 Y1 C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y13 C55 Y15 Y16 C58 Y17 Y16 C58 Y17 Y18 C60 Y19 Y20			_	_
C43 Y1 Y2 C44 Y2 Y3 C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y13 C55 Y14 Y15 C56 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20	C42		Y0	Y1
C45 Y3 Y4 C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y12 C55 Y14 Y15 C56 Y15 Y16 C58 Y17 Y18 C60 Y19 Y20			Y1	
C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y13 C54 Y13 Y14 C56 Y15 Y16 C57 Y16 Y17 C59 Y18 Y19 C60 Y19 Y20	C44		Y2	Y3
C46 Y4 Y5 C47 Y5 Y6 C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y13 C54 Y13 Y14 C56 Y15 Y16 C57 Y16 Y17 C59 Y18 Y19 C60 Y19 Y20	C45		Y3	Y4
C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y14 C56 Y15 Y16 C57 Y16 Y17 C59 Y18 Y19 C61 Y20	C46			
C48 Y6 Y7 C49 Y7 Y8 C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 Y12 C54 Y13 Y14 C56 Y15 Y16 C57 Y16 Y17 C59 Y18 Y19 C61 Y20	C47		Y5	Y6
C50 Y8 Y9 C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20			Y6	Y7
C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20	C49		Y7	Y8
C51 Y9 Y10 C52 Y10 Y11 C53 Y12 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20	C50		Y8	
C53 Y12 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20			Y9	Y10
C53 Y12 C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20	C52		Y10	Y11
C54 Y13 C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20				Y12
C55 Y14 C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20	C54			
C56 Y15 C57 Y16 C58 Y17 C59 Y18 C60 Y19 C61 Y20	C55			
C58 Y17 C59 Y18 C60 Y19 C61 Y20	C56			
C58 Y17 C59 Y18 C60 Y19 C61 Y20	C57			Y16
C60 Y19 C61 Y20	C58			Y17
C61 Y20				Y18
	C60			
C62				Y20
	C62			

Xn: Input register Yn: Output register

The input data (X0 to X10) for the FX1 linearizer are 0 to 100% in 10% increments.

Output setting conditions: $-6\% \le C01 \text{ to } C11 \le 106\%$

When the input is below 0%, the computing unit does not limit output, which is calculated using the following statement:

When the input is above 100%, the computing unit calculates the output using the following statement:




Figure 3.10.1 Relationship between Input and Output of FX1 Ten-Segment Linearizer

[Function Block]

The function block of the FX1 linearizer can be expressed as shown in figure 3.10.2.



Figure 3.10.2 Function Block of FX1 Linearizer

[Program Example]

Figure 3.10.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	FX1	Output Breakpoints		Ten-segment linearizer
G03	STY1	Output Breakpoints		Store the result in Y1
G04	Next computation			

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Setting conditions:

 $-6\% \le C12 \text{ to } C22 \le 106\%$ For input:

C12 < C13 < C14 < C15 < C16 < C17 < C18 < C19 < C20 < C21 < C22

 $-6\% \le C23 \text{ to } C33 \le 106\%$ For output:

When the input ≤ C12, the computing unit outputs the C23, and when the input ≥ C22, it outputs the C33.




Figure 3.10.3 Relationship between Input and Output of FX2 Arbitrary Ten-Segment Linearizer

[Function Block]

The function block of the FX2 linearizer can be expressed as shown in figure 3.10.4.



Figure 3.10.4 Function Block of FX2 Linearizer

[Program Example]

Figure 3.10.4 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	FX2	Output Breakpoints		Arbitrary ten-segment linearizer
G03	STY1	Output Breakpoints		Store the result in Y1
G04	Next computation			

Note: For the WXT, read the program steps and fixed constants in this section as shown below: Program steps: "G01 to G59" as "B20 to B59" Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

Setting conditions:

 $-6\% \le C01 \text{ to } C21 \le 106\%$ For input:

C01 < C02 < C03 < C04 < C05 < C06 < C07 < C08 < C09 < C10 < C11

< C12 < C13 < C14 < C15 < C16 < C17 < C18 < C19 < C20 < C21

 $-6\% \le C22 \text{ to } C42 \le 106\%$ For output:

When the input ≤ C01, the computing unit outputs the C22, and when the input ≥ C21, it outputs the C42.




Figure 3.10.5 Relationship between Input and Output of FX3 Arbitrary Twenty-Segment Linearizer

[Function Block]

The function block of the FX3 linearizer can be expressed as shown in figure 3.10.6.



Figure 3.10.6 Function Block of FX3 Linearizer

[Program Example]

Figure 3.10.6 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	FX3	Output Breakpoints		Arbitrary twenty-segment linearizer
G03	STY1	Output Breakpoints		Store the result in Y1
G04	Next computation			

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Setting conditions:

For number of line segments: Set the number of line segments in C43.

(Set it at % value. The number of line segments 1 to 20

corresponds to 100 to 2000%.)

For input : $-6\% \le C01 \text{ to } C21 \le 106\%$

C01 < C02 < C03 < C04 < C05 < C06 < C07 < C08 < C09 < C10 < C11

< C12 < C13 < C14 < C15 < C16 < C17 < C18 < C19 < C20 < C21

For output : $-6\% \le C22 \text{ to } C42 \le 106\%$

Since the FX4 linearizer operates based on the desired number of line segments set in C43, there is no need to set from the C01 to C42 fixed constants as with FX3. For the input data table, set as many fixed constants as necessary, beginning with C01 as in C01, C02, C03, . . . Likewise, set as many fixed constants as necessary for the output data table, beginning with C22 as in C22, C23, C24, . . . Setting more data items than necessary results in the extra data items being nullified.

For example, if you specify the number of line segments as 5, set the C01 to C06 and C22 to C27 fixed constants in the data table. Data values set in C07 to C21 and C28 to C42 are ignored.




Figure 3.10.7 Relationship between Input and Output of FX4 Arbitrary Twenty (Max.)-Segment Linearizer

[Function Block]

The function block of the FX4 linearizer can be expressed as shown in figure 3.10.8.



Figure 3.10.8 Function Block of FX4 Linearizer

[Program Example]

Figure 3.10.8 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	FX4	Output Breakpoints		Arbitrary twenty-segment linearizer
G03	STY1	Output Breakpoints		Store the result in Y1
G04	Next computation			

Note: For the WXT, this line-segment function cannot be used.

3.11 Comparison

[Mnemonic Instruction Code]

CMP Comparison

[Operation]

This command compares data in S1 and S2 registers, and stores the value in the S1 register in the following manner:

- If $S1 \le S2$, the value is 1.000.
- If S1 > S2, the value is 0.000.

The old value in the S1 register will be lost but the data in the S2 register remains.

[Function Block]

The function block can be expressed as shown in figure 3.11.1, which performs a comparison between two inputs and then outputs 1.000 (when $X1 \ge X2$) or 0.000 (when X1 < X2).




Figure 3.11.1 Function Block of Comparison

[Program Example]

Figure 3.11.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			
G02	LDX2	X2	X1		
G03	CMP	0 or 1	X1		Compare X1 and X2
G04	STY1	0 or 1	X1		Store the result in Y1
G05	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.12 **Signal Switching**

[Mnemonic Instruction Code]

SW Signal Switching

[Operation]

This command loads data in the S2 and S3 registers, and the switching signal in the S1 register:

- If S1 < 0.5, the data in S3 register is stored in the S1 register.
- If $S1 \ge 0.5$, the data in S2 register is stored in the S1 register.

[Function Block]

The function block can be expressed as shown in figure 3.12.1, which switches two inputs using the C01 as a switching signal.




Figure 3.12.1 Function Block of Signal Switching

[Program Example]

Figure 3.12.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			
G02	LDX2	X2	X1		
G03	LDC01	C01	X2	X1	
G04	SW	X1 or X2			X1 if C01 < 0.5 or X2 if C01 0.5
G05	STY1	X1 or X2			
G06	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.13 **First-order Lag Computation**

[Mnemonic Instruction Code]

LAGn First-order Lag Computation (n = 1 to 3)

$$Y = \frac{1}{1 + T_S} X$$

[Operation]

This command loads the input and time constant in the S2 and S1 registers respectively, performs the computation, and stores the result in the S1 register.

Setting range of time constant (minimum unit is 0.1 second)

The time constant for a first-order lag computation can be set up to 799.9 seconds where 0.000-1.000 (0.0-100.0%) of internal data corresponds to 0-100 seconds. (The internal value setting for the maximum time constant is 7.999.)

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block can be expressed as shown in figure 3.13.1.




Figure 3.13.1 Function Block of First-order Lag Computation

[Program Example]

Figure 3.13.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load time constant
G03	LAG1	(1-e ^{-t/C01})xX1			First-order lag computation
G04	STY1	$(1-e^{-t/C01})xX1$			Store the result in Y1
G05	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.14 First-order Lead (Differential Calculus)

[Mnemonic Instruction Code]

LEDn First-order Lead (Differential Calculus) (n = 1 to 3)

$$Y = \frac{T_{DS}}{1 + T_{DS}} X$$

[Operation]

This command loads the input and time constant in the S2 and S1 registers respectively, performs the computation, and stores the result in the S1 register.

Setting range of time constant (minimum unit is 0.1 second)

As with a first-order lag computation, the time constant for a differential computation can be set up to 799.9 seconds where 0.000-1.000 (0.0-100.0%) of internal data corresponds to 0-100 seconds. (The internal value setting for the maximum time constant is 7.999.)

Derivative gain

The derivative gain is 1.0 and you can multiply the result of first-order lead (differential) computation by a constant as necessary.

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block of the first-order lead (differential) computation with derivative gain can be expressed as shown in figure 3.14.1.




Figure 3.14.1 Function Block of Differential Calculus

[Program Example]

Figure 3.14.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01 G02 G03	LDX1 LDC01 LED1	X1 C01 e ^{-t/C01} xΔX1	X1		Load input 1 Load time constant First-order Lead (Differential calculus)
G04 G05 G06 G07	LDC02 MLT STY1 Next computation	C02 C02 $xe^{-t/C01}x\Delta X1$ C02 $xe^{-t/C01}x\Delta X1$	e ^{-t/C01} x∆X1		Load derivative gain Multiply by gain Store the result in Y1

ΔX1: A variation of input 1

3.15 Dead Time Computation

[Mnemonic Instruction Code]

DED Dead Time Computation

 $Y = e^{-LS} x X$ where L is dead time

This command cannot be used together with the VEL and MAV commands in the same program step.

[Operation]

This command loads the input and dead time in the S2 and S1 registers respectively, performs the computation, and stores the result in the S1 register.

· Setting range of dead time

The dead time can be set up to 2,047,000 seconds where 0.000-1.000 (0.0-100.0%) of internal data corresponds to 0-1000 seconds. (The internal value setting for the maximum dead time is 2047.0.)

· Principle

Figure 3.15.1 explains the principle of operation. The dead time computation stores the input in its dedicated buffer registers every sampling. The buffer register consists of 40 registers and the input moves to the right in the registers.

When the computing units turn on, the last input (A) is stored in all of the 40 buffer registers as an initial value. After dead time setting/40 seconds, the computing unit loads the next input (B). At the same time, all the data in buffer registers move to the right and data in the register 40 is output. Namely, reading an input, data shift, and outputting the 40th data are performed every dead time setting/40 seconds. Furthermore, the computing unit interpolates the outputs to achieve their gradual changes. However, the minimum sampling time is the same as the computation interval, which means if you set the dead time too short not all of the buffer registers may be used for computation. For instance, if the dead time is one second and the computation interval is 100 ms, only 10 buffer registers will be used.




Figure 3.15.1 Operational Principle of Dead Time Computation

Note: As this command is a dynamic operation, it can be used only once every computational interval.




Figure 3.15.2 Input/output Characteristics of Dead Time Computation

[Function Block]

The function block of the differential computation with derivative gain can be expressed as shown in figure 3.15.3.




Figure 3.15.3 Function Block of Dead Time Computation

[Program Example]

Figure 3.15.3 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load dead time
G03	DED	X1 _{t-C01}			Calculates value of X1 before C01 seconds
G04	STY1	X1 _{t-C01}			Store the result in Y1
G05	Next computation				

3.16 Velocity Computation

[Mnemonic Instruction Code]

VEL Velocity Computation

This command cannot be used together with the DED and MAV commands in the same program step.

[Operation]

This command uses the dead time computation and subtracts the input value sampled at a point of time a specified period before the current time from the sampled current input value. This period is set as the 'dead time.'

The velocity computation is performed according to the following equation:

$$Y1_{t} = X1_{t} - X1_{t-C01}$$

where Y1,: Output of velocity computation;

X1,: Current input value

X1_{t-C01}: Input value C01 seconds before

· Setting range of dead time

As with the dead time computation, the dead time can be set up to 2,047,000 seconds where 0.000-1.000 (0.0-100.0%) of internal data corresponds to 0-1000 seconds. (The internal value setting for the maximum dead time is 2047.)




Figure 3.16.1 Input/output Characteristics of Velocity Computation

As in figure 3.16.1, the computation results can be a negative value. So you need to add certain bias or perform the absolute value computation to the output of velocity computation.

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block of the differential computation can be expressed as shown in figure 3.16.2.




Figure 3.16.2 Function Block of Velocity Computation

[Program Example]

Figure 3.16.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1 C01	X1		Load input
G02	LDC01		Λ1		Load velocity computation time
G03	VEL	$X1_{t-}X1_{t-C01}$			Calculates velocity
G04	STY1	$X1_{t-}X1_{t-001}$			Store the result in Y1
G05	Next computation				

3.17 Velocity Limiter

[Mnemonic Instruction Code]

VLMn Velocity Limiter (n = 1 or 2)

[Operation]

This command loads the input, ascending velocity limit, and descending velocity limit in the S3, S2, and S1 registers respectively, performs the computation, and stores the result in the S1 register.

Setting range of velocity limit:

0.1% to 699.9% per minute where 0.001-1.000 (0.1-100.0%) of internal data corresponds to 0.0-100.0% per minute (If the velocity limiter is set to less than 0.1%, this function operates as 0.1%.)

(the internal value setting for the maximum and minimum velocity limits are 6.999 and 0.001, respectively).

· Principle

Figure 3.17.1 explains the principle of operation. Setting the limit at 700.0%/minute (the internal value 7.000) or above does not limit the input as is (i.e., works as an open limit function).




Figure 3.17.1 Input/output Characteristics of Velocity Limiter

[Function Block]

The function block can be expressed as shown in figure 3.17.2.




Figure 3.17.2 Function Block of Velocity Limiter

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Program Example]

Figure 3.17.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDC01	C01	X1		Load ascending velocity limit
G03	LDC02	C02	C01	X1	Load descending velocity limit
G04	VLM1	X1 after limit			Velocity limit computation
G05	STY1	X1 after limit			Store the result in Y1
G06	Next computation				

3.18 Moving Average Computation

[Mnemonic Instruction Code]

MAV Moving Average Computation

This command cannot be used together with the DED and VEL commands in the same program step.

[Operation]

This command is application of the dead time computation, totals the 40 inputs that have been sampled since going back to the preset computation time from the last sampling, and calculates the average.

· Setting range of computation time (minimum unit is 1 second)

As with the dead time computation, the computation time can be set up to 2,047,000 seconds where 0.000-1.000 (0.0-100.0%) of internal data corresponds to 0-1000 seconds. (The internal value setting for the maximum computation time is 2047.)

However, the minimum sampling time is the same as the computation interval, which means the minimum computation time that can use the 40 sampling buffer registers to their full effectiveness is four seconds if the computation interval is 100 ms. Therefore, if you set the computation time too short, not all of buffer registers may be used for computation. For instance, if the computation time is one second and the computation interval is 100 ms, only 10 buffer registers will be used.




Figure 3.18.1 Input/output Characteristics of Moving Average Computation

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block of the moving average computation can be expressed as shown in figure 3.18.2.




Figure 3.18.2 Function Block of Moving Average Computation

[Program Example]

Figure 3.18.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01 G02	LDX1 LDC01	X1 C01	X1		Load input Load computation time
G03	MAV	Moving Average			Calculates moving average
G04	STY1	Moving Average			Store the result in Y1
G05	Next computation				

3.19 Timer

[Mnemonic Instruction Code]

TIM Timer

[Operation]

This command loads value for timer start/stop before computation and the elapsed time after computation in the S1 register. The following table summarizes the behavior of the S1 register:

Before Computation	After Computation	Description
S1 < 0.5	0.000	Timer reset
S1 0.5	Elapsed time	At start of timer or while running

Figure 3.19.1 shows the timer operation. When the timer start signal is off (less than 0.5), the result of TIM computation is 0.000. When the signal is turned on (0.5 or more), the timer starts counting time and the TIM result increases as time elapses. If the count reaches 4,095,999 seconds, it is reset to zero (the internal value 1.000 corresponds to 1000 seconds so that the timer can count up to 4,095,999 seconds).




Figure 3.19.1 Timer Operation

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block can be expressed as shown in figure 3.19.2, which uses the X1 register as the timer start signal.



Figure 3.19.2 Function Block of Timer

[Program Example]

Figure 3.19.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX2	X2		Load timer start signal
G02	TIM	Time		Elapsed time
G03	STY1	Time		
G04	Next computation			

3.20 Status Change Detection (for MXD-A Only)

[Mnemonic Instruction Code]

CCD Status Change Detection

[Operation]

This command returns 1 as output if the input of S1 register changes 0 to 1 at the last computation interval. If no change takes place (e.g., the input holds 1 or 0) or the input changes 1 to 0, it returns 0. Figure 3.20.1 explains the input/output operation when checking the input status change. The status output is 0 at cold start.




Figure 3.20.1 Input/output Operation of Status Change Detection

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block can be expressed as shown in figure 3.20.2.



Figure 3.20.2 Function Block of Status Change Detection

[Program Example]

Figure 3.20.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDDI1	DI1			Load contact input
G02	CCD	0 or 1			Check Status Change
G03	STDO1	0 or 1			Output the result to DO1
G04	Next computation				

3.21 Pulse Input Counter (for MXD-A Only)

[Mnemonic Instruction Code]

PIC Pulse Input Counter

[Operation]

This command increases the counter as a pulse when the data in S2 register changes 0 to 1 while the content of S1 register is ON. For both the ON and OFF time, the computing unit only counts a pulse twice the control interval or longer. The counter can be increased up to 30,000 and if it exceeds 30,000 it limits the count and holds 30,000. The PIC command outputs analog signal of 0 to 30,000.

The internal value 1.000 corresponds to 1000 pulses. Furthermore, in the event of cold start, the computing unit resets the counter to zero and restarts counting from the next interval.

· Setting input conditions

For S2 register: Input

For S1 register: Start/Stop signal; starts or continues counting while the S1 register is ON (≥ 0.5), resets the counter when it is OFF (< 0.5).

Output

S1 register: Counter output (internal value 0 to 1.00 corresponding to 0 to 1000 pulses)

Note: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block can be expressed as shown in figure 3.21.1.



Figure 3.21.1 Function Block of Pulse Input Counter

[Program Example]

Figure 3.21.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01	LDDI1	DI1			Load pulse input
G02	LDX1	X1	DI1		Check start/reset status
G03	PIC	Computation result			Count pulse
G04	STY1	Computation result			Store the result in Y1
G05	Next computation				

3.22 Integrated Pulse Output Counter (for MXD Only)

[Mnemonic Instruction Code]

CPO Integrated Pulse Output

Note that this command uses the DO1 register, therefor the contact output is unavailable if the command is executed. This is because the DO1 cannot be used as a contact output.

[Operation]

This command loads the input and integrating ratio in the S2 and S1 registers, respectively. The S2 register has been made capable of storing data within the range of 0.000 to 10.000, because the data may exceed 1.0 as a result of temperature and pressure compensation. The S1 register can store the integrating ratio of 0.01 to 18.000. Note that the maximum output pulse is 5 pulses/second (for both computation intervals of 0.1 and 0.2 second).

The relationship between the integrating ratio (S1) and input (S2), and the pulse output is as follows:

For the input of 100% (S2):

The integrating ratio of 0 to 1.0 corresponds to 0 to 1000 pulses/hour, namely:

Integrated pulse output = integrating ratio (S1) x input (S2) x 1000 [pulse/hour]

For example, if the integrating ratio (S1) = 0.500 and the input value (S2) = 0.750, then the integrated pulse = $0.5 \times 0.75 \times 1000 = 375$ pulses/hour.

In addition, pulse outputs are ON-pulse of 100 ±1 ms long.

Note 1: A potential problem exists if the integrating ratio is too small, because the integrated value of the ratio and input also becomes too small to calculate or the results include integration errors. In other words, the integrating ratio of 0.01 cannot accommodate inputs no more than 2.4%.

Note 2: As this command is a dynamic operation, it can be used only once every computational interval.

[Function Block]

The function block can be expressed as shown in figure 3.22.1, where C01 is the integrating ratio.



Figure 3.22.1 Function Block of Integrated Pulse Output Counter

[Program Example]

Figure 3.22.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01 G02 G03 G04	LDX1 LDC01 CPO Next computation	X1 C01 X1	X1		Load input Load integrating ratio Output the result to DO1

3.23 **Alarm**

[Mnemonic Instruction Code]

HALn High alarm (n = 1 or 2)

LALn Low alarm (n = 1 or 2)

[Operation]

Stores the input value in the S3 register, the alarm setpoint in the S2 register, and the hysteresis width in the S1 register. A positive value greater than 0 can be stored in the S1 register.

After computation, the computing unit stores "1" in the S1 register if the input value is equal to or greater than the setpoint (abnormal), or stores "0" if the input value is smaller than the setpoint.

The contact outputs of the VJX7 and MXD are not interlocked with the alarm discussed in this section.




Figure 3.23.1 Input/Output Characteristics of Alarm Operation

[Function Block]

The function block can be expressed as shown in figure 3.23.2, where C01 is the alarm setpoint and C02 is the hysteresis width.




Figure 3.23.2 Function Block of Alarm

[Program Example]

Figure 3.23.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	S3	Description
G01 G02 G03 G04 G05	LDX1 LDC01 LDC02 HAL1 STDO1	X1 C01 C02 0/1 0/1	X1 C01 X1 X1	X1	Load input 1 Load alarm setpoint Load hysteresis width High alarm Store the result in DO1
G06	Next computation				

Note: For the WXT, this alarm function cannot be used.

3.24 Logical Operation

[Mnemonic Instruction Code]

 $\begin{array}{lll} \begin{tabular}{lll} \cap: AND & S2 \cap S1 \rightarrow S1 \\ \cup: OR & S2 \cup S1 \rightarrow S1 \\ \hline : NOT & \overline{S1} & \rightarrow S1 \\ \hline \because: EOR & S2 \cup S1 \rightarrow S1 \\ \hline \end{tabular}$

[Operation]

This command deals with the S1 and S2 registers. The result is stored in the S1 register as 0 or 1. The EOR operation returns 0 when the S1 and S2 contain the same value. The data in registers is considered to be 1 if it is 0.5 or more, and 0 if it is not.

[AND]							
S1	S2	S1					
0	0	0					
0	1	0					
1	0	0					
1	1	1					

[OR]					
S1	S2	S1			
0	0	0			
0	1	1			
1	0	1			
1	1	1			

[NOT]				
S1	S1			
0	1			
1	0			

[EOR]						
S1	S2	S1				
0	0	0				
0	1	1				
1	0	1				
1	1	0				

Register Values before and after Operations

3.25 Trigonometric Function (for VJX7 and WXT Only)

[Mnemonic Instruction Code]

SIN Sine

COS Cosine

TAN Tangent

ASIN Arcsine (SIN-1)

ACOS Arccosine (COS-1)

ATAN Arctangent (TAN-1)

[Operation]

The trigonometric function commands deal with the S1 register. The result is stored back in the S1 register . As with angle of trigonometric function,0-1.000 of internal data corresponds to 0-360 degree (0 to 2 π radian).




Figure 3.25.1 Input/output Characteristics of Sine Calculation




Figure 3.25.2 Input/output Characteristics of Cosine Calculation




Figure 3.25.3 Input/output Characteristics of Tangent Calculation




Figure 3.25.4 Input/output Characteristics of Arcsine Calculation




Figure 3.25.5 Input/output Characteristics of Arccosine Calculation




Figure 3.25.6 Input/output Characteristics of Arctangent Calculation

[Function Block]

A function block example of sine function can be expressed as shown in figure 3.24.7.



Figure 3.25.7 Function Block of Sine Calculation

[Program Example]

Figure 3.24.7 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	SIN	SIN (X1)		Sine calculation
G03	STY1	SIN (X1)		Store the result to Y1
G04	Next computation			

Note: For the WXT, read the program steps and fixed constants in this section as shown below: Program steps: "G01 to G59" as "B20 to B59"

Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

3.26 Other Functions

[Mnemonic Instruction Code]

LN Natural Logarithm

LOG Common Logarithm

EXP Exponential Function

PWR Power Function

[Operation]

All functions except PWR function are performed to the S1 register and the result is stored in the S1 register. The PWR function calculates "(S2)(S1)" and stores the result in the S1 register. The behavior of registers when the PWR function is executed is shown in figure 3.26.1 below.




Figure 3.26.1 Behavior of S Registers When PWR Function Is Executed

[Program Example a]

The PWR function can be programmed as follows.

Step	Program Statement	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	LDC01	C01	X1	C01 (exponent)
G03	PWR	X1 ^{C01}		Exponential calculation
G04	STY1	X1 ^{C01}		Store the result to Y1
G05	Next computation			

[Function Block]

A function block example of the LOG function can be expressed as shown in figure 3.26.2.



Figure 3.26.2 Function Block of LOG Function

[Program Example b]

Figure 3.26.2 can be programmed as shown in the table below.

Step	Program Statemen	S1	S2	Description
G01	LDX1	X1		Load input 1
G02	LOG	LOG (X1)		LOG calculation
G03	STY1	LOG (X1)		Store the result to Y1
G04	Next computation			

3.27 **Unconditional Jump**

[Mnemonic Instruction Code]

GOw w Unconditional Jump; where w w: 01 to 59 (20 to 59 for the WXT)

Unconditional jump is used to branch a program flow.

[Operation]

With this command, the program execution jumps to the step Gnn. The command does not change the arithmetic registers.

[Program Example]

Ste	р	Program Statement	S1	S2	S3	Description
G0	1	GO04	Α	В	С	
G0:	2					
G0:	3					
G0	4	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

Program steps: "G01 to G59" as "B20 to B59"

Fixed constants: "C01 to C59 (or H01 to H59)" as "C20 to C63"

3.28 **Conditional Jump**

[Mnemonic Instruction Code]

GIFnn Conditional Jump; where nn: 01 to 59 (20 to 59 for the WXT)

[Operation]

The program execution jumps to the step Gnn if the content of S1 register is 1. If the S1 register contains 0, then the program execution continues to the step next to the GIF command. After this command, the last data in S1 register will be lost and the data in S2 to S4 registers are pushed up to the S1 to S3 registers, respectively. The S4 register holds the old value.

The data in S1 register is considered to be 1 if it is 0.5 or more, and 0 if it is not.

[Program Example]

Step	Program Statement	S1	S2	S3	Description
G01	LDDI1	DI1	Α	В	1
G02	GIF06	Α	В	С	$\sqrt{S1}$
G03	Next computation				
G04					0
G05					
G06	Next computation				-

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.29 S Register Exchange

[Mnemonic Instruction Code]

CHG S Register Exchange

[Operation]

This command exchanges the data between S1 and S2 registers. The other registers, S3 and S4, still hold previous data. Figure 3.29.1 given below shows the behavior of registers when the CHG command is executed.

Arithmetic register




Figure 3.29.1 Behavior of S Registers When CHG Command Is Executed

[Function Block]

The function block can be expressed as shown in figure 3.29.2.



Figure 3.29.2 Function Block of S Register Exchange

[Program Example]

Exchanging the data between S1 and S2 registers can be programmed as follows.

Step	Program Statement	S1	S2	S3	Description
G01	LDX1	X1			Load input 1
G02	LDX2	X2	X1		Load input 2
G03	LDX3	Х3	X2	X1	Load input 3
G04	CHG	X2	Х3	X1	Exchange registers
G05	Next computation				

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.30 **S Register Rotation**

[Mnemonic Instruction Code]

ROT S Register Rotation

[Operation]

This command rotates data in all registers. Namely, the data in S2, S3, and S4 registers are pushed into the S1, S2, and S3 registers respectively and the data in the S1 register moves to the S4 register. The behavior of the registers when the ROT command is executed is shown below in figure 3.30.1.




Figure 3.30.1 Behavior of the S Registers When ROT Command Is Executed

[Function Block]

The function block can be expressed as shown in figure 3.30.2.



Figure 3.30.2 Function Block of S Register Rotation

[Program Example]

Loading and rotating the data in S registers can be programmed as follows.

Step	Program Statement	S1	S2	S3	S4	Description
G01	LDX1	X1				Load input 1
G02	LDX2	X2	X1			Load input 2
G03	LDX3	Х3	X2	X1		Load input 3
G04	LDC01	C01	Х3	X2	X1	Load fixed constant
G05	ROT	Х3	X2	X1	C01	Rotate registers
G06	Next computation					

Note: For the WXT, read the program steps and fixed constants in this section as shown below:

3.31 No Operation

[Mnemonic Instruction Code]

NOP

[Operation]

This command has no effect on the program operation.

3.32 Contact Input and Output (for MXD-A and VJX7 with Optional Contact Output Only)

[Mnemonic Instruction Code]

Symbol	MXD	VJX7 with Optional Contact Output
LDDI1	Loads contact input	
LDDO1	Loads contact output status	Loads contact output status
LDDO2		Loads contact output status
STD01	Outputs contact	Outputs contact
STDO2		Outputs contact

Note: Those commands are available only with MXD computing unit which has the standard contact I/O function and VJX7 which has an optional contact output function. For other models, DO1 and DO2 registers can be used as user flags.

[Operation]

With these commands, you can input and output contacts in the same way as analog input and output.

The data '0' means contact ON and '1' means OFF.

- LD: This command reads contact input and output statuses to the S1 register. The register's internal data is 0.000 for 0, and 1.000 for 1.
- ST: This command outputs the data of the S1 register as a status. The status data is 0 (contact ON) if the register data is less than 0.5, and 1 (contact OFF) if it is not.
- MXD-A Computing Unit

[Function Block]

The function block can be expressed as shown in figure 3.32.1, which turns ON or OFF the contact output depending on the contact input status. The dotted line indicates the flow of the contact signal.



Figure 3.32.1 Function Block of Contact Input and Output 1

[Program Example]

Figure 3.32.1 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDDI1	0 or 1		Load contact input 1
G02	STDO1	0 or 1		Output contact output 1
G03	Next computation			

VJX7 Computing Unit with Optional Contact Output

[Function Block]

The function block can be expressed as shown in figure 3.32.2, which exchanges the data between contact output 1 and 2.

Figure 3.32.2 Function Block of Contact Output 1 and Output 2

[Program Example]

Figure 3.32.2 can be programmed as shown in the table below.

Step	Program Statement	S1	S2	Description
G01	LDDO1	0 or 1		Load contact output status 1
G02	LDDO2	0 or 1	0 or 1	Load contact output status 2
G03	STDO1	0 or 1	0 or 1	Output data in S1 register (old DO2 status) to contact output 1
G04	CHG	0 or 1	0 or 1	Exchange S1 and S2 registers
G05	STDO2	0 or 1	0 or 1	Output data in S1 register (old DO1 status) to contact output 2
G06	Next computation			

3.33 User Flag

[Mnemonic Instruction Code]

LDDOn Loading Status Signal

(n = 2 to 4 for the MXD; n = 1 to 4 for the MXS, MXT, VJX7*)

STDOnStoring Status Signal

(n = 2 to 4 for the MXD; n = 1 to 4 for the MXS, MXT, VJX7*)

[Operation]

These commands can be used as temporary storage for the status signal (0 or 1).

3.34 End of Computation

[Mnemonic Instruction Code]

END

[Operation]

This command finishes the computation. If the program encounters the END command, it skips the rest of the computation and quits itself.

^{*:} For the VJX7 with an optional contact output, n = 3 or 4.

4. Programming

You can create programs by combining the examples mentioned in previous chapters. Refer to the following items when creating a program.

Programs should be as simple as possible

Auxiliary functions can be added at the later stage if required, but at the primary stage, programs should be simple, legible and consideration of the main objective function should be made.

Programs should be understandable by anyone

It is not necessary to create super-efficient programs that miss out steps. Such programs are difficult to understand. Bear in mind that programs should be understood by anyone.

• Make full use of exercises and precedents

Making good use of examples and precedents can save labor and is a short cut to making accurate programs. Make use of the exercises given in this document.

4.1 **Programming Procedures**




Figure 4.1.1 Programming Procedure Flow

4.2 Programming Exercise (Temperaturepressure compensation for ideal gas flow control)

This example of computation process shows temperature-pressure compensation of gas flow (Programmable on the MXT-A and WXT-A units).

The example describes scaling of the arithmetic computation and the method of determining a fixed constant.

(1) Determining computation method

As shown in figure 4.2.1, to compensate for flow signals from a differential pressure transmitter, pressure and temperature are adjusted.

Input signals from each detector are entered into the computing unit via a distributor or converter.

The unit performs computation of the three inputs; differential pressure, pressure, and temperature, and then outputs the compensated values.




Figure 4.2.1 Temperature-Pressure Compensation for Gas Flow Control

(2) Assembling of the arithmetic computation

Temperature-pressure compensation for ideal gas flow is normally expressed as follows:

$$Q_{X} = \sqrt{\frac{P_{f} \cdot T_{n}}{P_{n} \cdot T_{f}}} \cdot \Delta P$$

ΔP: Differential pressure

Q, : Gas flow converted to reference conditions

P,: Working gas pressure expressed as an absolute pressure

P_a: Orifice design reference pressure expressed as an absolute pressure

T_r: Working gas temperature expressed as an absolute temperature

T_a: Orifice design reference temperature expressed as an absolute temperature

(3) Normalization of Computation

Physical quantity of compensation expression is converted to normalized signal (0.000-1.000) of computing unit.

$$\begin{aligned} &P_{f} = P_{span} \cdot X2 + P_{min} \\ &T_{f} = T_{span} \cdot X3 + T_{min} \\ &Q_{x} = Q_{span} \cdot Y \\ &\Delta P = \Delta P_{span} \cdot X1 \end{aligned}$$

where X1: Differential pressure signal (0.000-1.000)

X2: Pressure signal (0.000-1.000)

X3: Temperature signal (0.000-1.000)

Y: Compensated flow signal (0.000-1.000)

By substituting normalized signal values, the following expression is obtained:

$$Q_{\text{span}} \cdot Y = \sqrt{\frac{\frac{P_{\text{span}}}{P_{\text{n}}} \cdot X2 + \frac{P_{\text{min}}}{P_{\text{n}}}}{\frac{T_{\text{span}}}{T_{\text{n}}} \cdot X3 + \frac{T_{\text{min}}}{T_{\text{n}}}}} \quad \cdot \Delta P_{\text{span}} \cdot X1$$

Orifice Qx and ΔP are normally designed so as to be $Y = \sqrt{\chi}$ in design reference condition.

Therefore, scaling by $\sqrt{\Delta P_{span}}/Q_{span}$ is not needed and as shown below, temperature pressure compensation expression is

$$Y = \sqrt{\frac{K2 \cdot X2 + A2}{K3 \cdot X3 + A3} \cdot X1}$$
 where $K2 = P_{span}/P_{n}$

$$A2 = P_{min}/P_n$$

$$K3 = T_{span}/T_{n}$$

A3 =
$$T_{min}/T_n$$
.

Since the MXT computing unit has three inputs, temperature and pressure compensations can be made in one unit.

Setting conditions for computation of temperature-pressure compensation

1. Orifice design reference pressure: P_n = 600 kPa

2. Orifice design reference temperature: T_n = 300°C

3. Pressure transmitter range: 0-1000 kPa

4. Temperature converter range: 0-500°C

By substituting the above data, the following expressions can be used to obtain K2, A2, K3, and A3:

- K2 = Pressure transmitter span/Orifice design reference pressure (absolute pressure) = 1000/ (600 + 101.3) = 1.426
- A2 = Pressure transmitter minimum scale (absolute pressure)/Orifice design reference pressure (absolute pressure) = (0 + 101.3)/(600 + 101.3) = 0.1445
- K3 = Temperature converter span/Orifice design reference temperature (absolute temperature) = 500/(300 + 273.15) = 0.8724
- A3 = Temperature transmitter minimum scale (absolute temperature)/Orifice design reference temperature (absolute temperature) = (0 + 273.15)/(300 + 273.15) = 0.4766

By substituting the above:

$$Y = \sqrt{\frac{1.426 \cdot X2 + 0.1445}{0.8724 \cdot X3 + 0.4766}} \cdot X1$$

(4) Fixed constants setting

Allocation of the fixed constants is as shown below:

Pressure compensation computation

Temperature compensation computation

(5) Assembling of the function block

This example can be assembled in the function block by one computation expression:




Figure 4.3.1 Flow Sheet of Function Block

(6) Data entry

After completion of the allotment of input/output and constants, the data is entered in the data sheet.

Table 4.1 shows an example of data entry of temperature-pressure compensation computation.

Table 4.1 Example of Data Sheet Entry (Temperature-Pressure Compensation Computation)

Data		Description	0%	100%
Analog input	X1	Differential pressure (mmH ₂ O)	0	3200
	X2	Pressure (kPa)	0	1000
	Х3	Temperature (°C)	0	500.0
Analog output	Y	Temperature-pressure compensation output (%)	0	100.0
Fixed constant	Value	Description		
C02	142.6%	K2 = 1.426		
C03				
C04	87.24%	K3 = 0.8724		
C05				
C06				
C07	14.45%	A2 = 0.1445		
C08	47.66%	A3 = 0.4766		
C09	0.6%			

K2 = C02

K3 = C04

A2 = C07

A3 = C08

(7) Program sheet

Table 4.2 shows an example of a program for temperature-pressure compensation computation. Enter the data in the program field of the table. Explanations are entered into "Description" column of the program sheet so that execution can be easily and quickly understood at a later date. The arithmetic register columns of the program sheet indicate the contents of registers, other than S4 register, following the execution of each program step. Data does not have to be entered in the arithmetic register columns.

Table 4.2 Program Example (Temperature-Pressure Compensation Computation)

Step	Program Statement	S1	S2	S3	Description
G01	LDX2	X2			Load pressure signal
G02	LDC02	C02	X2		Load fixed constant C02 =
					142.6% (K2 = 1.426)
G03	MLT	C02 x X2			K2 x X2
G04	LDC07	C07	C02 x X2		Load fixed constant C07 =
					14.45% (A2 = 0.1445)
G05	ADD	а			Pressure compensating term
					(a = C02 x X2 + C07)
G06	LDX3	X3	а		Load temperature signal
G07	LDC04	C04	X3	а	Load fixed constant C04 =
					87.24% (K3 = 0.8724)
G08	MLT	C04 x X3	а		K3 x X3
G09	LDC08	C08	C04 x X3	а	Load fixed constant C08 =
					47.66% (A3 = 0.4766)
G10	ADD	b	а		Temperature compensating
					term (b = C04 x X3 + C08)
G11	DIV	a/b			Pressure and temperature
					compensating term
					computation
G12	LDX1	X1	a/b		Load differential pressure
					signal
G13	MLT	a/b x X1			
G14	LDC09	C09	a/b x X1		Load low-cut point C09 =
					0.6%
G15	SQT	√a/b · X1			Temperature-pressure signal
					compensation computation
G16	STY1	√a/b · X1			Output compensated signal
G17	END				

5. Program Entry and Setting Fixed Constants

There are two ways to enter program code or set fixed constants.

One way is to use the Handy Terminal (JHT200) that deals with data one item at a time. The other is to use the Parameter Setting Tool (VJ77) that can collectively process data sent from a PC. Both of them can set and read program code and data, and monitor the data.

Refer to the respective document for details.

5

Appendix 1. List of Program Functions

	0			A	Arithmeti	c Register	Description				
Category	Command symbol	Command	Before Command Execution			After Comm			and Exe	cution	
	Syllibol		S1	S2	S3	S1	S2 -	S3	·		
	LDXn	Load Xn	А	В	С	Xn	Α	В	For MXS, VJXS, VJX7, and MXD: n = 1; For MXT and WXT:n=1 to 3(X _n :Input)		
Load	LDYn	Load Yn	А	В	С	Yn	Α	В	For MXD, MXT, VJXS, VJX7 without optional analog output, and WXT: n = 1; For MXS, VJXS, and VJX7 with optional analog output: n = 1 to 2 (Yn: Output)		
Luau	LDCnn	Load Cnn	Α	В	С	Cnn	Α	В	nn = 01 to 59, Cnn: Fixed constant *1		
	LDTn	Load Tn	Α	В	С	Tn	Α	В	n = 1 to 4, Tn: Buffer register		
	LDDIn	Load DIn	Α	В	С	Dln	Α	В	n = 1, DIn: Digital input *2		
	LDDOn	Load DOn	Α	В	С	DOn	Α	В	n = 1 to 4, DOn: Digital output *3		
	STXn	Store in Xn	Α	В	С	Α	В	С	Stores S1 in Xn.		
01	STYn	Store in Yn	Α	В	С	Α	В	С	Stores S1 in Yn.		
Store	STTn	Store in Tn	Α	В	С	Α	В	С	Stores S1 in Tn.		
	STDOn	Store in DOn	Α	В	С	Α	В	С	Stores S1 in DOn.		
	ADD	Addition	Α	В	С	B+A	С	D	S1←S2+S1		
	SUB	Subtraction	Α	В	С	B-A	С	D	S1←S2-S1		
	MLT	Multiplication	Α	В	С	BxA	С	D	S1←S2xS1		
	DIV	Division	A	В	C	B/A	С	D	S1←S2/S1		
	SQR	Square root extraction	A	В	С	√A	В	C	S1←√S1		
ŀ	ABS	Absolute value	A	В.	C	IAI	В	C	S1← S1		
	HSL	High selector	A	В	С	The higher of A and B	С	D	Compares S1 and S2 registers and stores the higher in S1		
Basic	LSL	Low selector	А	В	С	The lower of A and B	С	D	Compares S1 and S2 registers and stores the lower in S1		
Operation	HLM	High limiter	Upper limit	Input	Α	Limited input	Α	В	If input is less than the upper limit it is stored in S1, if not the upper limit value is stored in S1.		
	LLM	Low limiter	Lower limit	Input	А	Limited input	Α	В	If input is more than lower limit it is stored in S1, if not the lower limit value is stored in S1.		
	FX1,2	Ten-segment linearizer	Input	Α	В	Function output	Α	В	Ten-segment linearizer with equally divided ten break points FX1: C01 to C1 Arbitrary ten-segment linearizer FX2: C12 to C33 *4		
	FX3,4	Arbitrary line segment linearizer	Input	Α	В	Function output	Α	В	Arbitrary twenty-segment linearizer X-axis: C01 to C21, Y-axis: C22 to C42*5*6		
	CMP	Comparison	А	В	С	0/1	В	С	If S1 > S2, 0.000 → S1; If not, 1.000→S1		
	sw	Signal switching	0/1	Α	В	AorB	С	С	If S1 < 0.500, S3 \rightarrow S1; If not, S2 \rightarrow S1		
	SIN	Sine	Α	В	С	SINA	В	С	\$1←SIN(\$1) *7		
	cos	Cosine	Α	В	С	COSA	В	С	\$1←COS(\$1) *7		
	TAN	Tangent	Α	В	С	TANA	В	С	\$1←TAN(\$1) *7		
	ASIN	Arcsine	Α	В	С	ASINA	В	С	S1←ASIN(S1) *7		
Function	ACOS	Arccosine	Α	В	С	ACOSA	В	С	S1←ACOS(S1) *7		
Operation	ATAN	Arctangent	Α	В	С	ATANA	В	С	S1←ATAN(S1) *7		
•	LN	Natural logarithm	Α	В	С	LN (A)	В	С	S1←LN(S1)		
	LOG	Common logarithm	Α	В	С	LOG(A)	В	С	S1←LOG(S1)		
	EXP	Exponential Function	Α	В	С	EXP(A)	В	С	S1←EXP(S1)		
	PWR	Power Function	Α	В	С	BA	С	D	S1←S2 ^{S1}		

 ${\bf A},\,{\bf B},\,{\bf C}$ and ${\bf D}$ represent data prestored in arithmetic registers.

Although the computing unit has the four built-in registers S1 to S4, this table only shows S1 to S3. *1: nn = 20 to 63 for the WXT.

^{*2:} This function can be used for the MXD only.

^{*3:} For the MXD, DO1 is used as a digital output and DO2 to DO4 are used as buffers.

For a VJX7 with optional contact output, DO1, DO2, DO3 and DO4 are used as buffers. *4: For the WXT, FX1: C20 to C30 and FX2: C31 to C52.

^{*5:} For the WXT, FX3: C20 to C61.

^{*6:} For the FX4 linearizer, set as many data items as the number of line segments specified using C43. For the WXT, this function cannot be used. *7: This function can be used for the VJX7 and WXT only.

Command Arithmetic Register											
Category	symbol	Command	Before Co	mmand Ex	ecution	After Comm	and Exe	cution	Description		
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		S1	S2	S3	S1	S2	S3			
	LAGn	First-order lag	Time constant	Input	А	First-order lag computation output	А	В	Performs first-order lag computation of input, and stores the value in S1 (n = 1 to 3).		
	LEDn	Differential calculus	Time constant	Input	Α	Differential calculus output	Α	В	Performs differential calculus computation of input, and stores the value in S1 (n = 1 to 3).		
	DED	Dead time	Dead time	Input	Α	Dead time computation output	Α	В	Stores in S1, the input value sampled at a point of time a specified period before the current time *1		
	VEL	Velocity	Computation time	Input	Α	Velocity computation output	Α	В	Subtracts the input value sampled at a point of time a specified period before the current time from the sampled current input value and stores it in S1 *1		
	VLMn	-	Descending limit	Ascending limit	Input	Limited velocity input	Α	Α	Limits input velocity within preset limits and stores the value in S1 (n = 1 to 2).		
Dynamic	MAV	Moving average computation	Computation time	Input	Α	Moving average	Α	В	Calculates average from a time preset in the past to now and stores the result in S1 *1		
Operation	TIM	Timer	0/1	Α	В	Elapsed time	Α	В	If S1 < 0.500, resets timer; If not, starts or continues timer.		
	CCD	Status change detection	0/1	Α	В	0/1	Α	В	When S1 changes 0 to 1, S1 = 1 *2		
	PIC	Pulse input counter	Reset counter	Input	А	Counter output	Α	В	When S1 changes 0 to 1, S1 = 1 *2		
	SQT	Square root extraction with variable low-cut point	Low-cut point	Α	В	Low-cut √A	В	С	S1 ← Low-cut √S2		
	SQAn	Square root extraction with variable low-cut point	Low-cut point	Α	В	Low-cut	В	С	S1 ← Low-cut √S2(n = 1 to 3)		
	SQBn	Square root extraction with variable low-cut point	Low-cut point	Α	В	Low-cut √A	В	С	S1 ← Low-cut √S2(n = 1 to 3)		
	СРО	Integrated pulse output	Integrating ratio	Input	А	Input	Α	В	Converts input S2 to pulses using S1 as integrating ratio and outputs the result as digital signals *2		
	HALn	High alarm	Hysteresis	Alarm	Input	0/1	Α	Α	Stores in S1, the result of comparing the		
	LALn	Low alarm		point	value				input value of the S3 register with the alarm point of the S2 register and the hysteresis of the S1 register (n = 1 and 2). If the alarm is on, S1 = 1.		
	AND	Logical AND	Α	В	С	A∩B	С	D	S1←S2∩S1		
Logical	OR	Logical OR	Α	В	С	A∪B	С	D	S1←S2∪S1		
Operation	NOT	Logical NOT	Α	В	С	Ā	В	С	S1← S 1		
'	EOR	Logical EOR	Α	В	С	A⊎B	С	D	S1←S2 U S1		
	GOnn	Unconditional jump	Α	В	С	Α	В	С	Jumps to step Bnn (nn = 01 to 59) *3		
	GIFnn	Conditional jump	Α	В	С	В	С	D	If S1 = 0 jumps to the next step, if S1 = 1 jumps to step Bnn (nn = 01 to 59) *3		
	CHG	S register exchange	Α	В	С	В	Α	С	Exchanges S1 and S2 registers.		
Other	ROT	S register rotation	Α	В	С	В	С	D	S2→S1, S3→S2, S4→S3, S1→S4		
Juioi	NOP	No operation	А	В	С	А	В	С	No operation		
	END	END End of computation		В	С	Α	В	С			

A, B, C and D represent data prestored in arithmetic registers.

Although the computing unit has the four built-in registers S1 to S4, this table only shows S1 to S3.


*1: Any two commands among dead time, velocity, and moving average cannot be used together in a program step.

*2: For MXD only.

*3: For the WXT, nn = 20 to 59.

*4: For the WXT, this function cannot be used.

Appendix 2. Work Sheet



Appendix 3. Data Sheet (for WXT)

			· -		ı	Program No. :						
DAI	A SI	166	: 1			Model :						
Tag N	lo. :						Serial No. :					
Plant												
Data			Description	0%	100%		Buffe	er Register	Digita	l Input (Γ	OI1), Output (DOn	
		X1				T1			DO1			
Analog	Innut	X2		†		T2			DO2			
, unalog	input	+ - +		+		+			-	+		
		Х3				T3			DO3	 		
		Y1				T4			DO4			
Analog	Output	Y2		T		Note	: Us	e DO2 to DO4	DI1			
7	o arpar						as user flags.					
Fixed Consta	nt Va	lue	Des	cription		Fixed Co		Value		Descri	ption	
C20						C4						
C21						C4						
C22						C4						
C23						C4						
C25						C4						
C26						C4						
C27							C49					
C28						C50						
C29						C51						
C30						C5						
C31							C53					
C32							C54 C55					
C33						C5						
C35						C5						
C36						C5						
C37						C5						
C38						C6	0					
C39						C6						
C40						C6						
C41						C6	3					
Rema	ırks:											
	 						-		-			
△ No.	Rev	vised	Dr.	Ch.	Cı	ustome	er	Арр.	С	n	Dr.	
\vdash	-											

Appendix 4. Data Sheet (for VJX7, VJXS, MXS, MXD and MXT)

DATA SHEET									Program No. :				
									Model : VJX7				
Т	ag No	. :						Serial No. :					
Р	lant												
D	ata			Description	0%	100%		Buffe	er Register	Digital	Output (DOn)		
			X1	-			T1			DO1			
l +		X2		†		T2			DO2				
		X3		+		T3			DO3				
			Y1		+		T4			DO4			
Δr	nalog C	Jutnut	1		+			o: The	analog input (Vn)		n) registers that do		
٨١	lalog C	Juipui	12				NOU	not o		tual hardware	nd output (Yn) registers that do al hardware I/O ports can be flags.		
	I Constant	Val	ue	Des		Fixed C		Value	Desc	cription			
	101						НЗ						
	102 103						H3 H3						
	103						H3						
	105						H3						
	106						НЗ						
	107						НЗ						
	108						НЗ						
	109 110						H3 H4						
	1111						H4						
	112						H4						
F	113						H4	-3					
	114						H4						
	115						H4						
	116 117						H4						
	117						H4						
	119						H4						
H	120						H5	50					
	121						H5						
	122						H5						
	123 124						H5						
	124 125						HS		+				
Ė	126						H5						
	127						H5						
	128						H5						
	129						H5	9					
	130												
F	Remark	KS:											
	No.	Rev	ised	Dr.	Ch.	Cı	ustom	er	App.	Ch.	Dr.		
_													
								$\overline{}$					

Appendix 5. Program Sheet

PRO	OGRAM S	HEET			Program No. :						
					Model :						
Tag N	lo. :			S	Serial No. :						
Plant											
Step	Command	S1		S2	S3	Des	scription				
Pem-	arke:				1						
Remarks:											
△ No.	Revised	Dr.	Ch.	Custome	r App.	Ch.	Dr.				
					- ' '						

Revision Information

Title : Functions of VJ, M, and WXT Free-Program Computing Units

Manual number: TI 231-01EN

Feb. 2000/1st Edition Newly published

May. 2004/2nd Edition

Jul. 2005/3rd Edition

Dec. 2005/4ht Edition

Jul. 2015/5th Edition Error correction

Jan. 2017/6th Edition

Add the line segment function and alarm function to VJX7.

Written by Yokogawa Electric Corporation Published by Yokogawa Electric Corporation

2-9-32 Nakacho, Musashino-shi, Tokyo 180-8750, JAPAN



YOKOGAWA ELECTRIC CORPORATION

Headquarters

2-9-32, Nakacho, Musashino-shi, Tokyo, 180-8750 JAPAN Phone: 81-422-52-5555

Branch Sales Offices

Osaka, Nagoya, Hiroshima, Kurashiki, Fukuoka, Kitakyusyu

YOKOGAWA CORPORATION OF AMERICA

Head Office

12530 West Airport Blvd, Sugar Land, Texas 77478, USA Phone : 1-281-340-3800 Fax : 1-281-340-3838

2 Dart Road, Newnan, Georgia 30265, USA Phone : 1-800-888-6400/ 1-770-253-7000 Fax : 1-770-254-0928

YOKOGAWA AMERICA DO SUL LTDA.

Praca Acapulco, 31 - Santo Amaro, Sáo Paulo/SP, BRAZIL, CEP-04675-190 Phone : 55-11-5681-2400 Fax : 55-11-5681-4434

YOKOGAWA EUROPE B. V.

Euroweg 2, 3825 HD Amersfoort, THE NETHERLANDS Phone : 31-88-4641000 Fax : 31-88-4641111

YOKOGAWA ELECTRIC CIS LTD.

Grokholskiy per 13 Building 2, 4th Floor 129090, Moscow, RUSSIA

Phone: 7-495-737-7868 Fax: 7-495-737-7869

YOKOGAWA CHINA CO., LTD.

3F Tower D Cartelo Crocodile Building, No.568 West Tianshan Road, Shanghai 200335, CHINA Phone : 86-21-62396262 Fax : 86-21-62387866

YOKOGAWA ELECTRIC KOREA CO., LTD.

(Yokogawa B/D, Yangpyeong-dong 4-Ga), 21, Seonyu-ro 45-gil, Yeongdeungpo-gu, Seoul, 150-866, KOREA Phone : 82-2-2628-6000 Fax : 82-2-2628-6400

YOKOGAWA ENGINEERING ASIA PTE. LTD.

5 Bedok South Road, Singapore 469270, SINGAPORE Phone : 65-6241-9933 Fax : 65-6241-2606

YOKOGAWA INDIA LTD.

Plot No.96, Electronic City Complex, Hosur Road, Bangalore - 560 100, INDIA Phone : 91-80-4158-6000 Fax : 91-80-2852-1442

YOKOGAWA AUSTRALIA PTY. LTD.

Tower A, 112-118 Talavera Road, Macquarie Park NSW 2113, AUSTRALIA

Phone: 61-2-8870-1100 Fax: 61-2-8870-1111

YOKOGAWA MIDDLE EAST & AFRICA B.S.C.(C)

P.O. Box 10070, Manama, Building 577, Road 2516, Busaiteen 225, Muharraq, Kingdom of BAHRAIN

Phone: 973-17358100 Fax: 973-17336100

Apr. '15